



Scooter Controllers

INSTALLATION MANUAL



RHINO2 DS90, DS120, DS160 and DS180



RHINO2 GBK51948 Issue 6

Dec 2024

Page left blank intentionally

1 About this manual

This manual can help you understand and install the Dynamic Controls (DYNAMIC) RHINO2 scooter controller. It describes the general principles, but it gives no guidelines for specific applications. If there is a specific requirement for your application, please contact Dynamic Controls or one of the sales and service agents to assist you.

This manual must be read together with all other relevant scooter component manuals.

In this manual, a few symbols will help you identify the purpose of the paragraph that follows:

🚺 Note

Notes provide supporting information in order to install, configure, and use the product. Not following the instructions given in notes can lead to equipment failure.

Warning

Warnings provide important information that must be followed in order to install, configure, and use the product safely and efficiently. Not following the instructions given in a warning can potentially lead to equipment failure, damage to surrounding property, injury or death.

The term 'programming' used in this manual refers to adjusting parameters and configuring options to suit an application. 'Programming' does not change or alter any software within the controller and is performed using a controlled programming tool available only to authorised personnel.

The product is not user serviceable. Specialised tools are necessary for the repair of any component.

This manual contains integration, set-up, operating environment, test and maintenance information needed in order to ensure reliable and safe use of the product.

Warning

Do not install, maintain or operate this equipment without reading, understanding and following this manual – including the Safety and Misuse Warnings – otherwise injury or damage may result.

Due to continuous product improvement, DYNAMIC reserves the right to update this manual.

About this manual



This manual supersedes all previous issues, which must no longer be used.

🚺 Note

Get the latest version of this manual from Dynamic Controls' website: www.dynamiccontrols.com

DYNAMIC reserves the right to change the product without notification.

Any attempt to gain access to or in any way abuse the electronic components and associated assemblies that make up the scooter system renders the manufacturer's warranty void and the manufacturer free from liability.

DYNAMIC, the DYNAMIC logo, the RHINO logo, the RHINO2 logo are trademarks of Dynamic Controls. All other brand and product names, fonts, and company names and logos are trademarks or registered trademarks of their respective companies.

DYNAMIC owns and will retain all trademark rights and DYNAMIC or its licensors own and will retain all copyright, trade secret and other proprietary rights, in and to the documentation.

All materials contained within this manual, in hard copy or electronic format, are protected by copyright laws and other intellectual property laws.

© Copyright 2011 - 2024 Dynamic Controls. All rights reserved.



2 Contents

1 About this manual	1
2 Contents	3
3 Introduction	7
3.1 RHINO2 overview	8
3.2 RHINO2 features	8
4 Specifications	
4.1 Electrical Specifications	12
4.2 Physical Specifications	14
5 Installation and testing	
5.1 Mounting	
5.1.1 General Mounting Conditions	16
5.1.2 Mounting Orientation	
5.2 Attaching the terminal cover	
5.3 Connections and Wiring	20
5.3.1 General Wiring Recommendations	20
5.3.2 Wiring Diagram for DS90 and DS120	
5.3.3 Wiring Diagram for DS160 and DS180	22
5.4 Battery Connections	23
5.5 Motor Connections	25
5.5.1 Motor Protection	
5.5.2 Motor Testing	
5.6 Park Brake Connections	27
5.6.1 Park Brake Testing	
5.7 Battery Charging and Programming Connections	29
5.7.1 Battery charger connections	30
5.7.2 Programmer Connections	32
5.7.3 External Ambient Temperature Sensor Connection	33
5.8 Tiller Connector	34
5.9 Throttle Configuration	
5.9.1 Protection against open-circuit, short-circuit and leakage current	
5.9.2 Single throttle wiper	
5.9.3 Neutral Detect	
5.9.4 Two throttle wipers - mirrored	
5.9.5 Throttle Calibration	
5.9.6 Speed Limit Pot Connections	41
5.9.7 Alternative Speed Reduction Options	
5.9.8 Tiller Battery Supply	
5.9.9 Key Switch Input	45
5.9.10 Status Indicator Output	
5.9.11 Beeper Output	
5.9.12 Battery Gauge Output	
5.9.13 Brake and Reversing Lights	
5.10 Multifunction Pins	
5.10.1 Multifunction Inputs	48

	E 40.2 Multifunction Outputs	50
	5.10.2 Multifunction Outputs	
	5.11 Controller Power Modes	
	5.11.1 Powered Down	
	5.11.2 Normal Mode	
	5.11.3 Sleep Mode	
	5.11.4 Low Power Mode	
	5.12 Testing	
	Programming	
6	5.1 The Hand Held Programmer (HHP)	57
	6.1.1 Programming menu	. 57
	6.1.2 Diagnostics menu	.61
	6.1.3 Technician menu	. 62
6	5.2 Dynamic Wizard	
	6.2.1 Software version and module version	. 64
6	5.3 Parameter List	65
e	6.4 Parameter Variations	. 70
	6.4.1 Variations by module	70
	6.4.2 Variations by Profile 1	70
	6.4.3 Variations by Profile 2	70
6	5.5 Parameter Descriptions	. 71
	6.5.1 User Personalisation	72
	6.5.2 Throttle Configuration	. 76
	6.5.3 Drive Performance	83
	6.5.4 OEM Drive Limits	. 94
	6.5.5 Motor Management	. 95
	6.5.6 Park Brake Management	106
	6.5.7 Battery Management	108
	6.5.8 System Options	111
	6.5.9 Multi-function Inputs Configuration	113
	6.5.10 Multi-function Outputs Configuration	118
7[Diagnostics	123
7	7.1 Introduction	124
7	7.2 Flash Code Display	124
	7.2.1 Scooter / R-Series Flash Codes	124
	7.2.2 SHARK Flash Codes	125
	7.2.3 Type 3 Flash Codes	126
	7.2.4 Type 4 Flash Codes	126
7	7.3 Diagnostics Tools	127
	7.3.1 Hand Held Programmer	127
	7.3.2 DYNAMIC Wizard	127
	7.3.3 Fault log	127
7	7.4 HHP Fault Codes with sub codes	128
7	7.5 Advanced Diagnostics Logs	130
	7.5.1 Usage Counters (available in both Wizard and HHP)	130
	7.5.2 Run-time Readings (available in HHP – Technician mode only)	130



7.6 Service Scheduler	
7.7 Status Information — Single Wire Communications	
7.7.1 Status information overview	
7.7.2 Physical interface	
7.7.3 Protocol	
8 Appendices	
8.1 Neutral Detect Active States	
8.2 Parts List	
8.3 Intended Use and Regulatory Statement	
8.3.1 Intended Use	
8.3.2 Device Classification	
8.3.3 Compliance and Conformance with Standards	
8.3.4 Programming Adapter	
8.4 Service life	
8.5 Maintenance	
8.6 Warranty	
8.7 Safety and Misuse Warnings / Notices	
8.7.1 Warnings and notices to be included in the User Manual	
8.7.2 Service and Configuration Warnings / Notices	
8.8 Electromagnetic Compatibility (EMC)	
8.8.1 Minimising Emissions	
8.9 Environmental statement	
8.10 Labels	
8.10.1 Product label	
8.10.2 Motor / battery connector label (160 A and 180 A modules only)	
8.10.3 Version label	
9 Index	



Page 6





3 Introduction

3.1 RHINO2 overview	8
3.2 RHINO2 features	8

Introduction



3.1 RHINO2 overview

The RHINO2 scooter controllers provide a reliable, refined, cost-effective control solution for most mobility scooters, and includes:

RHINO2			
Model	Description		
DS90	90A Controller		
DS120	120A Controller		
DS160	160A Controller		
DS180	180A Controller		

3.2 RHINO2 features




Figure 1: RHINO2 – DS90 and DS120

Figure 2: RHINO2 – DS160 and DS180

- 90, 120, 160 and 180A models provide the power you want when you need it
- Programmable acceleration curves, improved rollback on slopes, and improved motor matching algorithms ensuring better curb-climbing and hill-starting capabilities
- Speed reduction wiper (SRW) technology provides a seamless speed reduction in turns for extra stability
- Throttle Dual Decode (requires ISO compliant speed pot) provides extra safety in case of a throttle failure.
- Intelligent motor and battery management providing automatic power flow optimisation, auto battery configuration, 5 V and 12 V battery capacity outputs (Trucharge) and in-depth battery logging and analysis tools
- Support for a range of battery types, multifunction pins and flexible drive inhibits
- Advanced diagnostics and servicing tools, including event and drive time logging, and programmable servicing scheduler
- 2 Drive profiles, brake and reverse lights, reversing beeper and electronic park brake release
- IP54 ingress protection
- A separately available aluminium terminal cover provides increased protection to IP55 when fitted



• Compliant with EU Directive 2011/65/EU of 8 June 2011 - Restrictions on use of Hazardous Substances (RoHS)



Unless otherwise specified, all references in this manual apply to all variants of the RHINO2 controller.



Page 10





4 Specifications

4.1 Electrical Specifications	,
4.2 Physical Specifications	

Specifications



4.1 Electrical Specifications

Parameter	Desc	ription		
Compatible Battery Supply 24 V supply, 2 x 12 V in	4 V supply, 2 x 12 V in series, circuit breaker protected			
Compatible Motor 24 V DC permanent mag	gnet type, typ	pically rated a	200-1000 wa	atts.
	Min	Nominal	Max	Units
Dperating Voltage (V _{batt})	18	24	32	V
Reverse Supply Voltage	-32			V
Quiescent Current (idle)			80	mA
Quiescent Current (sleep)			1	mA
Quiescent Current (Key-Off)			1	mA
Charging Current		4	8	A (RMS)
Throttle Resistance (Pin 2 - Pin 8)	4	5	6	kΩ
Speed Limit Pot – Pin 9 (linear)	90	100	110	kΩ
Speed Reduction Wiper – Pin 4, 6 or 12 (log)	9	10	11	kΩ
Current Rating – DS90				
Continuous (@ 20°C ambient)		36		А
 Peak (180 seconds @ 20°C initial) ^{See} warning below 		90		А
Boost Current		10		А
Boosted Current		100		А
Boost Time		10		S
Current Rating – DS120				
• Continuous (@ 20°C ambient)		48		А
 Peak (180 seconds @ 20°C initial) ^{See} warning below 		120		А
Boost Current		20		А
Boosted Current		140		А
Boost Time		10		S
Current Rating – DS160				
• Continuous (@ 20°C ambient)		64		А
 Peak (180 seconds @ 20°C initial) ^{See} warning below 		160		A
Boost Current		20		А
Boosted Current		180		А
Boost Time		10		S
Current Rating – DS180				
Continuous (@ 20°C ambient)		64		А
 Peak (60 seconds @ 20°C initial) See warning below 		180		A



Parameter	Description				
		Min	Nominal	Max	Units
Boost Current			20		А
Boosted Current			200		А
Boost Time			5		S
Park Brake Output					
Voltage			24		V
Current		1.25			А

Warning

The peak currents indicated above are based on when Stall Timeout is set to zero (that is, the stall timer is disabled). The installer must ensure that the scooter's wiring, connectors, and motor are suitable for these high currents for this time period. The stall timer should never be disabled during normal operation.



4.2 Physical Specifications

Parameter		I	Description		
Aluminium Top, Base and Terminal cover	Aluminium	alloy AD)C12		
Protection Rating (with cover)	Electronics	rated to	P55		
Protection Rating (without cover)	Electronics	rated to	DIP54		
Shipping Weight:	DS90, 120, 160, 180				
Controller Unit Terminal cover	952 grams 55 grams				
		Min	Nominal	Max	Units
Operating Temperature Range		-25 -13		50 122	°C °F
Storage Temperature Range		-40 -40		65 150	°C °F
Operating Humidity Range		0		90	%RH
Connector mating cycles ^{‡1}					
• Battery			30		
• Motor			30		
Park brake			30		
 Battery charging and programming 			30		
• Tiller			30		

‡1 Connector descriptions / part numbers can be found in section 5 Installation and testing.






Figure 4: DS160 and DS180 variants

For mounting hole dimensions, refer to Section 5.1 Mounting

5 Installation and testing

5.1 Mounting	16
5.1.1 General Mounting Conditions	
5.1.2 Mounting Orientation	
5.2 Attaching the terminal cover	
5.3 Connections and Wiring	
5.3.1 General Wiring Recommendations	
5.3.2 Wiring Diagram for DS90 and DS120	
5.3.3 Wiring Diagram for DS160 and DS120	
5.4 Battery Connections	
5.5 Motor Connections	
5.5.1 Motor Protection	
5.5.2 Motor Testing	
5.6 Park Brake Connections	
5.6.1 Park Brake Testing	
5.7 Battery Charging and Programming Connections	
5.7.1 Battery charger connections	
5.7.2 Programmer Connections	
5.7.3 External Ambient Temperature Sensor Connection	
5.8 Tiller Connector	
5.9 Throttle Configuration	35
5.9.1 Protection against open-circuit, short-circuit and	
leakage current	
5.9.2 Single throttle wiper	
5.9.3 Neutral Detect	
5.9.4 Two throttle wipers - mirrored	
5.9.5 Throttle Calibration	
5.9.6 Speed Limit Pot Connections	41
5.9.7 Alternative Speed Reduction Options	
5.9.8 Tiller Battery Supply	
5.9.9 Key Switch Input	
5.9.10 Status Indicator Output	
5.9.11 Beeper Output	
5.9.12 Battery Gauge Output	
5.9.13 Brake and Reversing Lights	. 47
5.10 Multifunction Pins	
5.10.1 Multifunction Inputs	. 48
5.10.2 Multifunction Outputs	. 50
5.11 Controller Power Modes	. 51
5.11.1 Powered Down	51
5.11.2 Normal Mode	. 51
5.11.3 Sleep Mode	
5.11.4 Low Power Mode	52
5.12 Testing	.54

Installation and testing

RHIN



5.1 Mounting

5.1.1 General Mounting Conditions




Figure 5: RHINO2 Mounting Configuration

- The position and orientation should give maximum mechanical protection to the controller.
- Mount out of the path of water splashes from wheels or cowling and protect the connector panel from direct splashing.
- The controller should be mounted under the scooter cover.
- Failure to adhere to the mounting conditions specified may lead to water ingress, which could result in system malfunctions and long-term damage to the unit.
- For peak performance, locate the controller so that air can flow over and around the case, particularly if mounting in the tiller.
- A position close to the batteries and motor is recommended to reduce the length of high-current wires.
- Use both screw positions to attach the controller. M5 cap screws are recommended. Other M5 fasteners can also be used. Do not over tighten the mounting screws (max 8Nm).
- Use a magnetic tip screwdriver for removing and fitting fasteners.
- Refer to section 5.1.2 Mounting Orientation for recommended mounting orientations.
- If an extension loom is fitted, mount it with the female connector facing horizontal or downwards, and protect it from direct splashing. If the extension loom is to be used for frequent disconnection, mount the female connector so that it faces downwards.

Warning

Regardless of mounting orientation, protect scooter wiring, connectors and components (including those of the tiller head) from the risk of damage, water splashes and/or water ingress, and route the cabling so that water will not run down into the connector system. Female connectors on extension cables should be mounted so that they are horizontal or face downwards.

Do not mount the RHINO2 in a position where the user can come into contact with the unit. The case temperature can exceed 41°C.

If cover accessory is used and product is mounted in an orientation that will allow water to pool, a drain or drain holes (of 2.5 mm diameter) should be drilled in the cover.






5.1.2 Mounting Orientation

Recommended mounting orientation

The recommended mounting orientations for RHINO2 units are vertical (with connector side on the bottom) and horizontal (with connector facing upwards or downwards). The horizontal (with connector facing downwards) mounting orientation is permitted to be tilted a further 30° for mounting.






Figure 6: Vertical (Connector side on the bottom) Mounting Orientation



Figure 7: Horizontal (Connector facing upwards) Mounting Orientation




Figure 8: Horizontal (Connector facing downwards) Mounting Orientation



Mounting orientation to be avoided

The horizontally tilted mounting orientations and vertical (with connector side on the top) orientation, which have chances of water and dirt accumulation, are not recommended.





Figure 9: Horizontally Tilted Mounting Orientations







5.2 Attaching the terminal cover

An optional terminal cover is available for the RHINO2 controller. This can be ordered separately – see *8.2 Parts List* for more details.

The terminal cover kit comprises a terminal cover and three M3x8mm screws. To attach the terminal cover, offer it towards the top case ensuring that the locating-lugs (see image below) are positioned in the recesses in the top case, and then screw the terminal cover to the top case with the M3 screws provided.

🚺 Note

- 1. Tighten the screws with a hand torque wrench to 80 cNm. Over-tightening may cause thread damage on the top case.
- 2. When attaching the terminal cover, ensure that no cables are trapped.




Figure 11: Attaching the terminal cover

7 Note

The terminal cover should not be fitted more than five times. If fitted more than five times, there is a risk of stripping the threads of the screw holes.



5.3 Connections and Wiring

5.3.1 General Wiring Recommendations

To maximise performance, minimise EMC emissions, maximise EMC and ESD immunity, and to keep the cabling of the scooter safe and tidy, please observe the following guidelines.

- Keep all cables as short as possible.
- Avoid wire loops, especially loops of single wires instead of wire pairs.
- Try to run wires in pairs or bunches. For example, run the battery positive and negative wires together and the motor positive and negative wires together. Bind wires together and fix them to the chassis.
- Do not route the cables (including the motor cable) near the motor case, where possible.
- Do not leave electrical connections unnecessarily exposed. Insulate exposed connections (for example with sleeving) to reduce the risk of short circuits, exposure to water and connection stress.
- Make sure that all vehicle sub-frames, particularly the transaxle, controller case and tiller head assemblies, are electrically connected.
- Make sure that the controller and speed setting potentiometers are electrically connected to the vehicle frame.
- Do not use the vehicle frame as the earth return. Any electrical low-resistance connection to the frame is a safety risk and is not allowed by international safety standards.
- To minimise electromagnetic emissions by the motor brushes, it may be necessary to fit capacitors between the brush holders and the motor case. Make sure that the leads are kept as short as possible. A suitable capacitor is 4n7, 2kV Ceramic.
- For best electrical performance, the wire size must be as large as possible. Recommended minimum wire sizes are shown in the wiring sections.
- For low-current signals, do not use wire sizes smaller than 0.5mm²/AWG20, because smaller wires are physically not strong enough for this application.
- Make sure that only supplied terminal screws are used.
- The type of cable used must be appropriate for the mechanical and environmental abuse it is likely to encounter.
- Do not use damaged or abused cables. A damaged cable can potentially produce localised heat, sparks or arcing and as such it can cause a fire.
- Protect all cables against possible contact with flammable material.
- All cables used should be resistant to fire to VW-1 (UL 1581) or similar.
- The installation must prevent and/or discourage the user from accessing any cable.
- While assembling the terminal cover, make sure that the wires are not trapped under the cover.
- While installing power and battery connectors of DS90 and DS120 variants, make sure to insert until you feel them click into position.
- Refer to sections 5.3.2 Wiring Diagram for DS90 and DS120 and 5.3.3 Wiring Diagram for DS160 and DS180 for wiring diagrams for all RHINO2 variants.



Warning

- Route the cables and fasten all scooter components in a position so that the cables, the connectors and the connector sockets of the RHINO2 do not allow water entry or suffer from physical strain, abuse or damage, such as cutting or crushing. Take particular care on scooters with movable structures such as seat raise. Make sure that the cables do not extend beyond the scooter so that they cannot be caught or damaged by external objects. Adequate strain relief must be provided and the mechanical limits of the cables/looms must not be exceeded. Ensure connectors are fully mated.
- 2. Cables should be adequately routed and secured to prevent pinching, cutting, crushing and chafing from both the mechanics of the scooter and external objects.
- 3. Cables with live pins should be restrained.
- 4. Disconnect all the cables of the scooter at the powered end whenever units are replaced or moved.
- 5. It is the responsibility of the installer to make sure that the finished wiring package is safe and fit for purpose.
- 6. Before making any connections to the controller, disable the scooter by one of the following means to prevent accidental movement.
 - 1. Place the battery circuit breaker in the open position.
 - 2. Disconnect the motor or batteries and/or elevate the drive wheels.
- 7. To meet ISO requirements, the Battery and Motor connectors must be fixed in such a way they cannot be swapped or transposed. Alternatively, these may be protected by a cover that cannot be removed without the use of tools.
- 8. If the DS160 or DS180 is not mounted under the scooter cover, then the cover accessory must be used.
- 9. The scooter user maintenance schedule and service instructions should include appropriate inspection and maintenance requirements for connectors, cables and wiring. It should also warn against the dangers of poor installation and maintenance of cables.
- 10. The cable size, insulation and connectors should be selected to ensure that any temperature rise during a fault condition does not result in visible damage or temperatures in excess of the dry air rated temperature.
- 11. Only use the defined contacts, connectors and boots with the wiring looms.
- 12. Provide support for cables, which are subject to frequent bending, with a cable chain or equivalent mechanism. Thoroughly test the cabling system where frequent cable-flexing is part of the intended application, and especially, consider the loom operation at low temperatures.

🚺 Note

To meet the requirements of relevant standards, a status indicator must be fitted to the scooter.



5.3.2 Wiring Diagram for DS90 and DS120




Figure 12: Wiring Diagram for DS90 and DS120

5.3.3 Wiring Diagram for DS160 and DS180




Figure 13: Wiring Diagram for DS160 and DS180

🚹 Warning

The fuses shown in these diagrams should be located as close to the controller as is practicable to minimise the length of unprotected cables.





5.4 Battery Connections

Battery connections			
Pin	Function	Minimum Wire Gauge (see notes below)	
B+		DS90: 2 x 3mm ² (2 x 12 AWG) DS120: 2 x 3mm ² (2 x 12AWG) DS160: 2 x 5mm ² (2 x 10AWG) DS180: 2 x 5mm ² (2 x 10AWG)	
В-	,	DS90: 2 x 3mm ² (2 x 12 AWG) DS120: 2 x 3mm ² (2 x 12AWG) DS160: 2 x 5mm ² (2 x 10AWG) DS180: 2 x 5mm ² (2 x 10AWG)	

Mating Connector Part Numbers DS90, DS120				
Dynamic Part #	Part Description	Supplier Part #		
GCN51971	6W Housing 250 Series Plug V0	N/A		
GCN0690	Terminal Female 12-14AWG	170258-2		

Mating Connector Part Numbers DS160, DS180					
Dynamic Part #	amic Part # Part Description Supplier Part #				
GCN1286	Crimp terminal M5 ring yellow 10-12AWG	2-130171-1			

The length of the battery leads should be as short as possible, and the gauge should be as heavy as possible to minimise the combined resistance of the battery wires and fuse, which in turn will help minimise the overall voltage drop under heavy load. The wire gauge recommendations given above are the MINIMUM gauge and are generally suitable for runs up to 800mm. Longer runs will require heavier wire – typically an extra 1.0mm² for each additional 400mm run length. The heavier the wire, the better driving performance will be. These notes are in addition to the general wiring recommendations as described in Section *5.3.1 General Wiring Recommendations*.

Warning

The RHINO2 system has been designed to perform optimally with either absorbed glass mat or Gel Cell 24 V deep cycle lead-acid batteries, rated between 20 - 120 Ah.

기 Note

The final connection to the Battery Positive (+) terminal should not be made until the scooter is completely wired and ready for testing as described in the Testing section.

To comply with ISO requirements, a red wire for the Battery Positive must be used. This must be the only use of a red wire in the controller installation.



The torque settings for the DS160 and DS180 battery terminal's screws should be between 4.5Nm and 5.5Nm. For DS90 and DS120 units, it is essential that at least four (2 pairs) battery terminals are used.

🚺 Note

A thermal circuit breaker or fuse must be installed between the battery supply and the controller, to protect both the batteries and the system wiring. This shall be mounted as close as possible to the battery terminals as per ISO7176-14 requirements. The thermal circuit breaker should have a trip rating no higher than the current limit of the controller or the protection wire. Check thoroughly to ensure that it provides the necessary degree of motor protection.

	Model	Fuse rating	Circuit breaker rating
	DS90	75A	60A
Fuse or circuit breaker	DS120	85A	70A
	DS160	100A	80A
Supply	DS180	110A	100A

🚺 Note

The thermal circuit breaker and fuse ratings, shown above, are for guidance only. The correct rating depends on your system (modules and cables) and should be calculated and verified through design and testing. Ensure that all wiring, overload selection and positioning complies with ISO7176-14 requirements.

If the two batteries are permanently wired together (for example in a single battery box), the best position for the circuit breaker is between the two batteries. If the batteries are separated (individual battery boxes), each battery requires a circuit breaker or fuse. A slow-acting, thermal type circuit breaker is suggested. Make sure that the protection system is in compliance with ISO7176-14 requirements.



5.5 Motor Connections

Motor connections		
Pin	Function	Minimum Wire Gauge (see notes below)
M+		DS90: 2 x 3mm ² (2 x 12 AWG) DS120: 2 x 3mm ² (2 x 12AWG) DS160: 2 x 5mm ² (2 x 10AWG) DS180: 2 x 5mm ² (2 x 10AWG)
M-		DS90: 2 x 3mm ² (2 x 12 AWG) DS120: 2 x 3mm ² (2 x 12AWG) DS160: 2 x 5mm ² (2 x 10AWG) DS180: 2 x 5mm ² (2 x 10AWG)

Mating Connector Part Numbers DS90, DS120				
Dynamic Part #	Supplier Part #			
GCN51970	4W Housing 250 Series Plug V0	N/A		
GCN0690	Terminal Female 12-14AWG	170258-2		

Mating Connector Part Numbers DS160, DS180					
Dynamic Part #	Part # Part Description Supplier Part #				
GCN1286	Crimp terminal M5 ring yellow 10-12AWG	2-130171-1			

The wire gauge recommendations above are the MINIMUM gauge and are generally suitable for runs up to 400mm. Longer runs will require heavier wire – typically an extra 1.0mm² for each additional 200mm run length. The heavier the wire, the better driving performance will be. In particular the length and gauge of wire affects the wire resistance and hence the optimum Load Compensation setting.

Make sure that the *Load Compensation* parameter is tuned to match the scooter wiring for best driving performance.

These notes are in addition to the *General Wiring Recommendations* as described in Section *5.3.1 General Wiring Recommendations*.

The motor polarity can be swapped with the *Motor Reverse* parameter.

🚺 Note

The torque settings for the DS160 and DS180 motor terminals should be between 4.5Nm and 5.5Nm. For DS90 and DS120 units, it is essential that all four motor terminals are used.



5.5.1 Motor Protection

To prevent the motor from overheating, the motor protection function can reduce the performance of the scooter when the motor consumes too much power for a prolonged period.

Enable motor protection with the *Motor Protection* parameter.



Enabling Motor Protection is only useful if its parameters are adapted to match the fitted motor. See the motor specifications given by the motor manufacturer for the correct values.

5.5.2 Motor Testing

The RHINO2 has four different modes for testing the motor circuitry: All, Open, Short and None. These are configured in the Wizard with the *Motor Testing* parameter.



It is highly recommended that motor testing is turned ON.



5.6 Park Brake Connections

	Park Brake Connections				
	Pin	Function	Wire Gauge		
	1	Park Brake Negative	0.5mm ² / 20AWG		
	2	Park Brake Positive	0.5mm ⁻ / 20AWG		
	Mating Connector Part Numbers				
2		Mating Connector Part Numbers			
2.	Dynamic Part #	Mating Connector Part Numbers Part Description	Supplier Part #		
	Dynamic Part # GCN0884		Supplier Part # 39-01-3028		

The RHINO2 supports a 24 V park brake that is connected to the park brake connector. A manual park brake release lever can be fitted so the scooter can be pushed when the controller is turned off. To meet ISO requirements, if a manual park brake release lever is fitted, a micro-switch should be connected in such a way that it inhibits driving when the park brake is released.

For example, wire a micro-switch to any Multifunction input that is configured to inhibit driving and mechanically couple this switch to the park brake release lever.




Figure 14: Recommended Park Brake Wiring using a mechanical release lever






Figure 15: Alternative Park Brake Wiring using a mechanical release lever

Alternatively, a normally closed micro-switch can be placed in series with the park brake. This will cause a Flash Code 5 to be displayed and the scooter will be unable to drive. To clear the fault, engage the park brake and turn the power off and then on again.

If the park brake is released when the scooter is off, the RHINO2 limits the speed of the scooter if the speed of the scooter is higher than the value that is set with the *Roll-away Speed* parameter. This is to make sure that the scooter is limited to a safe speed on a slope while the park brake is released.




Figure 16: Electronic Park Brake release wiring

The park brake may also be released electrically by activating a switch in the tiller. Park brake release functionality is available on any of the *Multifunction Inputs*. Set the corresponding *Pin* [x] *Function* parameter to 'Release Brake'.

The switch can be configured to be active in any of six states. Refer to Section *Active States* for further details about Active States.





If the park brake is released electrically, the RHINO2 limits the speed of the scooter to the value that is set with the *Push Speed* parameter. This is to make sure that the scooter is limited to a safe speed on a slope while the park brakes are electrically released.

Warning

To meet ISO requirements, the scooter must not be able to drive when the park brake is manually released.

Do not operate the park brake release while on a slope or when an occupant is on the scooter.

5.6.1 Park Brake Testing

The RHINO2 has three different modes for testing the park brake circuitry. These are selected with the *Park Brake Testing* parameter.

None — disables all open-circuit park brake testing.
 Pre-Drive — continuously tests that the park brake is present while not driving.
 Driving — continuously tests that the park brake is present including periodic tests while driving. This test may result in some audible noise during driving.

Regardless of the option selected above, the RHINO2 checks the park brake for short circuit faults immediately before and periodically during driving.

Warning

Do not turn off Park Brake Testing unless there is no park brake installed.

5.7 Battery Charging and Programming Connections

Dattery onar	sing and in				
	Charger/Programmer Connections				
	Pin	Function	Wire Gauge		
	1	Battery Negative	1.0mm² (16-18AWG)		
	2	Battery Positive	1.0mm² (16-18AWG)		
	3	External Ambient Temperature Sensor Input	0.5mm² (18-20AWG)		
	4	Multifunction Input/Program (P/I)	0.5mm² (18-20AWG)		
34	Mating Connector Part Numbers				
	Dynamic Part #	Part Description	Supplier Part #		
	GCN0886	Molex 'Mini-Fit Jr' 4-socket housing	39-01-3048		
	GCN0776	Molex 'Mini-Fit Jr' Receptacles 16AWG (0.8 – 1.3mm² wire)	39-00-0212		
	GCN0771	Molex 'Mini-Fit Jr' Receptacles 18-24AWG (0.2 – 0.8mm² wire)	39-00-0039		



5.7.1 Battery charger connections

Warning

- The scooter manufacturer should comply with the requirements of ISO7176, Part 25 regarding batteries and chargers.
- The maximum charging current for the RHINO2 scooter control system is 8A RMS.
- The scooter manufacturer must specify an appropriate battery charger for the batteries used in the scooter.
- The scooter manufacturer must specify the maximum current of any battery chargers to be used with the controller and warn against using battery chargers of higher current ratings.
- The battery charger must have over-current protection in the form of a non-resettable fuse, which does not self-reset until the fault is cleared.
- It is the responsibility of the scooter manufacturer to manage the risks of battery over-charging and any related gas emissions.
- To protect the scooter wiring from over-currents while charging the batteries, chargers must have the ability to reduce their current output when electrically shorted.

There are two options for connecting a battery charger, either on-board (OBC) or off-board. For examples of wiring, see below. If an on-board charger is installed, it is recommended to plug it directly into the Charge/Program connector. For either charging solution, a battery charger with a maximum rating of 8 A RMS should be used. A suitable fuse (with a maximum rating of 8 A) must be installed in the Battery Positive wire to protect the scooter wiring.

For off-board chargers, an XLR-type socket can be connected either through the Charge/Program connector or through the tiller by using the Battery + and Battery - connections on the tiller connector.

💧 Warning

To prevent driving while charging, an appropriate inhibit pin (in either the Charge/Program or Tiller connector) must be connected so that a connection between Battery Negative (B-) and Inhibit is made when charging. For off-board chargers, this connection must be made as soon as the charger is connected to the scooter, independent of the charging state.

Warning

The battery charger socket is to be used exclusively for the intended purpose. Warranty will be voided if any unauthorised device is connected to this port.

Charger inhibit functionality is available on pin 14 and pin P/I of the *Multifunction Inputs*. Set the corresponding *Pin* [x] *Function* parameter to 'Charger Inhibit' and set its Active state to 'Low'.

🚺 Warning

It is the manufacturer's responsibility to ensure that any configurable interface pin that is to be used as a Battery Charger Inhibit pin is correctly configured and tested. The maximum voltage on the inhibit pin must not exceed 3 V if a battery voltage is to be detected when the battery charger is connected.





Alternatively, any of the Multifunction Input pins that support the **Slow** function may be used. In this case, set *Slows to* to 0 and set *Latches* to 'Yes'. If *Latches* is set to 'Yes', a power cycle is required to be able to drive again. If *Latches* is set to 'No', removing the battery charger will allow driving immediately.




Figure 17: Example of On-board charger wiring (shown using Charger/Programmer connector)




Figure 18: Example of Charger Socket wiring for an Off-board charger (shown using the tiller connector)

🚺 Note

The inhibit pin is a Multifunction input and can be used for an alternative function if a charger is not plugged into this pin.

💧 Warning


1. A suitable fuse, with a maximum rating of 8A, must be installed in the Battery Positive wire to protect the scooter's wiring. Connect the fuse as close as practicable to the controller connector to minimise the length of unprotected wiring.

2. The Battery Positive (B+) wires (pin 2 of the 4-pin connector, and pin 7 of the 14-way connector) should be coloured "RED" to conform to ISO 7176-14.

dynamic



5.7.2 Programmer Connections



Pin 14 of the Tiller Connector and pin 4 of the charging/programming connector can both be used for programming the RHINO2. Charging and programming cannot occur using the same inhibit pin at the same time.

Figure 19: Programmer connections

The RHINO2 programming adapter will plug directly into an off-board charger socket or into the 4-pin Molex Mini-Fit Junior connector with the use of the AMP programming adapter. If an on-board charger is installed, it will be necessary to disconnect it prior to programming through this connector.

The RHINO2 can be programmed with two different programming tools:

- The DX-HHP hand-held programmer (6.1 The Hand Held Programmer (HHP))
- The PC-based Wizard programmer (6.2 Dynamic Wizard)




Figure 20: Programming adaptors

Programming socket	Adaptors needed	
XLR Charger socket	DWIZ-ADAPT	
Charger/Programmer socket	DWIZ-ADAPT + DR-PRGLM02	



5.7.3 External Ambient Temperature Sensor Connection

RHINO2 provides support for an external temperature sensor that can be connected to the charging/programming connector between pin 3 (External Ambient Temperature Sensor Input) and pin 1 (Battery Negative) — see *Figure 21*.




Figure 21: Connecting an NTC thermistor ambient temperature sensor

Connect an NTC thermistor¹ with a R_{25} value of 33 k Ω and a $B_{25/85}$ value of 4090 K.

The temperature data is transmitted on two single-wire communication pins: pin 14 on the tiller head connector (TH14) and pin 4 on the battery charging and programming connector (BC4). For more information, see 7.7 Status Information – Single Wire Communications.

🚺 Note

‡1: The recommended thermistor is manufactured by Vishay, part number NTCLE100E3333JB0: Thermistor, NTC, 33 kohm, NTCLE Series, 4090 K, Through Hole, Radial Leaded.



5.8 Tiller Connector

The tiller connector provides all the connections necessary to power and control all the functions contained in the tiller head. This connector also supports the new Multifunction pins that can be configured for alternative functionality depending on application requirements.

Where the Multifunction pins are listed below, the bold text indicates the recommended default functions.

	Tiller Connections			
	Pin	Function	Wire Gauge	
	1	Throttle Wiper (TW)		
	2	Throttle Positive (T+)		
	3	Multifunction Output (Beeper)	0.5mm² (20AWG)	
	4	Multifunction Input (Profile 2)		
	5	Key Switch (KS)		
107	6	Multifunction Input (Slow)		
0 2	7	Battery Positive (B+)	1.0mm² (18AWG)	
	8	Throttle Negative (T-)		
	9	Speed Limit Pot (SLP)	0.5mm ²	
	10	Multifunction Output (Status Low)	(20AWG)	
	11	Multifunction Output (none)	(20/11/0)	
	12	Multifunction Input (Reverse Drive)		
	13	Battery Negative (B-)	1.0mm² (18AWG)	
	14	Multifunction Input (Charger Inhibit)	0.5mm² (20AWG)	
		Mating Connector Part Numbers		
	Dynamic Part #	Part Description	Supplier Part #	
	GCN0887	Molex 'Mini-Fit Jr' 14-socket housing	39-01-2145	
	GCN0776	Molex 'Mini-Fit Jr' Receptacles 16AWG (0.8 – 1.3mm² wire)	39-00-0212	
	GCN0771	Molex 'Mini-Fit Jr' Receptacles 18-24AWG (0.2 – 0.8mm² wire)	39-00-0039	



5.9 Throttle Configuration

Select the correct throttle type with the *Throttle Type* parameter:

Throttle Type		Description	
	 Neutral	Forward	Reverse
Wig-wag			
		vard and reverse di , set the <i>Swap Thre</i> s'.	
Uni-polar	 Neutral	Forward*	Forward*
	The scooter mov sides of the throt	es in the same dire ttle.	ection for both
		<u> </u>	
Single-ended	Neutral	Forwa	ard*
		lfway but at the sta osition in a single d ot.	
* The direction is dependent on the position of a Ferry	ul/David a suitab		

* The direction is dependent on the position of a Forward/Reverse switch. Connect this switch to one of the *Multifunction Inputs* (see 5.10.1 *Multifunction Inputs*), and set the corresponding *Pin* [x] *Function* parameter *to 'Reverse Drive'*.

To have more throttle control at low speeds, increase the *Throttle Response* parameter.

5.9.1 Protection against open-circuit, short-circuit and leakage current

The RHINO2 offers OEMs a number of options for complying with international safety standards, EN12184 and ISO7176, with respect to the integrity of the scooter's throttle signal.

When single fault conditions occur on a scooter, the standards require appropriate means should be adopted to eliminate or reduce, as far as possible, consequent risks.

For the throttle signal, this means an error due to an open-circuit, short-circuit or leakage current does not result in a hazardous situation. Specifically, if it is reasonably foreseeable that a short circuit, open circuit or leakage current could occur between conductors that carry analogue speed or direction signals, reference voltages, or supply voltages, then the identified possibilities must be tested and comply with the requirements.





The RHINO2 supports three throttle configurations:

Single throttle wiper (see 5.9.2 Single throttle wiper)

This option is compatible with previous Rhino products. However, if the installation foreseeably allows a leakage current between either a 24 V supply or reference line and the speed potentiometer wiper line, the system will fail the ISO7176 leakage current requirement.

Furthermore, if a speed limit potentiometer is placed in the speed potentiometer wiper line and the installation foreseeably allows a leakage current between any other tiller connection and the speed potentiometer wiper, the system may fail the ISO7176 leakage current requirement.

🚺 Note

Leakage currents could arise from rain water ingress, splashes of water off the road surface and condensation from humid situations.

Single throttle wiper with separate Neutral Detect switch input (see 5.9.3 *Neutral Detect*)

This option allows compliance for any foreseeable leakage current. The Neutral Detect switch indicates whether or not the throttle is in the physical neutral position. If the throttle signal does not match the Neutral Detect signal, the controller generates a fault and does not drive. The controller will also stop if this happens while driving.

A throttle with two linear wiper signals that are each other's opposite (see 5.9.4 Two throttle wipers - mirrored)

This option also allows compliance for any foreseeable leakage current. If the sum of both signals is not constant, the controller generates a fault and does not drive. The controller will also stop if this happens while driving.

5.9.2 Single throttle wiper

Connect the throttle potentiometer ends to T+ (Throttle Positive, pin 2) and T- (Throttle Negative, pin 8). Connect the throttle wiper to TW (Throttle Wiper, pin 1).




Figure 22: Single throttle wiper

To use this option, set the *Throttle Input* parameter to 'Single'.







Warning

If the throttle potentiometer is powered externally (not by T+ and T-), take extreme care to avoid ground shift. The RHINO2 can interpret a ground shift voltage as a drive signal and the scooter might start driving. If the throttle must be powered externally, either use additional hardware as described below or use the Neutral Detect feature (see 5.9.3 Neutral Detect) to detect a ground shift and prevent a potential runaway.

5.9.2.1 Additional hardware to comply with ISO7176-14 2022 Clause 7.2

To make a single throttle wiper configuration compliant with the standard, extra hardware is required to check if the throttle signal is valid.

One way to achieve this is to use a Neutral Detect (ND) switch that indicates if the throttle is in the physical neutral position.




Figure 23: Neutral detect switch

Normally, the hardware transfers the Throttle Wiper voltage to the TW output directly. However, if the ND switch indicates "Neutral", but the wiper signal is not at the neutral value, the hardware must set the TW output to a "fault" value (higher than *Maximum Throttle Voltage* or lower than *Minimum Throttle Voltage*). A "fault" value causes the controller to generate a fault and prevent driving. This makes sure that the scooter will never drive if the throttle wiring is faulty. See also *Throttle Testing*.

The RHINO2 offers a Neutral Detect input, to which a Neutral Detect switch can be connected directly without the use of additional hardware. See the next section for details.

5.9.3 Neutral Detect

The Neutral Detect function can be used in addition to a classic single wiper throttle to check whether or not the throttle is in the physical neutral position. If the throttle signal does not match the Neutral Detect signal, the controller generates a fault and does not drive.

This makes sure that the scooter will never drive if the throttle wiring is faulty.






Figure 24: Neutral detect function

* The Neutral Detect switch can be connected to B+ or B-, dependent on which option is selected in the Active field of the Pin [x] Function parameter. For more information, see 6.5.9.2 Active States and 8.1 Neutral Detect Active States.

To use this option, set the *Throttle Input* parameter to 'Single' and select the correct throttle type with the *Throttle Type* parameter. Connect the Neutral Detect switch to one of the *Multifunction Inputs*, and set the corresponding *Pin* [x] *Function* parameter to 'Neutral Detect'.

This option can be used with a speed limit pot in series as well as with a speed limit pot in parallel. See *5.9.6 Speed Limit Pot Connections* for details.

🚺 Note

The Neutral Detect function assumes that the throttle is in Neutral when the Neutral Detect input is in its active state.

For optimal mechanical accuracy, the neutral window of the Neutral Detect switch (the range of physical throttle deflection at which the switch indicates 'Neutral') should be as narrow as possible.

Make sure that the Throttle Dead-band parameter is set larger than the mechanical neutral window of the Neutral Detect switch, otherwise throttle faults will occur.

If the throttle potentiometer is powered externally (not by T+ and T-), take care to avoid ground shift. Ground shift will result in a throttle fault.

Make sure that any mechanical design has the same lifespan as the throttle potentiometer.

5.9.3.1 Installation of a Neutral Detect switch

To detect the physical neutral position of the throttle potentiometer, many options are possible. Two options are shown here.

Disk with micro-switch

Mount a disk to the potentiometer shaft. The disk must have a notch, in which the roller of a micro-switch will fall when the throttle is in the neutral position. Fasten the disk in the correct neutral position with a screw.









Figure 25: Disk with micro-switch

Make sure that the notch is not too deep and that is does not have sharp edges, otherwise the user may have difficulty to move the throttle out of the neutral position and the disk may slide out of position during use.

To maximise accuracy, increase the diameter of the disk.

Wear and tear will decrease accuracy. Make sure that the mechanical design conforms to the required lifespan of the throttle potentiometer.

Disk with optical switch





Many other options are possible, for example a disk with a slit that allows the light of a slotted optical switch to pass through in the neutral position.

This option provides the advantage that there are no mechanical forces on the disk. The 'feel' of the throttle to the user is the same, and the chance that the disk will slide out of position during use is decreased. Also, the optical switch will probably last longer than the roller of a micro-switch under normal use.

To maximise accuracy, decrease the width of the slit.



5.9.4 Two throttle wipers - mirrored

The RHINO2 supports the use of a 2 x 10 k Ω dual-gang throttle with two linear wiper signals that are each other's opposite. The throttle can either be a short travel or long travel variant.




Figure 27: Two throttle wipers - mirrored

To use this option, set the *Throttle Input* parameter to 'Dual' and select the correct throttle type with the *Throttle Type* parameter.

For a speed limit pot in series with the throttle wiper signals, insert a dual-gang speed limit pot in series, and connect both pots to the two throttle wiper signals.

For a speed limit pot in parallel with the throttle, it is not possible to use the dedicated Speed Limit Pot input (pin 9), because it is already used for the 2^{nd} wiper input. To use a speed limit pot in parallel with the throttle, connect the wiper to pin 4 (or pin 6, or pin 12) instead of pin 9, and set *Pin* [x] *Function* (or Pin 6 Function, or Pin 12 Function) to 'SRW'. See *5.9.6 Speed Limit Pot Connections* for more details.

🚺 Note

If the throttle potentiometer is powered externally (not by T+ and T-), take care to avoid ground shift. Ground shift will result in a throttle fault.

5.9.5 Throttle Calibration

For correct throttle operation, the electrical range of the throttle must be calibrated by correctly setting *Swap Throttle Direction*, *Throttle Neutral Offset*, *Minimum Throttle Voltage*, *Maximum Throttle Voltage*, *Throttle Dead-band* and *Throttle Full Scale Deflection*.

The DX-HHP hand-held programmer can calibrate the throttle automatically. It is recommended to use the automatic process, especially for the Dual Decode circuits.



See 6.1.1.3 Throttle calibration in the programming section for details.

기 Note

To calibrate the throttle with the Wizard PC-based programmer, use the HHP emulator mode: Tools -> Plug-ins -> HHP Emulation

5.9.6 Speed Limit Pot Connections

A speed limit pot may be connected either in series with the throttle wiper, or in parallel by using the dedicated input Pin 9 (Speed Limit Pot wiper), Pin 2 (Throttle Positive) and Pin 8 (Throttle Negative).

5.9.6.1 In series with the throttle wiper

🚺 Warning

If a series speed limit pot is used, the system will be unlikely to satisfy all of the requirements of ISO7176-14:2022 Clause 7.2 "Controller command signal processing failure".

If wiring in series, use a $25k\Omega$ potentiometer and set *Speed Limit Pot* to 'No', because the dedicated speed pot input (pin 9) is not used.


To increase the chance of detecting short-circuit faults in the throttle wiring, use an ISO test resistor between the throttle wiper and the speed pot. The ISO Test resistor must be placed as close to the speed pot as possible, preferably directly soldered with as short a lead as possible and mechanically protected.

As an alternative to wiring a single ISO Test Resistor in the Throttle Wiper, two ISO Test Resistors may be added to the Throttle Positive and Throttle Negative terminal of the throttle potentiometer. This will, unfortunately, increase the susceptibility of the throttle circuit to leakage. The 2 ISO resistors must be placed as close to the throttle pot as possible, preferably directly soldered with as short a lead as possible and mechanically protected.



If ISO test resistors are used then it may be necessary to adjust:

- 1. the Throttle Calibration settings (5.9.5 Throttle Calibration)
- 2. the Throttle Configuration parameters (6.5.2 Throttle Configuration).



ISO Test Resistor





5.9.6.2 In parallel with the throttle

For a speed pot in parallel, use a $100k\Omega$ potentiometer and set *Speed Limit Pot* to 'Yes'.

If the Speed Limit Pot is at its minimum position, the speed of the scooter at full throttle deflection is set by *Lowest (Minimum) Forward Speed* and *Lowest (Minimum) Reverse Speed.*

The Dual Decode variant already uses pin 9 for the second throttle wiper connection. To use a separate Speed Limit Pot in parallel to the throttle with this variant, use a 10k log potentiometer. Connect it between pin 4¹ and B-, and set *Pin [x] Function* to 'SRW' (Speed Reduction Wiper). If the Speed Limit Pot is at its minimum position, the speed of the scooter at full throttle deflection is set by the *Speed Reduction Wiper (SRW) parameters*. To avoid a throttle dead-band when the speed is reduced, use the 'Speed Scale' parameters and leave the 'Speed Limit' parameters at 100%.





5.9.7 Alternative Speed Reduction Options


In addition to the throttle and speed limit pot, the RHINO2 has other speed reduction options to allow for further flexibility in the way speed reduction is applied. For specific details about each of these options, please refer to the programming section:

Option	Description
Profile 2	When this function is active, the drive performance and characteristics as defined in Profile 2 will be used. The primary use of this function is to set a Reduce Speed mode. Available on Tiller Connector Pins 4, 6, 12, and 14 and Charger/Programmer Connector Pin 4.
SRW (Speed Reduction Wiper) and SRW (variable)	If <i>Pin</i> [<i>x</i>] <i>Function</i> , where 'X' is 4, 6 or 12, is set to 'SRW', or SRW (variable), it provides a variable speed reduction based on the resistance between pin x and B- : decreasing the resistance will decrease the speed of the scooter. Decreasing the resistance to zero will slow down the scooter to a speed set by the <i>Speed Reduction Wiper (SRW) parameters</i> .

¹ Alternatively, connect between pin 6 and B-, or between pin 12 and B-, and set the relative Pin [x] Function parameter to 'SRW'.









Slow/Stop This function has three states: Inactive, Slow and Stop. When Slow is active, the scooter will slow to a programmed speed (a percentage of the maximum speed). Has no effect on scooter acceleration. When Stop is active, the scooter will stop at the programmed	Option	Description
B- This function has three states: Inactive, Slow and Stop. When Slow is active, the scooter will slow to a programmed speed (a percentage of the maximum speed). Has no effect on scooter acceleration or deceleration.	Slow/Stop	Stop
Emergency Deceleration rate. Available on Tiller Connector Pins 4, 6, 12, and 14 and		This function has three states: Inactive, Slow and Stop. When Slow is active, the scooter will slow to a programmed speed limit (a percentage of the maximum speed). Has no effect on scooter acceleration or deceleration. When Stop is active, the scooter will stop at the programmed Emergency Deceleration rate.

5.9.8 Tiller Battery Supply

Pin 7 provides the Battery Positive (B+) supply to the tiller, while Pin 13 provides the Battery Negative (B-) return. These pins have current ratings of 9A and can be used for wiring an XLR socket for an off-board battery charger. An external fuse (maximum rating of 8A) should be installed into the Battery Positive circuit. Refer to section *5.7 Battery Charging and Programming Connections* for further details about battery charging.

The B+ and B- supplies must not be connected either directly or through switches to the same input connector.

💧 Warning


A suitable fuse (maximum rating of 8A) must be installed in the Battery Positive wire to protect the scooter wiring. Fuse to be connected as close as practicable to the controller connector, to minimise the length of unprotected wiring.

In connecting switches between an input pin and either Battery Positive or Battery Negative, the installer must ensure that there is no possibility of the switch(es) connecting Battery Positive to Battery Negative.



5.9.9 Key Switch Input

Pin 5 of the tiller connector provides the key switch power circuit. A high-quality key switch (> 50,000 operations) should be used. Up to two status LEDs (up to 10 mA each) may be wired in line with this output as an alternative to using one of the Status output pins.



If there is no status LED wired in series with the key switch, set *Key Switch Status LED* to 'No' to decrease the current drain by 10 mA when the RHINO2 is turned on.

🖊 Note

The voltage drop across the LED should be less than 5 V at 10 mA.


If more brightness is desired, two LEDs may be connected in series. The total voltage drop across the LEDs must not exceed 5 V.

LEDs with voltage ratings, for example 12 V or 24 V, have internally fitted resistors and must not be used.

5.9.10 Status Indicator Output

Pins 3, 10, and 11 on the tiller connector can be configured as dedicated status outputs. Pin 10 also has the ability to be active either high or low.

Pin 10 is rated for 50 mA sink and 10 mA source, whereas Pins 3 and 11 are capable of an output up to 500 mA. Select a resistor to limit LED current.






🖊 Note

The status indicator can be configured to display five different types of diagnostics flash code plus battery deep discharge warning.

5.9.11 Beeper Output

Pins 3 and 11 on the tiller connector can be configured as a beeper output. They are both capable of an output up to 500 mA.




🚺 Note

The following beeper functions can be enabled or disabled: beeping when entering sleep mode, beeping the fault codes, beeping when driving in reverse plus battery deep discharge warning.

5.9.12 Battery Gauge Output

The RHINO2 has incorporated a battery capacity algorithm and can output this to either a 5 V or 12 V voltmeter battery gauge display (shown below). Alternatively, a digital LED display is supported by using the "LED Battery Gauge" wiring shown on the right. The algorithm used is the same as the Dynamic Shark power chair controller and has built-in filters to adjust for voltage dips under load and floating voltages after periods of idling.

This function is available on Pin 10 of the tiller connector and is rated for 10 mA source.



🚺 Note

For a 5 V Voltmeter Battery Gauge, set Pin 10 Function to '5V Gauge'. For a 12 V Voltmeter Battery Gauge, set Pin 10 Function to '12V Gauge'. For an LED Battery Gauge, set Pin 10 Function to 'Other'.






5.9.13 Brake and Reversing Lights

Pin 3 and Pin 11 on the tiller connector can be configured as either a brake light or reversing light. Either light output may be connected to an LED array (500 mA) or relaydriven incandescent or halogen bulb.

If an LED array is used, it must be a 24 V array and have its own internal current limiting system. An LED array will also need to incorporate reverse polarity protection such as a series diode.

Note: An LED array may exhibit a faint glow if not engaged.

The brake light will operate whenever the controller decelerates. The reversing light will operate whenever the controller is driving in reverse.



🚺 Note

Pins 3 and 11 can be set to one of Beeper, Brake Light, Reversing Light or Status.



5.10 Multifunction Pins

The Multifunction Pins maximise flexibility in both scooter design and installation. Scooter variations typically implemented through wiring changes can now be implemented through programming.

The RHINO2 offers both Multifunction Input and Output pins.

5.10.1 Multifunction Inputs

The Multifunction Inputs are available on pin 4, 6, 12 and 14 of the Tiller Connector and on the Programming/Inhibit (P/I) pin of the programming connector These inputs are activated by external circuits. Each input pin can be set to operate a specific function (see table below).

Most functions are fully configurable as to the circuit state in which they are active (or operating), as well as the ability to become latched (where the controller must be turned off and then on again to cancel the function). In addition, the speed to which a Slow input decelerates is fully customizable.

	Pin 4	Pin 6	Pin 12	Pin 14	Pin P/I
Reverse Drive	•	٠	٠	٠	٠
Release Brake	•	•	•	•	•
Charger Inhibit				•	•
Profile 2	•	•	٠	٠	•
Slow	•	•	٠	٠	•
Slow/Stop	•	•	•	٠	٠
Slow/Stop Fwd	•	•	٠	٠	•
Slow/Stop Rev	•	•	٠	٠	•
SRW	•	•	٠		
SRW (variable)	•	٠	٠		
Neutral Detect	•	•	٠	٠	٠

The table below shows the supported functionality for each input pin. The specific functionality of each input will be explained in a further section.

For an extensive description of each function and the configuration options, see *Multi-function Inputs Configuration*.




Figure 28: Multifunction Input Pins

The configurable options for each input pin are:

Active — This defines the circuit state at which the function operates.
Slows to — If a Slow function is active, this is the speed the scooter will be limited to.
Latches — This defines whether the function is latching. If a function is latched, the active condition will have to be removed and the controller turned off and

then on again before the function will be turned off. The Latches parameter applies only to the functions that inhibit driving: Charger Inhibit and Stop. **Flashes** — During Drive Inhibit (when a Stop condition or a Charger Inhibit condition occurs) a flash code will be displayed.

Due to the nature of the different functions, some functions do not support the complete range of configuration. See the table below for further details.

	Active	Slows to	Latches	Flashes
SRW				
SRW (variable)				
Profile 2	•			
Charger Inhibit	•		•	•
Slow	•	•	•	●(0% only)
Reverse Drive	•			
Release Brake	•			
Slow/Stop Fwd	•	•	٠	•
Slow/Stop Rev	•	•	•	•
Slow/Stop	•	٠	٠	•
Neutral Detect	•			



5.10.2 Multifunction Outputs

The Multifunction Outputs will output signals dependent on the condition of the controller or batteries. As with the Multifunction Inputs, the Multifunction Output pins have been designed to offer maximum flexibility in the implementation of the scooter feature set and are programmable using the Wizard.

With the exception of the status output on Pin 10, these functions are not configurable as to their active state and do not have the ability to be latched. The specific functionality of each output is explained in the previous sections:

- 5.9.10 Status Indicator Output
- 5.9.11 Beeper Output
- 5.9.12 Battery Gauge Output
- 5.9.13 Brake and Reversing Lights

The table below shows the supported functionality for each input pin.

	Pin 3	Pin 10	Pin 11
Beeper	•		٠
Brake Light	•		•
Reversing Light	•		•
Status	•		•
Power Status	•		٠
Status High		•	
Status Low		•	
Fault High		•	
Fault Low		•	
5 V Battery Gauge		•	
12 V Battery Gauge		•	
Other (multi-LED battery gauge display)		•	

For more information, see 6.5.10 Multi-function Outputs Configuration.

If the Deep Discharge Beeper (beep on low battery) is enabled, all pins configured for 'Beeper', 'Status ', or 'Status High/Low' will issue this warning. The warning is a Flash Code 1¹.




Figure 29: Multifunction Output Pins



¹ Flash Code 1 appears for Flash Code Types: Scooter, R-Series, and Type 3. For Flash Code Type 'Shark', the Flash Code is 2; for Flash Code Type 4', the Flash Code is 1-4.



5.11 Controller Power Modes

When not powered down, the RHINO2 controller operates within one of three power modes:

- Normal Mode,
- Sleep Mode, or
- Low Power Mode¹

These different modes provide various levels of operation and power usage.

Figure 30 shows how the controller transitions from one mode to the next as a consequence of certain events, such as the user turning the key to the ON position (Key ON) or when the Sleep Timer expires — these modes and transitions are explained next.




Figure 30: Controller power modes

5.11.1 Powered Down

When powered down, the controller is effectively powered off: the scooter cannot be driven and there are no status updates from the single wire communication pins. To enter Normal Mode (powered up and driveable), the RHINO2 controller requires a Key ON event.

5.11.2 Normal Mode

In Normal Mode, the scooter is completely powered up and operational. Status information is transmitted on the single wire communication pins.

¹Low power mode is only available in firmware supporting DFVN 6. Program revisions and software versions are detailed in the table in section *6.2.1 Software version and module version*.





To exit Normal Mode manually, the user must switch the key to its off position (Key OFF), at which point the controller transitions to Low Power Mode (if enabled) or to Powered Down if Low Power Mode is turned off in the programming.

If the *Sleep Timer* has been enabled (*Sleep Timer* > 0), and the throttle has been in the Neutral position for *Sleep Timer* minutes, Normal Mode is exited automatically, dropping into Sleep Mode.

5.11.3 Sleep Mode

When in Sleep Mode, the controller is partially powered off to reduce energy consumption and to make sure that the scooter does not drive if the user accidentally deflects the throttle. The scooter does not respond to commands, but all inputs are powered and monitored, and status updates from the single wire communication pins continue to transmit. The status LED(s) flash once every 5 seconds to indicate to the user that the controller is in Sleep Mode.

From Sleep Mode, the controller can transition back to Normal Mode, or into Low Power Mode.

To transition back to Normal Mode, the user must 'Wake Up' the controller by either turning the key (OFF then ON), or deflecting the throttle — this is determined by the parameter *Wakeup Style*.

The controller automatically transitions to Low Power Mode from Sleep Mode on one of the following events:

- key OFF: the user turns the key to the OFF position
- 6 hours elapsed: the controller has been in Sleep Mode for 6 hours
- throttle fault: the controller has detected a throttle fault
- flat battery: the battery is flat
- battery charging: the battery is charging

5.11.4 Low Power Mode

When in Low Power Mode, the controller operates in a low power mode to reduce energy consumption. During Low Power Mode, the controller continues to monitor the system (motor, battery, faults etc.) and Status information is transmitted on the single wire communication pins, once every 12 hours.

The controller remains in Low Power Mode until one of the following events occur:

- Low Power Mode Duration has timed out
- The battery becomes flat
- Key ON

If *Low Power Mode Duration* times out, or the battery becomes flat, the controller transitions to Powered Down. *Low Power Mode Duration* can be set between 0 and 90 days.





If *Low Power Mode Duration* is set to zero, then the controller transitions straight to Powered Down on key off.

If the user turns the key to the ON position (Key ON), the controller transitions to Normal Mode.



5.12 Testing

To ensure that each scooter meets a minimum level of safety, the following procedure should be undertaken. This procedure should be carried out in a spacious environment and with due regard to any possible unexpected scooter movement in the event of faulty installation.

- 1. Raise the wheels off the ground using blocks under the scooter frame so that the wheels can turn freely.
- 2. Recheck all wiring, paying particular attention to polarities of batteries, motor and park brake.
- 3. Make the final connection to the Battery Positive (+) terminal, open the key switch and close the circuit breakers.
- 4. Turn the key switch to turn the RHINO2 on. Ensure it turns on correctly.
- 5. Turn the key switch again to turn the RHINO2 off. Ensure it turns off correctly. Turn the key switch again to turn the RHINO2 back on.
- 6. Ensure all installed hardware is functioning correctly by activating appropriate buttons/switches etc.
- 7. Move the throttle slightly out of neutral and listen for the "click" as the park brake disengages.
- 8. Move the throttle backwards and forwards and ensure that the wheels respond smoothly and in the correct direction.
- 9. Release the throttle to neutral and listen for the click of the park brake re-engaging.
- 10. Turn off the RHINO2 and remove the blocks from under the scooter.
- 11. Turn the RHINO2 back on and turn the speed dial (if installed) to the lowest speed setting.
- 12. Sit in the scooter and drive forward and reverse slowly, checking for precise and smooth control.
- 13. Repeat at higher speeds.
- 14. Drive the scooter on a 1:6 ramp and check for normal power, smoothness and parking.
- 15. Test all other hardware fitted.
- 16. Repeat testing until the scooter performs as expected.

6 Programming

6.1 The Hand Held Programmer (HHP)	57
6.1.1 Programming menu	
6.1.2 Diagnostics menu	61
6.1.3 Technician menu	62
6.2 Dynamic Wizard	64
6.2.1 Software version and module version	64
6.3 Parameter List	
6.4 Parameter Variations	
6.4.1 Variations by module	
6.4.2 Variations by Profile 1	70
6.4.3 Variations by Profile 2	
6.5 Parameter Descriptions	71
6.5.1 User Personalisation	72
6.5.2 Throttle Configuration	76
6.5.3 Drive Performance	83
6.5.4 OEM Drive Limits	
6.5.5 Motor Management	
6.5.6 Park Brake Management	
6.5.7 Battery Management	
6.5.8 System Options	
6.5.9 Multi-function Inputs Configuration	
6.5.10 Multi-function Outputs Configuration	118

💧 Warning

Performance adjustments must only be made by healthcare professionals, or by persons who completely understand the adjustment process and the capabilities of the operator.

Wrong settings, or programming in a location that is not safe, can cause injury to the operator or bystanders, or damage to the vehicle or surrounding property.

After you have configured the vehicle, check to make sure that the vehicle performs to the specifications entered in the programming procedure. If the vehicle does not perform to specifications, reprogram it. Repeat this procedure until the vehicle performs to specifications. If the wanted operation cannot be reached, contact your service agent.

Ensure that the deceleration parameters are always higher than the acceleration parameters for a safe response.

It is the responsibility of the health care professional to make sure that the user is capable of both cognitively understanding and physically operating the programmed features and functions.

With inappropriate programming settings, certain features and options may not be accessible or perform as expected.

²rogramming



The RHINO2 is programmed during manufacture with default settings. Modify these settings with a programmer to suit a specific scooter model or end user. The RHINO2 can be programmed with two different programming tools:

- The DX-HHP hand-held programmer (see 6.1 The Hand Held Programmer (HHP))
- The PC-based Wizard programmer (see 6.2 Dynamic Wizard)


Warning

No matter which programmer is used, after configuring the system, make sure:

- the programming has completed correctly and verify that the program has written as requested;
- vehicle safety is tested;
- the user is capable of understanding and driving the vehicle.

Two different programming sockets can be used to program the RHINO2:

- The standard 3-pin XLR-type Battery Charger socket (if available on the scooter)
- The Charger/Programmer socket on the RHINO2 itself.





Programming socket	Adaptors needed
XLR Charger socket	DWIZ-ADAPT
Charger/Programmer socket	DWIZ-ADAPT + DR-PRGLM02



6.1 The Hand Held Programmer (HHP)



The DX-HHP Hand Held Programmer (HHP) is a programming tool that gives access to drive parameters (such as speed and acceleration) and throttle calibration. A technician mode additionally gives access to system settings such as load compensation, and can read extensive system diagnostics such as motor voltage.

🖊 Note

The Wizard PC-based programmer has an HHP emulator mode: **Tools -> Plug-ins -> HHP Emulation**

Narning

The DX-HHP is for use only by scooter manufacturers and their authorised dealers. It is not for use by the scooter user. Dealers may only program parameters as instructed by the scooter manufacturer.

The DX-HHP Manual should be read and understood before attempting to use the HHP.

- Turn on the scooter before you connect the programmer to the RHINO2.
- All changes are saved immediately, it is not necessary to disconnect the HHP or to cycle the power to save changes. For this reason it is not possible to cancel a change, other than to set the parameters back to their original settings manually.




Figure 32: Programmer Main Menu Screen

The following sections describe the menus of the HHP and give a parameter listing if applicable.

- 6.1.1 Programming menu
- 6.1.2 Diagnostics menu
- 6.1.3 Technician menu

6.1.1 Programming menu

The programming menu gives access to

- The speed and acceleration settings of Drive Profile 1 and Drive Profile 2
- Other (non-profiled) settings such as left or right-handed throttle, sleep timer, beeper settings and the service scheduler
- Throttle calibration

dynamic







Figure 33: Programming menu

6.1.1.1 Profile 1/2

The RHINO2 has two Drive Profiles that are typically used as follows:

- Drive Profile 1 Normal Drive
- Drive Profile 2 A 'Slow Speed' mode for indoor use, that the user can select with a 'Slow' switch

Normally Drive Profile 1 is always selected. Drive Profile 2 is only used when *Pin* [x] *Function* is set to 'Profile 2' and the associated input pin is activated.





- 1. In the Main Menu screen, press PROG to enter the Programming Menu.
- 2. To select Drive Profile 1, press EDIT. To select Drive Profile 2, press NEXT and then press EDIT.
- 3. Press NEXT until the desired parameter is shown.
- 4. Press UP or DOWN to adjust the parameter to the desired value. Please note that each change is effective immediately, there is no option to cancel a change. To undo a change, manually set the parameter back to its original setting with UP or DOWN.
- 5. Press EXIT twice to return to the Main Menu.

For each drive profile, the following parameters can be adjusted:

Parameter
Maximum Forward Speed
Forward Acceleration
Forward Deceleration
Maximum Reverse Speed
Reverse Acceleration
Reverse Deceleration






Parameter

Lowest (Minimum) Forward Speed

Lowest (Minimum) Reverse Speed

6.1.1.2 Non-profiled

The parameters that are not in the Drive Profiles can be adjusted in the Non-Profiled menu.



- 1. In the Main Menu screen, press PROG to enter the Programming Menu.
- 2. To select Non-Profiled, press NEXT twice and then press EDIT.
- 3. Press NEXT until the desired parameter is shown.
- 4. Press UP or DOWN to adjust the parameter to the desired value. Please note that each change is effective immediately, there is no option to cancel a change. To undo a change, manually set the parameter back to its original setting with UP or DOWN.
- 5. Press EXIT twice to return to the Main Menu.

In the Non-Profiled Menu, the following parameters can be adjusted:

Parameter
Sleep Timer
Enable Beeper
Swap Throttle Direction
BatGauge Sensitivity
Service Scheduler
Flash Code Beeper
Sleep Beeper (Beep on Sleep)
Reversing Beeper
Motion Beeper

6.1.1.3 Throttle calibration

The throttle calibration automatically detects and sets the correct values for the *Swap Throttle Direction, Throttle Neutral Offset, Minimum Throttle Voltage* and *Maximum Throttle Voltage* parameters.

🚺 Note


The HHP can only calibrate the throttle if there are no faults active, including throttle faults and OONAPU (Out Of Neutral At Power Up) faults that are caused by a faulty calibration.



To calibrate a throttle when a throttle fault is active, set Throttle Testing to 'No' with the Wizard, calibrate the unit, and then set Throttle Testing to 'Yes' again. For OONAPU (Out Of Neutral At Power Up) faults, set Throttle OONAPU Testing to 'None' during calibration, and return it to its original setting afterwards.

The throttle calibration does not set the Throttle Dead-band and Throttle Full Scale Deflection parameters. These parameters must still be set manually.

If a Speed Limiting Potentiometer (SLP) has been fitted, then the SLP must be set for full speed when performing throttle calibration. Throttle calibration may fail if the SLP is set to a lower speed.





- 1. In the Main Menu screen, press PROG to enter the Programming Menu.
- 2. To select Throttle Calibration, press NEXT three times and then press YES.
- 3. Wait until 'Deflect Forward' is shown on the HHP.
- Deflect the throttle FULLY forward. This procedure measures the end position of the throttle, so it is important that you deflect the throttle as far as it can go mechanically.
- 5. Keep the throttle deflected forward until 'Return to Neutral' is shown on the HHP.

기 Note

If the 'Return to Neutral' screen does not appear, the calibration procedure was started while a fault was active. Press EXIT to cancel the calibration procedure, eliminate the fault and start the calibration procedure again.

6. Release the throttle to its neutral position.




Figure 37: Throttle calibration - deflect reverse

- 7. Wait until 'Deflect Reverse' is shown on the HHP.
- 8. Deflect the throttle FULLY reverse.
- 9. Keep the throttle deflected until 'Return to Neutral' is shown on the HHP.
- 10. Release the throttle to its neutral position.
- 11. If the throttle calibration is complete, the HHP will show 'Successful'.
- 12. Press EXIT to go to the Main Menu, or press NEXT to go to the Programming Menu.





Failed calibration

If the controller cannot measure the throttle correctly, or when there is no expected throttle activity for 20 seconds during any of the calibration screens, the HHP will show 'Failed'.





Figure 38: Failed calibration

If this happens, press RETRY to repeat the calibration from the start, and go back to step 4.

6.1.2 Diagnostics menu

If a fault exists, the HHP can show extended diagnostics information.



- 1. In the Main Menu screen, press DIAG to enter the Diagnostics Menu.
- 2. If a fault exists, the System Faults screen gives a description of the current fault.
- 3. Press NEXT for the fault log. The fault log shows the last four faults that have occurred. The faults are shown in 4-digit numbers. See 7.4 HHP Fault Codes with sub codes for more information. Press MORE to see earlier faults; up to 16 faults can be displayed.
- 4. Press NEXT to access the usage counters. Press MORE to see the counters one by one.

Usage Counter	Description
Time on (h)*	The total time that the unit has been powered up
Power-ups*	The total number of successful power-ups
Drive Time (h)*	The total time during which the throttle has been deflected
Drive Count*	The total number of times that the throttle has been deflected and returned to neutral

*The HHP reads the currently active value of these parameters. A diagnostics report made with the Wizard shows the values that have been stored the last time that the unit was turned off. For this reason, the usage counters shown in the Wizard are usually slightly lower than the values shown in the HHP.



5. Press NEXT to see the unit identification. Press MORE to see the parameters one by one: Model, ESN and Software version.

Identification	Description
Model	The model number of the unit (DS90, DS120 etc.)
ESN	The serial number of the unit
Version	The software version number of the unit

6. Press EXIT to return to the Main Menu.

6.1.3 Technician menu

Some parameters are protected; they can only be accessed in Technician Mode. To enter technician mode on the HHP:

- 1. Turn the RHINO2 ON
- 2. Connect the HHP to the RHINO2
- 3. Press TECH



Figure 40: Press TECH

4. Enter the technician password




Figure 41: Enter technician password

5. Press OK

* *	TECHN	ICIAN	**
Ent	er Pa	ssnum	ber
	00	0	\frown
D1	D 2	D 3	OK

Figure 42: Press OK

You are now in Technician mode.

** T	ECHN	ICIAN	**
Load	Comp	ensati	on
	100	mOhm	
EXIT N	EXT	DOWN	UP

Figure 43: Technician mode



In the Technician Menu, the following parameters can be adjusted:

Parameter	Section
Load Compensation	6.5.5.5
Soft Start Period	6.5.3.9
Soft Finish	6.5.3.10

Also, the following parameters can be read in real-time:

Parameter	Typical
Battery Voltage	23 - 28 V
Motor Voltage	0 - Battery Voltage
Motor Current	0 - unit rating
Case Temperature	10 - 80°C
FET Temperature	10 - 120°C
Throttle Voltage	0 - 5 V



6.2 Dynamic Wizard

The PC-based Dynamic Wizard provides access to all the parameters that are allowed to be edited or seen based on the dongle level. In addition, the Wizard can also generate comprehensive diagnostics reports. For more information, see the Wizard user manual.

6.2.1 Software version and module version

Some parameters are only available to specific module versions or program revisions. Each software version will support only one program revision.

You can check the software version of your controller with:

- the main screen of the HHP (see 6.1 The Hand Held Programmer (HHP)).
- the Wizard: Read Diagnostics. The software version is in the System Information section.

You can check the module version of your program with:

• the Wizard Tools -> Change Module Version.

The relation between program revision and software version is shown below:

Program revision	Software version
DFVN 0	Not available
DFVN 1	0.08 - 1.01
DFVN 2	1.02 - 1.09
DFVN 3	1.10 - 1.17
DFVN 4	1.18 - 1.19
DFVN 5	1.20 - 1.28
DFVN 6	1.29 – and higher



6.3 Parameter List

Key: \checkmark Editable at this level (\checkmark * = HHP Technician Mode)

Note

Some of the parameters in this list have a limited settable resolution; if a parameter value is set by an amount that is smaller than the parameter's step-size, the parameter's value will be rounded to a value as close as possible to the set value.

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
User Personalisation (6	.5.1 User Personalisati	on)				
Sleep Timer	0 - 30min	30min	\checkmark			\checkmark
Wakeup Style	Key + Throttle Key Only	Key Only				\checkmark
Swap Throttle Direction	No / Yes	No	\checkmark	\checkmark	\checkmark	\checkmark
Enable Beeper	No / Yes	Yes	\checkmark	\checkmark	\checkmark	\checkmark
Flash Code Beeper	No / Yes	No	\checkmark	\checkmark	\checkmark	\checkmark
Sleep Beeper	No / Yes	Yes	\checkmark	\checkmark	\checkmark	\checkmark
Motion Beeper	None Reverse Forward/Reverse	Reverse	\checkmark	\checkmark	\checkmark	\checkmark
Reversing Beeper	No/Yes	No	\checkmark			
Beeper On Time	100 – 1500ms	300ms		\checkmark	\checkmark	\checkmark
Beeper Off Time	0 – 1500ms	700ms		\checkmark	\checkmark	\checkmark
Deep Discharge Beeper	No / Yes	Yes	Yes		\checkmark	\checkmark
Sleep on Fault	No / Yes	Yes		\checkmark	\checkmark	\checkmark
Power Off after Sleep	No / Yes	Yes		\checkmark	\checkmark	\checkmark
Throttle Configuration (6.5.2 Throttle Configur	ation)				
Throttle Type	Wig-wag Single-ended Uni-polar	Wig-wag			\checkmark	\checkmark
Throttle Input	Single Dual	Single			\checkmark	\checkmark
Throttle Neutral Offset	-0.6 +0.62 V	0 V			\checkmark	\checkmark
Throttle Full Scale Deflection	20 - 100 %	75 %			\checkmark	\checkmark
Throttle Response	0 - 100 %	80 %		\checkmark	\checkmark	\checkmark
Throttle Dead-band	0 - 100 %	25 %			\checkmark	\checkmark
Throttle Testing	No / Yes	Yes				\checkmark
Maximum Throttle Voltage	0 - 5 V	4.90 V				\checkmark
Minimum Throttle Voltage	0 - 5 V	0.10 V				\checkmark
Throttle OONAPU	None Non-Latching	Latching				\checkmark



Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Testing	Latching	Deladit			510	Auv
Throttle Fault Non Latching	No / Yes	No				\checkmark
Speed Limit Pot	No / Yes	No				\checkmark
Slam Brake Enable	No / Yes	No				\checkmark
Slam Brake Threshold	6 - 94%	13%				\checkmark
Enable SRW Open Circuit Testing	No / Yes	No		\checkmark	\checkmark	\checkmark
Drive Performance (6.5.	.3 Drive Performance)					
Maximum Forward Speed	20 - 100 %	See 6.4 Parameter Variations	\checkmark	\checkmark	\checkmark	\checkmark
Forward Acceleration	0 - 100 %	See 6.4 Parameter Variations	\checkmark	\checkmark	\checkmark	\checkmark
Forward Deceleration	0 - 100 %	See 6.4 Parameter Variations	\checkmark	\checkmark	\checkmark	\checkmark
Maximum Reverse Speed	20 - 100 %	See 6.4 Parameter Variations	\checkmark	\checkmark	\checkmark	\checkmark
Reverse Acceleration	0 - 100 %	See 6.4 Parameter Variations	\checkmark	\checkmark	\checkmark	\checkmark
Reverse Deceleration	0 - 100 %	50 % (Profile1) 50 % (Profile 2) √		\checkmark	\checkmark	\checkmark
Lowest (Minimum) Forward Speed	0 - 100 %	20 % (Profile1) 20 % (Profile 2)	\checkmark	\checkmark	\checkmark	\checkmark
Lowest (Minimum) Reverse Speed	0 - 60 %	20 % (Profile1) 20 % (Profile 2)	\checkmark	\checkmark	\checkmark	\checkmark
Soft Start Period	0 - 2550ms	800ms	\checkmark		\checkmark	\checkmark
Soft Finish	0 - 100 %	35 %	\checkmark		\checkmark	\checkmark
Emergency Deceleration	0 - 100 %	80 %				\checkmark
Slam Braking	0 - 100 %	50 %				\checkmark
Push Speed	5 - 70 %	15 %				\checkmark
Roll-away Speed	5 - 70 %	15 %				\checkmark
SRW Forward Speed Limit	0 - 100 %	50 %			\checkmark	\checkmark
SRW Forward Speed Scale	0 - 100 %	50 %			\checkmark	\checkmark
SRW Reverse Speed Limit	0 - 100 %	50 %			\checkmark	\checkmark
SRW Reverse Speed Scale	0 - 100 %	50 %			\checkmark	\checkmark
SRW Scaling Resistor (Ohm)	400 - 25500Ω	3200Ω			\checkmark	\checkmark
SW Current Limit Decel	6 - 94%	75% (DS90)				\checkmark



Parameter Scalar	Possible Values	Default	HHP Lite		Std	Adv
HW Current Limit Decel Scalar	6 - 94%	56% (DS90)				\checkmark
OEM Drive Limits (6.5.4	OEM Drive Limits)					
Maximum Forward Speed Limit	0 - 100 %	100 %			\checkmark	\checkmark
Maximum Reverse Speed Limit	0 - 100 %	100 %			\checkmark	\checkmark
Minimum Forward Speed Limit	0 - 100 %	0 %			\checkmark	\checkmark
Minimum Reverse Speed Limit	0 - 100 %	0 %			\checkmark	\checkmark
Acceleration Limit Deceleration Limit	0 - 100 % 0 - 100 %	100 % 100 %			\checkmark	\checkmark
Motor Management (6.5	5.5 Motor Management)				
Motor Protection	No / Yes	Yes				\checkmark
Motor Continuous Current	See 4.1 Electrical Specifications	See 6.4 Parameter Variations				\checkmark
Motor Heating Time	1 - 255s	20s				\checkmark
Motor Cooling Time	4 - 1020s	32s				\checkmark
Thermal Rollback Start	0 – 70°C	65°C				\checkmark
Thermal Rollback End	70 – 80°C	75°C				\checkmark
Motor Reverse	No / Yes	No			\checkmark	\checkmark
Load Compensation	0 - 225mΩ	See 6.4 Parameter Variations	\checkmark		\checkmark	\checkmark
Maximum Load Compensation	0 - 225mΩ	225mΩ				\checkmark
Load Compensation Damping	0 - 60%	25%				\checkmark
Remembered Load Compensation	15 - 60%	50%				\checkmark
Current Limit	See 4.1 Electrical Specifications	See 6.4 Parameter Variations			\checkmark	\checkmark
Boost Current	See 4.1 Electrical Specifications	See 6.4 Parameter Variations			\checkmark	\checkmark
Boost Time	All: 10s Except: DS180: 5s	See 6.4 Parameter Variations			\checkmark	\checkmark
Stall Timeout	0-51s	15s				\checkmark
Motor Testing	None Open (Pre-Drive Only) Short	Short				\checkmark





Parameter	Possible Values	Default	HHP	Lite	Std	Adv
	All (Open Pre-Drive					
	Only) Open (Pre-Drive and					
	Drive)					
	All (Open Pre-Drive and Drive)					
Maximum Motor Voltage	0 - 64 V	26.2 V				\checkmark
Max Motor V Scalar	60-100%	70%				\checkmark
Max Motor V Demand Limit	50 - 100%	100%				\checkmark
Max Motor V Ramp Down Time	0.5 – 2.5s	2.0s				\checkmark
Max Motor V Recovery Time	0.5 – 2.5s	2.0s				\checkmark
Park Brake Managemer	nt (6.5.6 Park Brake Mo	anagement)				
Park Brake Testing	None Pre-drive Driving	Pre-drive				\checkmark
Park Brake Neutral Delay	0 - 25500ms	200ms			\checkmark	\checkmark
Park Brake Release Delay	0 - 25500ms	100ms			\checkmark	\checkmark
Battery Management (6	5.5.7 Battery Managem	ent)				
Overvoltage Warning	24 – 34.2 V	30.2				\checkmark
Overvoltage Rollback	30.2 – 36.2 V	34.2 V				\checkmark
Undervoltage Rollback Start	18 - 32.2 V	21 V				\checkmark
Undervoltage Rollback End	17 - 21 V	18 V				\checkmark
Battery Gauge Minimum	16 - 24 V	22 V				\checkmark
Battery Gauge Maximum	19 - 27 V	24.4 V				\checkmark
Battery Gauge High Warning	24 - 32 V	29 V			\checkmark	\checkmark
Battery Gauge Low Warning	18 - 26 V	23.4 V			\checkmark	\checkmark
Battery Gauge Dead- band	0 - 6 V	3.5 V				\checkmark
BatGauge Sensitivity	5 -170	40	\checkmark			\checkmark
Battery Cut-Off Voltage	16 - 24 V	21 V		\checkmark	\checkmark	\checkmark



Parameter	Possible Values	Default	HHP	Lite	Std	Adv
System Options (6.5.8 S		Doradit	1		014	
Service Scheduler	No / Yes	No			\checkmark	\checkmark
Service Period	0 - 5100h	5000h	\checkmark	\checkmark	\checkmark	\checkmark
Actuator Time-Out	NOT USED					
Enable 1Hz Data	No/Yes	No				\checkmark
Low Power Mode Duration ¹	0 – 90 days	0				\checkmark
Multi-function Inputs C	onfiguration (6.5.9 Mu	lti-function Inputs Cor	nfiguratic	on)		
	None					
Pin 4 Function Reverse Drive Release Brake	Profile 2			\checkmark	\checkmark	
Pin 6 Function	Charger Inhibit Profile2 Slow Slow/Stop	Slow/Stop			\checkmark	\checkmark
Pin 12 Function	Slow/Stop FWD Slow/Stop REV SRW	Reverse Drive			\checkmark	\checkmark
Pin 14 Function	SRW (variable) Neutral Detect Actuator Wig-Wag	Charger Inhibit			\checkmark	\checkmark
Prog/Inh Pin Function	(NOT USED) Actuator Control (NOT USED)	Charger Inhibit			\checkmark	\checkmark
Multi-function Outputs	Configuration (6.5.10 I	Aulti-function Outputs	Configur	ration)		
Flash Code Type	Scooter Shark Type 3 Type 4	Scooter			\checkmark	\checkmark
Pin 3 Function	None Brake Light Reverse Light	Beeper			\checkmark	\checkmark
Pin 11 Function	Beeper Status Power Status	Power Status			\checkmark	\checkmark
Pin 10 Function	None Status High Status Low Fault High				\checkmark	\checkmark
Key Switch Status LED	No / Yes	Yes				\checkmark

¹Low power mode is only available in firmware supporting DFVN 6. Program revisions and software versions are detailed in the table in section 6.2.1 Software version and module version.



6.4 Parameter Variations

The default values of some parameters differ from module to module (DS90, DS160C etc.) and from profile to profile. Because of these variations, a separate table, below, is required to display them.

6.4.1 Variations by module

	Module					
Parameter	DS90	DS120	DS160	DS180	Units	
Motor Continuous Current	36	48	64	64	А	
Load Compensation	60	40	28	28	mΩ	
Current Limit	90	120	160	180	А	
Boost Current	0	20	20	20	А	
Boost Time	0	3	5	5	S	

6.4.2 Variations by Profile 1

	Module					
Parameter	DS90	DS120	DS160	DS180	Units	
Maximum Forward Speed	100	100	100	100	%	
Forward Acceleration	35	30	20	20	%	
Forward Deceleration	60	60	55	55	%	
Maximum Reverse Speed	40	40	35	35	%	
Reverse Acceleration	30	30	15	15	%	

6.4.3 Variations by Profile 2

	Module				
Parameter	DS90	DS120	DS160	DS180	Units
Maximum Forward Speed	60	60	50	50	%
Forward Acceleration	35	30	20	20	%
Forward Deceleration	60	60	55	55	%
Maximum Reverse Speed	30	30	25	25	%
Reverse Acceleration	30	30	15	15	%



6.5 Parameter Descriptions

Warning

- Any given starting point settings in this section must be used as a guideline only.
- It is the responsibility of the scooter manufacturer to make sure that the program is safe and suitable for a particular scooter configuration.
- It is the responsibility of the dealer or therapist to check and make sure that the settings of a scooter for a particular user are safe and appropriate for that user.



6.5.1 User Personalisation

6.5.1.1 Sleep Timer

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Sleep Timer	0 - 30min	30min	\checkmark			\checkmark

The RHINO2 automatically "goes to sleep" if the throttle has been in the Neutral position for Sleep Timer minutes. When the RHINO2 sleeps, it is partially turned off to reduce energy consumption and to make sure that the scooter does not move if the user accidentally moves the throttle. In Sleep Mode, the scooter does not respond to commands.

To wake up the RHINO2, take the action that is selected with *Wakeup Style*.

If *Wakeup Style* is set to 'Key + Throttle', the Status Light gives a short flash every 5 seconds during sleep mode.

To disable Sleep Mode, set Sleep Timer to zero.

6.5.1.2 Wakeup Style

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Wakeup Style	Key + Throttle Key Only	Key Only				\checkmark

Defines how the controller will wake up from sleep.

Key Only — Only the key switch wakes up the controller (by turning the key off and then on again).

Key + Throttle — The key switch as well as any throttle movement wakes up the controller.

🚺 Note

If the value of Sleep Timer is zero, the value of Wakeup Style is ignored.

6.5.1.3 Swap Throttle Direction

Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Swap Throttle Direction	No / Yes	No	\checkmark	\checkmark	\checkmark	\checkmark

This parameter is normally only used when *Throttle Type* is set to 'Wig-wag'. For singleended and uni-polar throttles, use a Forward/Reverse switch instead (see *Pin* [x] Function). If this parameter is used in conjunction with a Forward/Reverse switch, then it will invert the polarity of the Forward/ Reverse switch.

Yes — The polarity of the throttle is reversed. Moving the throttle in the direction that normally causes forward movement now results in reverse movement while the reverse buzzer beeps. Typically used for left-handed operation.

No — The polarity of the throttle is normal. Typically used for right-handed operation.

🚺 Note

The Motor Reverse parameter also reverses the direction of the scooter, but it does not swap the behaviour of the reversing buzzer or the speed limit parameters. If Motor Reverse is set to 'Yes', the reversing buzzer will





beep when the scooter moves forward, and the forward speed will be limited by the Maximum Reverse Speed parameter. For this reason, do not use Motor Reverse for left-handed operation. Use Swap Throttle Direction instead.

6.5.1.4 Enable Beeper

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Enable Beeper	No / Yes	Yes	\checkmark	\checkmark	\checkmark	\checkmark

Yes — The beeper will beep according to the settings of *Flash Code Beeper*, *Sleep Beeper*, *Motion Beeper* and *Deep Discharge Beeper*.

No – All beeper functions are disabled.

6.5.1.5 Flash Code Beeper

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Flash Code Beeper	No / Yes	No	\checkmark	\checkmark	\checkmark	\checkmark

This parameter is only used when *Enable Beeper* has the value 'Yes'.

Yes - If a flash code is shown on the Status LED, the buzzer beeps the same number of beeps as the flash code number.

No — The buzzer does not beep during a fault.

6.5.1.6 Sleep Beeper

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Sleep Beeper	No / Yes	Yes	\checkmark	\checkmark	\checkmark	\checkmark

This parameter is only used when Enable Beeper has the value 'Yes'.

Yes — When the controller goes to sleep, the buzzer beeps for one second.

No – When the controller goes to sleep, the buzzer does not beep.

6.5.1.7 Motion Beeper

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Motion Beeper	Wizard None Reverse Forward/Reverse	Wizard Reverse	\checkmark	\checkmark	\checkmark	\checkmark
	HHP Yes No	HHP No				

This parameter is only used when Enable Beeper has the value 'Yes'.

None — The scooter does not beep when it is moving Reverse — The scooter beeps only when it is moving in the reverse direction

Forward/Reverse — The scooter beeps when it is moving in any direction



6.5.1.8 Reversing Beeper

0 1						
Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Reversing Beeper	Yes No	No	\checkmark			

Note that the *Reversing Beeper* parameter does not exist in the Wizard since the *Motion Beeper* parameter can be used to switch on the beeper for reversing.

When using the HHP to program, use both the *Motion Beeper* and the *Reversing Beeper* parameters, as set out in the table below.


Motion Beeper	Reversing Beeper	Wizard Equivalent
No	Yes	Reverse
Yes	Yes	None
No	No	None
Yes	No	Forward/Reverse

6.5.1.9 Beeper Timing

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Beeper On Time	100 – 1500ms	300ms		\checkmark	\checkmark	\checkmark
Beeper Off Time	0 – 1500ms	700ms		\checkmark	\checkmark	\checkmark

These parameters are only used when *Enable Beeper* has the value 'Yes'.

Beeper On Time and Beeper Off Time together set the beeper interval time. During Beeper On Time the beeper emits a sound. During Beeper Off Time the beeper is silent.



6.5.1.10 Deep Discharge Beeper

Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Deep Discharge Beeper	No / Yes	Yes		\checkmark	\checkmark	\checkmark

This parameter is only used when *Enable Beeper* has the value 'Yes'.

Enables beeping if the battery is drained to the cut-off level set by Battery Cut-Off Voltage.

🚺 Note

This parameter must be set to comply with the ISO 7176-14 (2008) "over-discharge protection" requirement.



6.5.1.11 Sleep on Fault

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Sleep on Fault	No / Yes	Yes		\checkmark	\checkmark	\checkmark

Enables going to sleep if a fault condition is active. If set to no, the unit will not go to sleep, but will signal the fault indefinitely.

🚺 Note

If the value of Sleep Timer is zero, the value of Sleep on Fault is ignored.

During a throttle fault or OONAPU (Out Of Neutral At Power Up) fault the controller will never go to sleep, even if this parameter is set to 'Yes'.

6.5.1.12 Power Off after Sleep

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Power Off after Sleep	No / Yes	Yes		\checkmark	\checkmark	\checkmark

Enables powering the unit off automatically after sleeping for approximately 6 hours to save battery power.



6.5.2 Throttle Configuration

6.5.2.1 Throttle Type						
Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Throttle Type	Wig-wag Single-ended Uni-polar	Wig-wag			\checkmark	\checkmark

Wig-wag — The throttle controls speed and direction, no Forward/Reverse switch is required. The neutral position is the centre position of the pot. If the throttle is moved out of the centre position in one direction, the scooter drives forward. If the throttle is moved out of the centre in the opposite direction, the scooter drives in reverse.

Single-Ended — The throttle controls speed only. The neutral position is at the start of the pot. The direction of the scooter is selected with a Forward/Reverse switch.

Uni-polar —The throttle controls speed only. The neutral position is the centre position of the pot. If the throttle is moved out of the centre position in either direction, the scooter starts to drive in the direction that has been selected with the Forward/Reverse switch. This allows left-handed and right-handed operation of the same wig-wag without reprogramming the scooter.

The standard direction of the scooter can be swapped with *Swap Throttle Direction*. If a Forward/Reverse switch is needed, connect it to one of the *Multifunction Inputs*, and set the corresponding *Pin* [x] *Function* parameter to 'Reverse Drive'. For schematics, see 5.9 *Throttle Configuration*.

6.5.2.2 Throttle Input

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Throttle Input	Single Dual	Single			\checkmark	\checkmark

Single — Use for a standard throttle with a single wiper.

Dual — Use for a throttle with two linear wiper signals that are each other's opposite.

In the extreme positions, one wiper is set to the minimum value and the other wiper is set to the maximum value. In the halfway position, both wipers have the same value. The RHINO2 checks both signals for consistency: the sum of both signals must be a constant value, equal to the maximum value. If the sum of the signals is more than 3% lower or higher than the expected maximum value, the scooter stops and a throttle fault is shown on the Status light.

6.5.2.3 Throttle Neutral Offset

Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Throttle Neutral Offset	-0.6 to +0.62 V	0 V			\checkmark	\checkmark


Set this to account for any slight mechanical offset between the throttle neutral position and the centre position of the throttle wiper. The offset is an absolute voltage above or below neutral.







Use the HHP to calibrate the unit instead of setting a value manually, see *Throttle calibration* for details.



The default neutral value is dependent on the value of the *Throttle Type* parameter:

- Wig-wag and Uni-polar both have the default neutral value at 2.5 V.
- Single-ended has its default neutral value at 0 V + *Maximum Throttle Voltage*. In this case, all negative values of *Throttle Neutral Offset* are ignored and all positive values are multiplied by 2, which means that a Wizard setting of 0.5 V will produce an actual neutral offset of 1.0 V.

6.5.2.4 Throttle Full Scale Deflection

Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Throttle Full Scale Deflection	20 - 100 %	75 %			\checkmark	\checkmark

Set the percentage of total throttle movement that will result in full speed.

The scale of this parameter ranges between *Throttle Neutral Offset* (0%) and *Maximum Throttle Voltage / Minimum Throttle Voltage* (100%).

For example, if a mechanical stop restricts the throttle from moving more than 60% of its full electrical travel, set this parameter to 50% to make sure that the scooter can still reach maximum speed.




Figure 45: Example throttle full scale deflection



6.5.2.5 Throttle Response

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Throttle Response	0 - 100 %	80 %		\checkmark	\checkmark	\checkmark

Defines the scooter response to movement of the throttle.

0% — The response to the throttle is linear. If the throttle is held halfway, the scooter will drive at half its programmed speed.

100% — The response to the throttle is curved. If the throttle is held halfway, the scooter will drive at around 25% of its programmed speed. This gives the user finer control at low speed. The curve does not change the maximum speed, so the scooter will still drive at full maximum speed when the throttle is fully deflected.





Figure 46: Throttle response

6.5.2.6 Throttle Dead-band

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Throttle Dead-band	0 - 100 %	25 %			\checkmark	\checkmark

Also commonly referred to as 'Neutral Window', *Throttle Dead-band* sets how far the throttle must be moved out of neutral before the controller will begin to drive. The percentage range is dependent on the value of the *Throttle Type* parameter.

The speed demand from the throttle remains at zero while the throttle deflection from neutral is less than half of the programmed Throttle Dead-band. As the throttle is deflected beyond this point and up to the programmed Dead-band, the throttle demand increases smoothly from zero so that there is no abrupt change in demand as the throttle moves out of neutral. For a throttle deflection greater than the programmed Dead-band the speed demand is proportional to the throttle deflection.







6.5.2.7 Throttle Testing

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Throttle Testing	No / Yes	Yes				\checkmark

Yes — The RHINO2 tests if the voltage at the throttle wiper has a value that is between *Minimum Throttle Voltage* and *Maximum Throttle Voltage*. This is especially useful when ISO resistors are used to detect faults in the throttle wiring. If the voltage falls more than 10% outside the limits, a throttle fault is generated, the scooter will not drive and a 'Throttle Fault' flash code is shown on the Status light. For the correct flash code, see the description of the *Flash Code Type* parameter.

No — The RHINO2 does not generate throttle faults. This setting is not recommended because faults in the throttle wiring may not be detected. Use for throttle calibration and throttle testing only.

For schematics and the use of ISO resistors, see 5.9 *Throttle Configuration*.

6.5.2.8 Maximum Throttle Voltage

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Maximum Throttle Voltage	0 - 5 V	4.90 V				\checkmark
Minimum Throttle Voltage	0 - 5 V	0.10 V				\checkmark

Maximum Throttle Voltage sets the maximum expected throttle voltage. Set this parameter to the voltage that is present at the RHINO2 throttle wiper input (pin 1 of the tiller head connector) when the wiper of the throttle is moved fully to the Throttle Positive position (pin 2).

Minimum Throttle Voltage sets the minimum expected throttle voltage. Set this parameter to the voltage that is present at the RHINO2 throttle wiper input when the wiper of the throttle is moved fully to the Throttle Negative position (pin 8).

The minimum and maximum throttle voltage parameters determine the operation of the *Throttle Full Scale Deflection* and *Throttle Dead-band* parameters. See the description of those parameters for details.

If *Throttle Testing* is set to 'Yes', and the voltage at the throttle wiper input is more than 10% higher than *Maximum Throttle Voltage* or 10% lower than *Minimum Throttle Voltage*, the controller generates a throttle fault to indicate that an error may have occurred with the throttle or its wiring.






Figure 47: Wig-wag setup with Neutral Offset = -0.5 V, Dead-band = 25% and Full Scale Deflection = 80%

6.5.2.9 Throttle OONAPU Testing

Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Throttle OONAPU Testing	None Non-Latching Latching	Latching				\checkmark

An Out Of Neutral At Power Up (OONAPU) fault occurs if the throttle is not in the neutral position when the scooter is switched on. This makes sure that the scooter does not suddenly start to drive.

If an OONAPU fault exists, the Status LED shows a flash code* and the scooter does not drive. Return the throttle to the neutral position. The fault goes away and the scooter drives normally.

Latching — If the throttle is not returned to the neutral position within 5 seconds, the OONAPU fault becomes a latching fault. To clear the fault, switch the scooter off and then on again.

Non-Latching — The OONAPU fault never becomes a latching fault. To clear the fault, simply return the throttle to the neutral position. Use this setting for users who have difficulty to return the throttle to the neutral position within 5 seconds.

None — An OONAPU fault will never occur. Do not use except for testing purposes or throttle calibration.

*The flash code that is shown depends on the *Flash Code Type* parameter.

🚺 Note

If an OONAPU fault does not go away after the scooter has been turned off and on, the throttle may be faulty or incorrectly calibrated. See section 5.9.5 Throttle Calibration for more information.

🚺 Warning

If Throttle OONAPU Testing is set to 'None', the scooter is unsafe for normal operation. The scooter can start to drive unexpectedly if it is turned on while the throttle is stuck or held in a deflected position.





6.5.2.10 Throttle Fault Non Latching

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Throttle Fault Non Latching	No/Yes	No				\checkmark

Set to 'Yes' for non-latching throttle faults, set to 'No' for latching throttle faults.

💧 Warning

Only set this parameter to 'Yes' for testing purposes. If throttle faults are non-latching, the scooter immediately starts to drive at the speed that the throttle is held at when a throttle fault disappears. This can easily happen with a throttle that is not calibrated correctly.

6.5.2.11 Speed Limit Pot

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Speed Limit Pot	No / Yes	No				\checkmark

Yes — The dedicated Speed Limit Pot input (pin 9) is used to limit the speed of the scooter. Use this setting with a 100 k Ω speed pot that is connected IN PARALLEL with the throttle, between 'Throttle Positive' (pin 2) and 'Throttle Negative' (pin 8), and that has its wiper connected to pin 9 (speed limit pot input).

No – The Speed Limit Pot input (pin 9) is ignored. Use this setting with a 25 k Ω speed pot that is connected IN SERIES with the throttle, and that is connected to pin 1 (throttle wiper input).

For schematics and the use of ISO resistors, see 5.9.6 Speed Limit Pot Connections .


🚺 Note

If Speed Limit Pot is set to 'Yes' when no speed pot is connected to pin 9 (when the speed pot is wired in series with the throttle instead of in parallel), the RHINO2 will read pin 9 as if the speed pot is at its lowest setting, and will always limit the speed of the scooter to the lowest forward and reverse speeds.

If the voltage at pin 9 is the same as Throttle Positive (T+), the maximum speed of the scooter at 100% throttle deflection is not limited and is as set by the *Maximum Forward Speed* and *Maximum Reverse Speed* parameters.

If the voltage at pin 9 is the same as Throttle Negative (T-), the maximum speed of the scooter at 100% throttle deflection is scaled down to *Lowest (Minimum) Forward Speed* and *Lowest (Minimum) Reverse Speed*.





The throttle output is scaled down, not limited, so the throttle does not have a dead-band when the speed pot is at a low setting.

6.5.2.12 Slam Brake

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Slam Brake Enable	No / Yes	No				\checkmark
Slam Brake Threshold	6 - 94%	13%				\checkmark

Slam Brake Enable turns on slam braking in the forward and reverse directions.

Slam braking is applied when the throttle is significantly moved in the opposite direction to the direction that the scooter is currently moving in (the minimum amount of throttle movement in the opposite direction is set with *Slam Brake Threshold*).

During a slam brake, the scooter decelerates with the rate that is set with the *Slam Braking* parameter. Be careful when enabling slam braking because this setting may not be suitable for all scooter types.

6.5.2.13 Enable SRW Open Circuit Testing

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Enable SRW Open Circuit Testing	No / Yes	No		\checkmark	\checkmark	\checkmark

When *Enable SRW Open Circuit Testing* is enabled, a fault will be generated when the SRW resistor is disconnected. This is useful for detecting open circuit faults (e.g. broken wire) in the SRW circuit.





6.5.3 Drive Performance

The RHINO2 has two Drive Profiles, which are typically used for

- Drive Profile 1 Normal Drive
- Drive Profile 2 A 'Slow Speed' mode for indoor use that the user can select with a 'Slow' switch. The indoor profile can limit the speed as well as the acceleration.

Normally, Drive Profile 1 is always selected. Drive Profile 2 is only used when Pin[x] *Function* is set to 'Profile 2' and the associated input pin is activated.

Note that the following parameters, such as the maximum speed, acceleration and deceleration rates, can be set specifically to facilitate learner drivers.

6.5.3.1 Maximum Forward Speed

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Maximum Forward Speed	20 - 100 %	See Parameter Variations	\checkmark	\checkmark	\checkmark	\checkmark

Sets the maximum speed in the forward direction when the highest speed has been selected with the speed limit pot (see *5.9.6 Speed Limit Pot Connections*) and the throttle is fully deflected forward. Dealers can adjust this parameter to the preference of an individual user or to the terrain that a specific scooter will be used in.

🚺 Note

This parameter cannot be set higher than the value of the Maximum Forward Speed Limit parameter that has been set by the scooter manufacturer.

6.5.3.2 Forward Acceleration

Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Forward Acceleration	0 - 100 %	See Parameter Variations	\checkmark	\checkmark	\checkmark	\checkmark

Sets how quickly the forward speed increases after the throttle has been deflected forward.

0 % — From standstill, the scooter reaches full forward speed in 10 s
100 % — From standstill, the scooter reaches full forward speed in 0.4 s




Figure 49: Acceleration characteristics



Low acceleration values give a softer performance and a less sensitive throttle response. High acceleration values give a more aggressive performance and a fast throttle response.

🚺 Note

This parameter cannot be set higher than the value of the Acceleration Limit parameter that has been set by the scooter manufacturer.

6.5.3.3 Forward Deceleration

Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Forward Deceleration	0 - 100 %	See Parameter Variations	\checkmark	\checkmark	\checkmark	\checkmark

Sets how quickly the scooter slows down after the throttle has been released from forward deflection to neutral.

0 % — From full forward speed, the scooter stops in 10s
100 % — From full forward speed, the scooter stops in 0.4s




Figure 50: Deceleration characteristics

Low deceleration values produce a gentle stop but increase the braking distance. High deceleration values produce a more aggressive stop but can be uncomfortable. Adjust this parameter to the preference of the user.

🚺 Note

This parameter cannot be set higher than the value of the Deceleration Limit parameter that has been set by the scooter manufacturer.

Warning

Setting Forward Deceleration too low or too high can result in a scooter that is unsafe. Test thoroughly after programming to make sure that the scooter complies with local regulatory requirements for maximum allowable braking distance.



6.5.3.4 Maximum Reverse Speed

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Maximum Reverse Speed	20 - 100 %	See Parameter Variations	\checkmark	\checkmark	\checkmark	\checkmark

Sets the maximum speed in the reverse direction when the highest speed has been selected with the speed limit pot (see *5.9.6 Speed Limit Pot Connections*) and the throttle is fully deflected reverse. Dealers can adjust this parameter to the preference of an individual user or to the terrain that a specific scooter will be used in.

Note

This parameter cannot be set higher than the value of the Maximum Reverse Speed Limit parameter that has been set by the scooter manufacturer.

6.5.3.5 Reverse Acceleration

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Reverse Acceleration	0 - 100 %	See Parameter Variations	\checkmark	\checkmark	\checkmark	\checkmark

Sets how quickly the reverse speed increases after the throttle has been deflected reverse.

0 % – From standstill, the scooter reaches full reverse speed in 10 s

 $100 \ \%$ – From standstill, the scooter reaches full reverse speed in 0.4 s

Low acceleration values give a softer performance and a less sensitive throttle response. High acceleration values give a more aggressive performance and a fast throttle response.

🚺 Note

This parameter cannot be set higher than the value of the Acceleration Limit parameter that has been set by the scooter manufacturer.

6.5.3.6 Reverse Deceleration

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Reverse Deceleration	0 - 100 %	50 % (Profile1) 50 % (Profile 2)	\checkmark	\checkmark	\checkmark	\checkmark

Sets how quickly the scooter slows down after:

• the throttle has been released to neutral while driving reverse

• the key switch is removed while driving in reverse

0 % – From full reverse speed, the scooter stops in 10 s

100 % – From full reverse speed, the scooter stops in 0.4s

Low deceleration values produce a gentle stop, but increase the braking distance. High deceleration values produce a more aggressive stop, but can be uncomfortable. Adjust this parameter to the preference of the user.

🚺 Note

This parameter cannot be set higher than the value of the Deceleration Limit parameter that has been set by the scooter manufacturer.





Warning

Setting Reverse Deceleration too low or too high can result in a scooter that is unsafe. Test thoroughly after programming to make sure that the scooter complies with local regulatory requirements for maximum allowable braking distance.

6.5.3.7 Lowest (Minimum) Forward Speed

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Lowest (Minimum) Forward Speed	0 - 100 %	20% (Profile1) 20% (Profile 2)	\checkmark	\checkmark	\checkmark	\checkmark

This parameter is only used when Speed Limit Pot is set to 'Yes'.

Lowest (Minimum) Forward Speed sets the maximum speed in the forward direction when the lowest speed has been selected with the speed limit pot (see *5.9.6 Speed Limit Pot Connections*) and the throttle is fully deflected forward. Dealers can adjust this parameter to the preference of an individual user or to the terrain that a specific scooter will be used in.

🚺 Note

This parameter is used with a speed limit pot that is connected IN PARALLEL with the throttle, between 'Throttle Positive' (pin 2) and 'Throttle Negative' (pin 8), and that has its wiper connected to pin 9 (speed limit pot input). If the scooter has a speed limit pot that is connected IN SERIES with the throttle wiper, Lowest (Minimum) Forward Speed is not used and Speed Limit Pot must be set to 'No'.

This parameter cannot be set lower than the value of the Minimum Forward Speed Limit parameter that has been set by the scooter manufacturer.

6.5.3.8 Lowest (Minimum) Reverse Speed

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Lowest (Minimum) Reverse Speed	0 - 60 %	20 % (Profile1) 20 % (Profile 2)	\checkmark	\checkmark	\checkmark	\checkmark

This parameter is only used when *Speed Limit Pot* is set to 'Yes'.

It sets the maximum speed in the reverse direction when the lowest speed has been selected with the speed limit pot (see *5.9.6 Speed Limit Pot Connections*) and the throttle is fully deflected reverse. Dealers can adjust this parameter to the preference of an individual user or to the terrain that a specific scooter will be used in.

🖊 Note

This parameter cannot be set lower than the value of the Minimum Reverse Speed Limit parameter that has been set by the scooter manufacturer.




6.5.3.9 Soft Start Period

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Soft Start Period	0 - 2550ms	800ms	\checkmark		\checkmark	\checkmark

Whenever there is a change in speed demand, the soft start function temporarily reduces the acceleration / deceleration rate during the time that is set with *Soft Start Period*. This makes the acceleration / deceleration smoother, especially with high acceleration / deceleration rates or high load compensation settings.

Higher values give a softer start, while lower values give a more direct and harsh start.

To disable soft start completely, set *Soft Start Period* to zero.



Warning

Soft Start Period and Soft Finish values have the potential to impact the Emergency Deceleration rate. Manufacturers should consider the impact of these values when setting the Emergency Deceleration rate to ensure that required stopping distances can be achieved. It is recommended to set Soft Start Period and Soft Finish values before finalising the Emergency Deceleration value.


6.5.3.10 Soft Finish

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Soft Finish	0 - 100 %	35 %	\checkmark		\checkmark	\checkmark

When the scooter almost reaches its desired speed during acceleration or deceleration, the acceleration/deceleration rate is slowly decreased to zero. This prevents a sudden change in acceleration once the desired speed is reached.

Use the Soft Finish parameter to adjust the point where the soft transition starts. **0** % — Direct and harsh transition (no soft finish at all) **100** % — Very smooth transition

For most applications, the default value of 35 % works fine.





🚺 Warning

Soft Start Period and Soft Finish values have the potential to impact the Emergency Deceleration rate. Manufacturers should consider the impact of these values when setting the Emergency Deceleration rate to ensure that required stopping distances can be achieved. It is recommended to set Soft Start Period and Soft Finish values before finalising the Emergency Deceleration value.



6.5.3.11 Emergency Deceleration

Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Emergency Deceleration	0 - 100 %	80 %				\checkmark

Emergency Deceleration sets how quickly the scooter comes to a halt when travelling forward and:

- a Stop input is active, or
- a fault that requires an emergency stop occurs, or
- the key switch is removed while driving forward.

Note that *Emergency Deceleration* applies only to the forward direction; when decelerating in reverse, normal deceleration applies. Compare this with *Slam Braking*, which is applied in both directions, forward and reverse.

If the normal deceleration rate is higher than *Emergency Deceleration*, the normal deceleration value is used.

🚺 Warning

If this parameter is set too high, the user can fall out of the scooter during an emergency stop.

💧 Warning

Soft Start Period and Soft Finish values have the potential to impact the Emergency Deceleration rate. Manufacturers should consider the impact of these values when setting the Emergency Deceleration rate to ensure that required stopping distances can be achieved. It is recommended to set Soft Start Period and Soft Finish values before finalising the Emergency Deceleration value.

6.5.3.12 Slam Braking

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Slam Braking	0 - 100 %	50 %				\checkmark

Slam Braking sets how quickly the scooter comes to a halt when the throttle is moved significantly in the opposite direction to the direction that the scooter is currently moving in.

Slam Braking is enabled with *Slam Brake Enable* and its threshold, which is the minimum amount of throttle movement in the opposite direction before slam braking is engaged, is set with *Slam Brake Threshold*.

Note that if the normal deceleration rate is higher than *Slam Braking*, then the normal deceleration value is used instead of this setting.

🚺 Warning

If this parameter is set too high, the user can fall out of the scooter during a slam braking operation.

6.5.3.13 Push Speed

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Push Speed	5 - 70 %	15 %				\checkmark

This feature will limit the scooter to a safe speed when:





- 1. the controller is powered up, and
- 2. the park brake has been released electrically (this would normally be the case if the scooter is being pushed).

If the scooter is being pushed (by an external force) at a higher speed than *Push Speed*, the controller will limit the speed to *Push Speed*.

🚺 Note

To release the park brake electrically, set one of the Multifunction input pin parameters (see 6.5.9 Multifunction Inputs Configuration) to 'Release Brake'. Do not operate the 'Release Brake' function while on a slope.

🚺 Warning

To meet ISO requirements, the scooter must not be able to drive when the park brake is released manually.

Do not operate the park brake release while on a slope or when an occupant is on the scooter.

6.5.3.14 Roll-away Speed

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Roll-away Speed	5 - 70 %	15 %				\checkmark

This feature will limit the scooter to a safe speed if rolling away on a slope when:

- 1. the controller is powered down, and
- 2. the park brake has been released manually.

If the scooter moves at a higher speed than *Roll-away Speed*, the controller will turn on by itself and limit the scooter to a safe speed.

When the scooter has come to a stop, the controller can be turned on with the key switch and normal driving is possible.

🚺 Warning

Make sure the controller selected for each scooter has the capacity to reduce the speed of the scooter to a safe level under roll-away conditions. Setting a lower Roll-away Speed value will also prevent the scooter from gaining too much momentum when a roll-away occurs.

Warning

If this parameter is set too high, especially with heavier scooters, there is a risk of injury, through collision or crushing, when the scooter rolls down a slope.

7 Note

If the batteries are not connected, the controller uses the power that is generated by the motors during a rollaway to power itself on. In this case the controller will also limit the speed to a safe level.

🚺 Warning

1) After the scooter has stopped successfully, apply the park brake before turning on the scooter. During the 2second boot process the scooter is not controlled. In these 2 seconds, the scooter will start to roll again before it will come to an abrupt halt when the RHINO2 has completed the boot process.



2) If the batteries are not connected and the scooter is rolling away at some speed, the anti-rollaway feature may cause sudden braking so that it can reduce the speed of the scooter quickly; this may be upsetting and / or dangerous for the occupant.

0.3.3.13 Speed Reduction wiper (Sitve) parameters					
Parameter	Possible Values	Default	ННР	Lite	Std	Adv
SRW Forward Speed Limit	0 - 100 %	50 %			\checkmark	\checkmark
SRW Reverse Speed Limit	0 - 100 %	50 %			\checkmark	\checkmark
SRW Forward Speed Scale	0 - 100 %	50 %			\checkmark	\checkmark
SRW Reverse Speed Scale	0 - 100 %	50 %			\checkmark	\checkmark

6.5.3.15 Speed Reduction Wiper (SRW) parameters

These parameters are only used when *Pin* [x] *Function*, where 'x' is 4, 6 or 12, is set to 'SRW' or 'SRW (variable)'.

When *Pin* [x] *Function*, where 'x' is 4, 6 or 12, is set to 'SRW', or 'SRW (variable)' the RHINO2 reduces the speed proportionally to the resistance between pin x (4, 6 or 12) of the tiller head connector and Battery Negative (B-).

If *Pin* [x] *Function* is set to 'SRW', and the resistance is $10k\Omega$ or more, the speed is not reduced. If the resistance is zero, the speed is reduced to the value of any of the four SRW Speed parameters.

If *Pin* [x] *Function* is set to 'SRW (variable)' and the resistance is the value of *SRW Scaling Resistor (Ohm)* or more, the speed is not reduced. If the resistance is zero, the speed is reduced to the value of any of the four SRW Speed parameters.

For more information on Speed Reduction Wiper connections, see section 5.9.7 Alternative Speed Reduction Options.




Figure 53: Speed Reduction Wiper (SRW) parameters

The speed can be reduced in 2 different ways:


Limit — Limits the speed of the scooter itself. This means that the throttle can still ask for 100% speed, but when the scooter reaches the SRW Speed Limit value, the actual speed





will not increase any further. This creates a dead-band in throttle operation. However, below the speed limit the behaviour of the throttle does not change.

Scale — Scales the throttle output. This means that if SRW Speed Scale is set to 50%, the throttle will only ask for 50% speed at full deflection. This does not create a throttle deadband. However, it changes the behaviour of the throttle over the full range of deflection.



All four parameters reduce the speed simultaneously and independently of each other. If any of the parameters is set to 100%, it disables the reduction effect of that specific parameter.

6.5.3.16 SRW Scaling Resistor (Ohm)

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
SRW Scaling Resistor (Ohm)	400 - 25500Ω	3200Ω			\checkmark	\checkmark

Sets the maximum resistor value to be used in the SRW circuit when Pin [x] Function, where 'x' is 4, 6 or 12, is set to SRW (variable). Its range is 400 to 25500 Ω in steps of 100 Ω . The value set here corresponds to the input resistance that results in no reduction in speed. Note that this value must be set at least 5% lower than the actual maximum resistor value connected to the pin to allow for component tolerance, otherwise, maximum speed might not be achieved.

This parameter is only available for editing if Pin [x] Function, where 'x' is 4, 6 or 12, is set to SRW (variable).

6.5.3.17 SW Current Limit Decel Scalar

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
SW Current Limit Decel Scalar	6 - 94%	75% (DS90)				\checkmark

This parameter is applied if the software current limit is exceeded due to regenerative currents. When applied, it will reduce the deceleration rate of the scooter in an attempt to slow down the current increase. This parameter should be set as high as possible to minimise the impact on stopping distance.



6.5.3.18 HW Current Limit Decel Scalar

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
HW Current Limit Decel Scalar	6 - 94%	56% (DS90)				\checkmark

This parameter is applied if the hardware current limit is exceeded due to regenerative currents. If the *SW Current Limit Decel Scalar* cannot reduce the current enough, and the current increases further, then this parameter will come into effect, and thereby reducing the deceleration rate of the scooter further. This parameter should be set below the *SW Current Limit Decel Scalar*, but still as high as possible to minimise the impact on stopping distance.

Current Limit Deceleration Scalars Explained

Regenerative currents occur when the scooter decelerates, and if uncontrolled, they can easily exceed two or three times the maximum current of the controller. If regenerative currents are too high for too long, the controller will shut down the motor and apply the park brake (i.e. slam stop) to prevent damage to the motor and the controller. In this instance, the controller will show flash code 4 and the Wizard will report OVER_CURRENT when it applies slam stop. The best way to avoid excessive regenerative currents is to reduce the deceleration rates, in particular Emergency Deceleration, to the lowest acceptable values.

To prevent the controller from performing a slam stop, deceleration scalars are applied before the regenerative current becomes too high. The *SW Current Limit Decel Scalar* is applied first when the current exceeds the maximum programmed motor current limit. The effect of this is a reduction of the deceleration rate that will, in turn, reduce the increase of the current. If the current continues to increase further (around 30A), the *HW Current Limit Decel Scalar* is applied. This will reduce the deceleration rate even further. Note that the value of *HW Current Limit Decel Scalar* must be set lower than *SW Current Limit Decel Scalar*.

If these scalars are set as low as possible, the lifetime of the controller and the motor is extended and the long-time performance is not affected (no FET degrading). However, these scalars will affect stopping distance: smaller scalar values will increase the stopping distance. As guidance and a starting point, set the scalars as follows:

- for small scooters (maximum current 90A):
 - SW Current Limit Decel Scalar: 75%
 - HW Current Limit Decel Scalar: 50%
- for medium sized scooters (120A):
 - SW Current Limit Decel Scalar: 69%
 - HW Current Limit Decel Scalar: 44%
- for large scooters (160A):
 - SW Current Limit Decel Scalar: 56%
 - HW Current Limit Decel Scalar: 31%



If further tuning is required, set *SW Current Limit Decel Scalar* to the recommended value and *HW Current Limit Decel Scalar* to a value lower than the recommended value.

Warning

The following procedure is potentially dangerous because the scooter and controller will be operated at their extremes and this can result in a slam stop of the scooter.

Drive down the steepest specified slope at maximum specified loading (additional weight can be added to the scooter) at maximum speed and then release the throttle. The scooter should now decelerate and come to a stop at the programmed deceleration rate. If the controller applies slam stop, both parameters must be lowered immediately. Repeat the test, but instead of releasing the throttle, turn off the key. This invokes emergency deceleration. If the controller applies slam stop, both parameters must again be lowered. When the controller does not apply slam stop any more, the stopping distance on a flat surface must be verified.

While doing this, one or both parameters can be lowered or increased slightly to find the required regulatory stopping distance on a flat surface and the smoothest deceleration. Don't forget to repeat the test on the slope to verify that slam stop is still not invoked with the new settings.



6.5.4 OEM Drive Limits

The OEM Drive Limits allow the OEM to set the maximum value that dealers can set several drive performance parameters to. This allows OEMs to limit certain parameters for specific scooter models. Dealers will not be able to set the value of these parameters higher or lower than the limits given below.

6.5.4.1 Maximum Forward Speed Limit

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Maximum Forward Speed Limit	0 - 100 %	100 %			\checkmark	\checkmark
			_			

Sets the maximum value that can be set by a dealer for the *Maximum Forward Speed* parameter. Set to 100 % for no effect.

6.5.4.2 Maximum Reverse Speed Limit

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Maximum Reverse Speed Limit	0-100%	100 %			\checkmark	\checkmark

Sets the maximum value that can be set by a dealer for the *Maximum Reverse Speed* parameter. Set to 100 % for no effect.

6.5.4.3 Minimum Forward Speed Limit

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Minimum Forward Speed Limit	0 - 100 %	0 %			\checkmark	\checkmark

Sets the minimum value that can be set by a dealer for the *Lowest (Minimum) Forward Speed* parameter. Set to 0 % for no effect.

6.5.4.4 Minimum Reverse Speed Limit

		Default		1 310	Adv
Minimum Reverse Speed Limit	0 - 100 %	0 %		\checkmark	\checkmark
Minimum Reverse Speed Limit	0 - 100 %	0 %		√	

Sets the minimum value that can be set by a dealer for the *Lowest (Minimum) Reverse Speed* parameter. Set to 0 % for no effect.

6.5.4.5 Acceleration Limit

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Acceleration Limit	0 - 100 %	100 %			\checkmark	\checkmark

Sets the maximum value that can be set by a dealer for the *Forward Acceleration* and *Reverse Acceleration* parameters. Set to 100 % for no effect.

6.5.4.6 Deceleration Limit

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Deceleration Limit	0 - 100 %	100 %			\checkmark	\checkmark

Sets the maximum value that can be set by a dealer for the *Forward Deceleration* and *Reverse Deceleration* parameters. Set to 100 % for no effect.



6.5.5 Motor Management

6.5.5.1 Motor Protection

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Motor Protection	No / Yes	Yes				\checkmark

Motor Protection is a function that calculates the approximate temperature of the motor by measuring the motor current over time. If the calculated motor temperature becomes too high, the current output of the RHINO2 is reduced to protect the motor from burning out.

🚺 Note

This function assists in motor protection. However, it cannot completely prevent the motor from burning out. The motor may last longer, but specific conditions can still burn out a motor, even with Motor Protection activated.

The motor protection function operates in parallel with other current control functions and so the actual current limit will be determined by whichever process requests the lowest operating current.

🚺 Warning

When a scooter is driven uphill the controller will indicate a thermal fault if either the controller or the motor becomes very hot. In this situation the controller will reduce the available motor current to protect the controller and motor. It is possible with this reduced performance, that the controller is unable to provide sufficient power to the motor to hold the scooter on the slope and so as a safety precaution, the controller may force the scooter to a stop with the park brake applied when the user is attempting to continue driving.

If the scooter operator observes this thermal fault indication (same indication as Stall timeout or Overcurrent fault) the recommended response is to immediately stop driving by releasing the throttle to neutral, then to wait for at least 30 seconds before attempting to continue driving.

Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Motor Continuous Current	90A (DS90) 120A (DS120) 160A (DS160)	See Parameter Variations				\checkmark
Motor Heating Time	1 - 255s	20s				\checkmark
Motor Cooling Time	4 - 1020s	32s				\checkmark

6.5.5.2 Motor Protection Parameters

These parameters are only used if *Motor Protection* is set to 'Yes'.

Adapt these parameters to match the motor that is fitted on the scooter. See the motor specifications given by the motor manufacturer for the correct values.

Motor Continuous Current is the current at which the motor can run continuously without becoming too hot.

Motor Heating Time is the time that the motor can run at the programmed *Current Limit* before it becomes too hot. If the motor current has been close to *Current Limit* for *Motor Heating Time* seconds, the current is limited to *Motor Continuous Current* so the motor can cool down.





Before the current can reach the *Current Limit* value again, the motor current must stay below the value of *Motor Continuous Current* for *Motor Cooling Time* seconds.

🚺 Note

The time before the motor protection current limit is activated depends on the actual motor current. Motor Heating Time is the time that the motor can take the full Current Limit current before it becomes too hot. If the actual motor current is above Motor Continuous Current but much lower than Current Limit , the time before the motor protection limit is activated is longer.

6.5.5.3 Thermal Rollback Start / End

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Thermal Rollback Start	0-70°C	65°C				\checkmark
Thermal Rollback End	70 – 80°C	75°C				\checkmark

Thermal rollback provides protection for the controller against overheating. The values of these two parameters set the range for when the thermal rollback starts (*Thermal Rollback Start*), and ends (*Thermal Rollback End*).

When the controller temperature exceeds *Thermal Rollback Start* and is less than the upper temperature limit *Thermal Rollback End*, the controller rolls back the demand, load compensation and current limit in order to control the temperature rise to protect the controller against overheating. As the temperature falls back within this range, the control allows the demand, load compensation and current limit to recover.

6.5.5.4 Motor Reverse

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Motor Reverse	No / Yes	No			\checkmark	\checkmark

Yes — The polarity of the motor pins on the RHINO2 is reversed and the motor turns in the opposite direction.

No – The polarity of the motor pins is as described in section 5.5 Motor Connections.

🚺 Note

Do not use Motor Reverse to setup the scooter for left-handed use — set the Swap Throttle Direction parameter to 'Yes' instead. Motor Reverse only swaps the motor polarity, not other forward/reverse features such as the Forward/Reverse speed setting and the reversing beeper. Using Motor Reverse to setup the scooter for lefthanded use will result in the reversing beeper beeping while the scooter drives forward.





6.5.5.5 Load Compensation

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Load Compensation	0 - 225 mΩ	See Parameter Variations	\checkmark		\checkmark	\checkmark

Load Compensation automatically compensates for changes in motor speed when the scooter drives over loads such as sidewalks, curbs or slopes.

🚺 Note

The Load Compensation parameter affects the performance of all other speed and acceleration parameters, and it is important to set this parameter correctly **before you program these parameters**. If the Load Compensation parameter is changed after the scooter has been set up, the complete speed/acceleration programming and testing procedure must be repeated.

Set *Load Compensation* to the resistance of the motor that is installed on the scooter.


		Motor Resistance	
	Too low	Correct	Too high
Scooter behaviour	 Drives like it is going through thick mud Slows down when it goes up a sidewalk edge or up a ramp Slows down with heavier users Rolls back significantly after stopping on a slope 	 Drives smoothly Keeps the speed reasonably constant. Only slightly slows down on a slope Does not roll back after stopping on a slope 	 Drives very rough Hard to control, vibrates or surges May creep forward after stopping on a slope Motor becomes hotter than normal very easily, decreased motor life
	L.J.		LJ DI

If the scooter gives poor performance on carpet or at low speeds, the most probable cause is a Load Compensation value that is set too low.

Determining the correct motor resistance by looking at the scooter behaviour

Tools needed

- 1. A scooter with a RHINO2 controller fitted
- 2. A Hand Held Programmer (HHP) or a laptop with the Wizard Programmer
- 3. A slope that you can drive up to





Procedure

- Set Load Compensation to 20.
- Drive the scooter onto a slope and increase the Load Compensation value until the scooter does not roll back after it has stopped on the slope.

To test if Load Compensation has the correct value, perform a series of scooter tests (drive on a slope, up a sidewalk edge, and over thick carpet) and check if the scooter behaviour is similar to the correct behaviour described above.




Figure 55: Optimum Load Compensation

기 Note

This test procedure causes the motor to become hot. For this reason, the resulting value for Load Compensation is too high. Reduce Load Compensation by 20% to make sure that the scooter is still comfortable to drive when the motor is cold.

A new motor usually has a higher motor resistance than a motor that has been used for some time, because the motor brushes that are inside the motor do not make optimal contact until they are "worn in". If possible, perform this procedure when the motor has been used for several hours.

6.5.5.6 Maximum Load Compensation

Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Maximum Load Compensation	0 - 225 mΩ	225mΩ				\checkmark

This parameter sets the maximum value that the *Load Compensation* parameter can be set to. This value must be set by the OEM to match the motors of the scooter.

Maximum Load Compensation prevents the dealer from setting *Load Compensation* to a value that is too high, which can be dangerous.



6.5.5.7 Load Compensation Damping

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Load Compensation Damping	0 - 60%	25%				\checkmark

Load Compensation Damping is used to dampen the effects of the load compensation to avoid bucking and instability at high Load Compensation settings.

The recommended value for this parameter is between 25 – 50%. It is important to avoid higher as this can lead to the load compensation continuing to be applied when the motor current has fallen, causing problems such as the scooter continuing to surge forward after, for example, climbing an obstacle.

The Load Compensation Damping parameter interacts with the following parameters:

- Remembered Load Compensation
- Load Compensation
- Park Brake Neutral Delay

When setting these parameters, follow the method below:

- 1. Adjust the *Load Compensation* parameter first to give correct driving performance.
- 2. Adjust *Load Compensation Damping* to minimise bucking, while keeping the system responsive.
- 3. Adjust the *Park Brake Neutral Delay* parameter to provide acceptable rollback on slopes and prevent jerking higher values decrease jerking but give more rollback and vice versa.
- 4. Adjust the *Remembered Load Compensation* to give acceptable starting performance when the park brake is released, both when driving on the flat and on slopes. (Note: this parameter has no effect if the scooter stops and restarts driving quickly such that the park brake is never applied.)

6.5.5.8 Remembered Load Compensation

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Remembered Load Compensation	15 - 60%	50%				\checkmark

The controller records the amount of motor current that is required to hold the scooter stationary just before the park brake is applied. When the scooter starts off again, this recorded value is used to calculate the starting load compensation value to reduce the amount that the scooter rolls back. The Remembered Load Compensation parameter adjusts the amount of this starting load compensation.

The Remembered Load Compensation parameter interacts with the following parameters:

- Load Compensation Damping
- Load Compensation
- Park Brake Neutral Delay



When setting these parameters, follow the method below:

- 1. Adjust the *Load Compensation* parameter first to give correct driving performance.
- 2. Adjust *Load Compensation Damping* to minimise bucking, while keeping the system responsive.
- 3. Adjust the *Park Brake Neutral Delay* parameter to provide acceptable rollback on slopes and prevent jerking higher values decrease jerking but give more rollback and vice versa.
- 4. Adjust the *Remembered Load Compensation* to give acceptable starting performance when the park brake is released, both when driving on the flat and on slopes. (Note: this parameter has no effect if the scooter stops and restarts driving quickly such that the park brake is never applied.)

6.5.5.9 Current Limit

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Current	0 - 90 (DS90) 0 - 120 (DS120) 0 - 160	See Parameter			/	/
Limit	(DS160)	Variations			v	V

Current Limit sets the maximum output current in Amperes that the RHINO2 will deliver to a motor. A low value can affect the performance of the scooter, for example when the scooter tries to climb up a curb.

The maximum useable setting depends on the current rating for the controller type, for example 90A for the DS90. Higher settings have no effect on the controller.

Warning

Do not set this parameter too high for the type of motor used.

🚺 Note

The time that the RHINO2 will deliver the maximum sustained current to the motors is limited by the Stall Timeout parameter.

To protect the electronics of the RHINO2, the maximum current will be reduced further if the controller becomes too hot.

6.5.5.10 Boost Current/ Boost Time

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Boost Current	DS90: 10A DS120, DS160: 20A	See Parameter Variations			\checkmark	\checkmark
Boost Time	All: 10s Except DS180: 5s	See Parameter Variations			\checkmark	\checkmark

The RHINO2 can deliver an additional current (*Boost Current*) of 10A (DS90), and 20A (DS120, DS160) for the *Boost Time* of up to 10 seconds, to overcome transient loads such as starting on a hill, climbing obstacles, etc.

If the *Boost Time* is reached, then the current is limited to *Current Limit*.





Before the current can reach the *Boost Current* value again, the motor current must stay below the value of *Current Limit* for at least twice as long as it was above *Current Limit*.

6.5.5.11 Stall Timeout

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Stall Timeout	0-51s	15s				\checkmark

If the throttle is deflected but the scooter cannot drive because

- it is on a slope that is too steep, or
- it tries to climb up a curb that is too high, or
- it is trapped,

then the maximum current (as set by the *Current Limit* parameter) will flow through the motor continuously, because the motor is still trying to drive. This situation is called motor stalling.

Motor stalling can cause motor damage when the motor becomes too hot. To prevent motor damage, the RHINO2 disables drive after *Stall Timeout* seconds of maximum continuous current.

If a stall timeout occurs, the scooter performs an emergency stop and the Status LED shows Flash Code 4 (see section 7.2 *Flash Code Display* for flash code descriptions). The scooter does not drive. To reset the fault, turn the scooter off and turn it back on again.

🚺 Note

Some safety standards specify a particular stall timeout. See the regulations of the country in which the scooter is to be used to determine what the correct Stall Timeout value is

Warning

Do not set Stall Timeout to 0s. This will disable the stall timer and the motors will not be protected in a stall situation. If Stall Timeout is set to zero, the RHINO2 will deliver as much power as it can, for as long as it can, while still protecting itself. This is not recommended because it can be against local regulations and can cause motor damage.



6.5.5.12 Motor Testing

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Motor Testing	None Open (Pre-Drive Only) Short All (Open Pre-Drive Only) Open (Pre-Drive and Drive) All (Open Pre-Drive and Drive)	Short				√

This parameter is set to determine which tests are performed on the motor (open circuit / short circuit) and when they are performed (before driving / during driving).

All (Open Pre-Drive Only)	Test the motor for both open and short circuits. The motor is tested for open circuits before starting to drive. The motor is tested for short circuits before driving and continuously while driving.
All (Open Pre-Drive and Drive)	Test the motor for both open and short circuits. Open circuit testing is performed before and during driving. The motor is tested for short circuits before driving and continuously while driving.
Open (Pre-Drive and Drive)	 Test the motor for open circuits. Open circuit testing is performed before and during driving. Use this setting if low impedance motors are being detected as a short circuit.
Short	Test the motor for short circuits.The motor is tested for short circuits before driving and continuously while driving.
Open (Pre-Drive Only) None	Test the motor for open circuits. Open circuit testing is performed before driving only. - Disable all motor testing.

Warning

- 1. For safety reasons, do not set this parameter to 'None' unless for testing in a controlled environment.
- 2. The safest option is "All (Open Pre-Drive and Drive)".
- 3. Only set this parameter to 'Open (Pre-Drive and Drive)' or 'Short' if the motors that are used are failing the test and they have been fully tested to make sure that they are healthy.
- 4. Only set this parameter to 'Open (Pre-Drive Only)' or 'All (Open Pre-Drive Only)' if the open circuit test while driving gives false faults or undesirable behaviour (such as increased motor noise).

6.5.5.13 Maximum Motor Voltage

Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Maximum Motor Voltage	0 - 64 V	26.2 V				\checkmark

Maximum Motor Voltage sets the maximum voltage that the RHINO2 will apply to the motor.

🚺 Note

If local regulations require that the scooter speed is limited to a specific value, use this parameter to set a speed limit for a particular scooter type (for specific motors and a specific wheel diameter).



If the momentary battery voltage is less than the programmed *Maximum Motor Voltage* value (for example when the battery is almost empty), then the battery voltage itself is the maximum applied voltage at 100 % speed demand.

The actual voltage output from the RHINO2 may at times be higher than this setting due to *Load Compensation* (see 6.5.5.5 Load Compensation).

Setting the value for Maximum Motor Voltage

Find a flat and smooth driving surface, long enough to achieve driving at maximum speed.

Set *Maximum Motor Voltage* to 1 V above the battery voltage. Drive at maximum speed and record the maximum speed. Now reduce *Maximum Motor Voltage* in small steps until the maximum speed is just not achieved anymore. Take the value of *Maximum Motor Voltage*, plus a small margin for tolerance (e.g. 0.2 V), as the value for *Maximum Motor Voltage*.

6.5.5.14 Max Motor V Scalar

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Max Motor V Scalar	60-100%	70%				\checkmark

This parameter determines how much the *Maximum Motor Voltage* is scaled down when the scooter is at maximum throttle demand, and when the scooter's speed rises above the maximum speed when driving down a slope. Reducing the *Maximum Motor Voltage* will reduce the maximum speed and hence slow the scooter to a safer, more comfortable speed when driving down the slope.

As a guide, the table below shows by how much the scalar reduces the *Maximum Motor Voltage*:

Max Motor V Scalar	Maximum Motor Voltage Reduction
60%	3 V
80%	4 V
100%	5 V

For more information, see 6.5.5.18 Downhill Speed Limiting.



6.5.5.15 Max Motor V Demand Limit

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Max Motor V Demand Limit	50 - 100%	100%				\checkmark

This parameter determines when to reduce *Maximum Motor Voltage* based on the throttle demand. If the throttle demand is above this level, the *Maximum Motor Voltage* is reduced.

Note that if this parameter is set too low, then driving on a flat surface could be affected, as it will add a short burst of additional acceleration when stopping.

For more information, see 6.5.5.18 Downhill Speed Limiting.

6.5.5.16 Max Motor V Ramp Down Time

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Max Motor V Ramp Down Time	0.5 – 2.5s	2.0s				\checkmark

This parameter sets the time it takes to ramp down the *Maximum Motor Voltage* when starting to drive down a slope. If this time is set too low, going down a short slope will also result in a noticeable speed reduction.

For more information, see 6.5.5.18 Downhill Speed Limiting.

6.5.5.17 Max Motor V Recovery Time

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Max Motor V Recovery Time	0.5 – 2.5s	2.0s				\checkmark

This parameter sets the time it takes to recover *Maximum Motor Voltage* to its programmed value when leaving a slope. If this time is set too short, speed will increase suddenly to match the throttle demand.

For more information, see 6.5.5.18 Downhill Speed Limiting.

6.5.5.18 Downhill Speed Limiting

When driving a scooter down a long slope at maximum speed, some scooters may experience an unintentional speed increase, especially large, high speed scooters (15kmh or faster). In most cases this unintentional speed increase is undesirable. This section describes how the controller can be programmed to either prevent or reduce this increase. Before setting up downhill speed limiting, ensure that *Load Compensation* and *Maximum Motor Voltage* are already set up correctly.

There are four parameters that are used to set up the desired behaviour:

- Max Motor V Scalar
- Max Motor V Demand Limit
- Max Motor V Ramp Down Time
- Max Motor V Recovery Time



As a starting point, set these parameters according to the following table:

Max Motor V Scalar	100%
Max Motor V Demand Limit	60%
Max Motor V Ramp Down Time	0.5s
Max Motor V Recovery Time	0.5s

The first parameter to set up is *Max Motor V Scalar*. Drive down a long slope at maximum speed. Shortly after entering the slope, the scooter will automatically decelerate and continue to drive at a reduced speed. If this reduced speed is too low, decrease the value of parameter *Max Motor V Scalar* until the reduced speed is as desired.

The next parameter to set up is *Max Motor V Ramp Down Time*. This parameter determines how quickly the scooter decelerates when entering a slope. Increase this value until a smooth transition is achieved. If this time is set too short, going down a short slope will also result in a noticeable speed reduction.

The next parameter to set up is *Max Motor V Recovery Time*. This parameter determines how quickly the scooter accelerates to the maximum speed when the slope ends. Increase this value until a smooth transition is achieved.

The last parameter to set up is *Max Motor V Demand Limit*. The downhill speed is only limited if the throttle demand is above the level set with this parameter. This parameter must be set up when driving on a flat surface. Drive at maximum speed and release the throttle. If this parameter is set too low, the scooter will add a short burst of additional deceleration when stopping. Increase the value of this parameter until this additional deceleration is not noticeable anymore. Setting this parameter to 100% will disable downhill speed limiting.

Verify that the behaviour when driving down a slope at full speed is still as desired.



6.5.6 Park Brake Management

6.5.6.1 Park Brake Testing

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Park Brake Testing	None Pre-drive Driving	Pre-drive				\checkmark

This parameter allows you to disable open-circuit testing on the park brake. Disabling open-circuit testing does not disable short-circuit testing. Short-circuit park brake testing is ALWAYS performed, even when the parameter is set to None.

Driving — The RHINO2 checks the park brake for open circuit and short circuit faults before and during driving.

Pre-drive — The RHINO2 checks the park brake for open-circuit before driving, but not during driving. Use this option when the test during driving is very noisy and/or incorrect faults are generated. Short circuit faults are still checked pre-drive and during driving.

None — The RHINO2 does not check the park brake for an open-circuit fault. This option allows the RHINO2 to be used without an electric park brake. Short circuit faults are still checked.

Warning

For safety reasons, do not use 'None' if the scooter has an electric park brake.

6.5.6.2 Park Brake Neutral Delay

Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Park Brake Neutral Delay	0 - 25500ms	200ms			\checkmark	\checkmark

The *Park Brake Neutral Delay* parameter sets the delay between zero speed demand (after the scooter has decelerated and stopped) and the moment that the park brake is engaged.




Figure 56: Park Brake Neutral Delay

The correct value of this parameter is dependent on the mechanics of the park brake that is used on the scooter. The delay must be longer for a fast-acting park brake.





If the value of *Park Brake Neutral Delay* is set too high, there may be too much rollback when stopping on a slope. If the value is set too low, the scooter may stop too abruptly.

6.5.6.3 Park Brake Release Delay

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Park Brake Release Delay	0 - 25500ms	100ms			\checkmark	\checkmark

The *Park Brake Release Delay* is the interval between when the park brake is released and when the scooter starts driving.

When the scooter is stopped, and the throttle is deflected, the park brake is released immediately but the scooter will not start driving until the *Park Brake Release Delay* has expired. This is useful for a park brake that has a slow mechanical release.




Figure 57: Park Brake Release Delay

Set the *Park Brake Release Delay* to suit the mechanical release speed of the park brake: set the value high for slow releases, and low or zero for fast releases.

Warning

If the Park Brake Release Delay value is set too high the scooter may begin rolling before the motors start driving.



6.5.7 Battery Management

6.5.7.1 Overvoltage Rollback

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Overvoltage Warning	24 - 30.2 V	30.2 V				\checkmark
Overvoltage Rollback	30.2 – 36.2 V	34.2 V				\checkmark

Set *Overvoltage Warning* to the voltage at which the controller will **begin slowing** the scooter to protect the batteries from an over-voltage condition.

Set *Overvoltage Rollback* to the voltage at which the controller will **stop** driving the scooter to protect the batteries from an over-voltage condition.

6.5.7.2 Undervoltage Rollback

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Undervoltage Rollback Start	18 - 32.2 V	21 V				\checkmark
Undervoltage Rollback End	17 - 21 V	18 V				\checkmark

If the battery voltage falls below *Undervoltage Rollback Start*, the RHINO2 reduces the maximum throttle input value, so the user cannot ask for full speed any more. This

- protects the battery,
- gives the scooter a longer range before the battery is completely empty, and
- gives the user a physical warning that the battery is almost empty before the battery is damaged.

The scooter will drive slower but should still be able to climb small obstacles such as curbs. If the battery voltage falls below *Undervoltage Rollback End*, the scooter stops driving because the throttle is reduced to zero.




Figure 58: Undervoltage rollback (start and end)



6.5.7.3 Battery Gauge Minimum/Maximum

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Battery Gauge Minimum	16 - 24 V	22 V				\checkmark
Battery Gauge Maximum	19 - 27 V	24.4 V				\checkmark

Battery Gauge Minimum sets the voltage at which the battery gauge indicates an empty battery.

Battery Gauge Maximum sets the voltage at which the battery gauge indicates a full battery.

6.5.7.4 Battery Gauge Warning

Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Battery Gauge High Warning	24 - 32 V	29 V			\checkmark	\checkmark
Battery Gauge Low Warning	18 - 26 V	23.4 V			\checkmark	\checkmark

Battery Gauge High Warning sets the voltage at which a high-voltage condition is indicated.

Battery Gauge Low Warning sets the voltage at which a low-voltage condition is indicated.

6.5.7.5 Battery Cut-Off Voltage

Parameter	Possible Values	Default	ННР	Lite	Std	Adv
Battery Cut-Off Voltage	16 - 24 V	21 V		\checkmark	\checkmark	\checkmark

This parameter is only used when *Deep Discharge Beeper* has the value 'Yes'.

The *Battery Cut-Off Voltage* specifies the voltage at which the battery is empty and battery damage will occur if the battery is discharged any further. If the battery voltage falls below this value, the RHINO2 gives the user an audible warning. The cut-off level for lead-acid batteries is 21 V.

기 Note

An audible and visible deep discharge warning is required to comply with ISO7176-14.

6.5.7.6 Battery Gauge Dead-band

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Battery Gauge Dead-band	0 - 6 V	3.5 V				\checkmark

Prevents the battery gauge from increasing when the battery voltage recovers after driving.

If the scooter is driving, the battery voltage will be lower than when the scooter stands still. However, the actual charge of the battery does not increase during standstill, even though the voltage has increased. This can cause the battery gauge to increase as well, showing a charge that is too high during standstill.

Battery Gauge Dead-band makes sure that the battery gauge only shows a higher charge when the battery is actually being charged. Any increase in battery voltage that is lower than the value of *Battery Gauge Dead-band* is ignored.



6.5.7.7 BatGauge Sensitivity

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
BatGauge Sensitivity	0-170	40	\checkmark			\checkmark

Adjusts the speed with which the battery gauge reacts to voltage fluctuations of the battery.

Batteries with a higher capacity take more time to discharge. For this reason, the battery gauge should react slower with high-capacity batteries to ignore fast voltage fluctuations that happen when the scooter encounters temporary loads such as a ramp.

If the battery voltage is less than the battery gauge currently indicates, the battery gauge decreases by 5% after BatGauge Sensitivity x 1.5 seconds. The 100% range of the battery gauge falls between *Battery Gauge Minimum* and *Battery Gauge Maximum*.

For better battery gauge accuracy, increase the value of *BatGauge Sensitivity* with highcapacity batteries and decrease the value with low-capacity batteries.



6.5.8 System Options

6.5.8.1 Service Scheduler

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Service Scheduler	No / Yes	No			\checkmark	\checkmark
Service Period	0 - 5100h	5000h	\checkmark	\checkmark	\checkmark	\checkmark

The *Service Scheduler* is a preventative maintenance feature that allows the OEM to set up scheduled servicing plans for their scooter customers.

To enable the Service Scheduler function, set Service Scheduler to 'Yes'.

Service Period sets the drive time between service schedules. When this number of hours has been exceeded, the status indicator will flash slowly 3 times every time the scooter is turned on or wakes up from sleep, to indicate that a service is due. This alarm is repeated every 15 minutes. Setting the value of *Service Period* to zero will disable the *Service Scheduler* and its alarm.

To clear the service indication, erase the controller history with the Wizard: Tools -> Erase Controller History.

🚺 Note

Erasing the controller history erases the fault log as well. Consequently, erasing the controller history to erase the fault log will reset the service scheduler as well.

6.5.8.2 Actuator Time-Out

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Actuator Time-Out	NOT USED					\checkmark

6.5.8.3 Enable 1Hz Data

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Enable 1Hz Data	No / Yes	No				\checkmark

The RHINO2 controller transmits scooter status information from two single-wire communication pins, *TH14* and *BC4* — see 7.7.2 *Physical interface*. There are two packets available:

- Full Data packet
- 1 Hz Data packet

The **Full Data** packet is transmitted always; the **1 Hz Data** packet is optional and only transmitted if enabled with this parameter. The **1 Hz Data** packet is limited to the following status information:

- Battery voltage
- Ambient temperature
- Motor current



If **1** Hz Data is not enabled, its status information is included in the Full Data packet instead.

🚺 Note

Single wire communications is covered in section 7.7 Status Information – Single Wire Communications.

6.5.8.4 Low Power Mode Duration

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Low Power Mode Duration ¹	0 – 90 days	0				\checkmark

This parameter sets the number of days the controller remains in Low Power Mode.

For more information about Low Power Mode, see 5.11 Controller Power Modes.

¹Low power mode is only available in firmware supporting DFVN 6. Program revisions and software versions are detailed in the table in section 6.2.1 Software version and module version.






6.5.9 Multi-function Inputs Configuration

6.5.9.1 Pin [x] Function

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Pin 4 Function	None Reverse Drive Release Brake	Profile 2			\checkmark	\checkmark
Pin 6 Function	Charger Inhibit Profile2 Slow	Slow/Stop			\checkmark	\checkmark
Pin 12 Function	Slow/Stop Slow/Stop FWD Slow/Stop REV	Reverse Drive			\checkmark	\checkmark
Pin 14 Function	SRW SRW (variable) Neutral Detect	Charger Inhibit			\checkmark	\checkmark
Prog/Inh Pin Function	Actuator Wig-wag (NOT USED) Actuator Control (NOT USED)	Charger Inhibit			\checkmark	\checkmark

The Program/Inhibit (P/I) pin of the charger connector and pin 4, 6, 12 and 14 of the tiller head connector can be configured as input pins.



Connect external switches or potentiometers to the input pins to activate one of the following functions:

None — No function, normal drive in all states.

Reverse Drive — When this function is active, it swaps the throttle direction. This function can be used for a 'Reverse' switch when *Throttle Type* is set to 'Single-ended' or 'Uni-polar'. If this function is activated while driving, the scooter will immediately decelerate to zero at the normal rate and then accelerate in the opposite direction. If multiple pins are programmed to perform Reverse Drive, they work in parallel: reverse drive applies as long as any combination of one or more pins is activated. Available on all input pins.

Release Brake — When this function is active, the park brake is released electrically, so that it is possible to push the scooter. It is not possible to drive the scooter while the park brake is released. To prevent a roll-away situation while the park brake is released, the scooter will stop if the speed during pushing is higher than the value of the *Push Speed* parameter. If the switch is active at power-up or is activated while driving, a park brake fault flash code will show on the Status light, but the scooter will still drive normally. In this



case, the Release Brake function will be disabled and the state of the associated input pin ignored until the power is cycled. Available on all input pins.

Charger Inhibit — Stops the scooter at the programmed *Emergency Deceleration* and inhibits drive. If *Latches* is set to 'Yes', the scooter must be turned off and on before it is possible to drive again. If *Flashes* is set to 'Yes', the Status Light will show a "Drive Inhibit" flash code while the drive inhibit is active. See section *7.2 Flash Code Display* for more information on flash codes. Note: to make the Charger Inhibit pin compatible with the industry standard where the inhibit signal must be connected to B- to activate inhibit, set Active to 'Low'. Available on pin 14 and P/I.

Profile 2 — When this function is active, the scooter switches to Profile 2 (see 6.5.3 Drive *Performance*). A typical application for Profile 2 is a user-selectable 'slow speed' mode that can be used indoors, while Profile 1 is selected for outdoor use. Apart from changing the maximum speed, the indoor profile can have its acceleration and deceleration adjusted as well. Available on all input pins.

Slow — Limits the maximum speed of the scooter to the value that is set with *Slows to*. Has no effect on scooter acceleration or deceleration. *Slows to* is a percentage of *Maximum Forward Speed* or *Maximum Reverse Speed*. For example, if *Maximum Forward Speed* is set to 80% and *Slows to* is set to 50%, the resulting maximum speed will be half of 80%, which is 40%. If *Slows to* is set to 0%, the function behaves the same as the 'Stop' state of the Slow/Stop function (including latching and flashing), which is described below. If *Slows to* is set higher than 0%, the Slow function neither latches nor flashes. Available on all input pins.

Slow/Stop – This function has three states:

- Normal drive (pin not connected).
- Slow (2.2 k Ω connected to B+ if Active High or B- if Active Low). Operates the same as the Slow function.
- **Stop** (pin connected to B+ if Active High or B- if Active Low). Stops the scooter at the programmed *Emergency Deceleration* and inhibits drive. If *Latches* is set to 'Yes', the scooter must be turned off and on before it is possible to drive again. If *Flashes* is set to 'Yes', the Status Light will show a "Drive Inhibit" flash code while the drive inhibit is active. See section 7.2 *Flash Code Display* for more information on flash codes.

Only valid Active settings are 'High' and 'Low', all other settings disable the input (the input will never become active). Available on all input pins.

Slow/Stop FWD — The same as Slow/Stop, but only applies to the forward direction; reverse drive is not affected. If *Latches* is set to 'No' and forward Stop has been activated and released, forward drive will still not be possible until the scooter has stopped and the throttle has been returned to neutral. Flash codes are not used during this function (*Flashes* is ignored). Available on all input pins.





Slow/Stop REV — The same as Slow/Stop, but only applies to the reverse direction; forward drive is not affected. If *Latches* is set to 'No' and reverse Stop has been activated and released, reverse drive will still not be possible until the scooter has stopped and the throttle has been returned to neutral. Flash codes are not used during this function (*Flashes* is ignored). Available on all input pins.

SRW — The Speed Reduction Wiper function provides an analogue input that can be used for a user-operated speed limit pot, or an anti-tip feature that automatically limits the speed of the scooter while turning. For more information, see the description of the *Speed Reduction Wiper (SRW) parameters*. Available on pins 4, 6 & 12 only.

SRW (variable) — The SRW (variable) function is an alternative to the SRW function above. It operates identically to the SRW function except that the resistor value is specified with the *SRW Scaling Resistor (Ohm)* parameter. Available on pins 4, 6 & 12 only.

🚺 Note

It is possible to configure more than one input pin to use the SRW functions, but each one **MUST** use the same SRW function, that is, they must all use SRW or they must all use SRW (variable). If one or more inputs use SRW at the same time that the other pins use SRW (variable) then the behaviour is undefined. If multiple input pins are programmed for SRW / SRW (variable), the controller will:

- use the input with the **LOWEST** resistance attached to determine speed reduction
- signal an open-circuit fault (if enabled) only when **ALL** input pins are open-circuit.

Neutral Detect — To prevent a runaway caused by a faulty electrical throttle circuit, this function compares the throttle signal with the signal from a 'neutral' switch. The 'neutral' switch must be mechanically connected to the throttle so that it activates when the throttle is in the true neutral position. If the throttle now gives an out-of-neutral output signal when the 'neutral' switch is still active, the RHINO2 does not drive and the Status light shows a "Throttle Fault" flash code. The scooter must be turned off and on to clear the fault. For this function to work correctly, the 'neutral window' of the throttle (as set with the *Throttle Dead-band* parameter) must be larger than the active range of the 'neutral' switch. Only valid Active settings are 'High', 'Low' and 'Open', all other settings will result in throttle faults. See also *8.1 Neutral Detect Active States*. Available on all input pins.

Actuator Wig-Wag - NOT USED

Actuator Control - NOT USED

🚺 Note

The Latches and Flashes parameters for all Stop and Charger Inhibit inputs work as follows:

If Latches is set to Yes, then once the corresponding drive inhibit function has been activated, driving will not be possible until the input has been returned to its inactive state and the controller power is cycled off. OONAPU testing is not relevant since even if the throttle is returned to neutral within the OONAPU period, driving is still inhibited.

If Latches is set to No, activation of the corresponding drive inhibit input will force driving to stop and driving

dynamic



will be prevented until the throttle has been returned to neutral. Since an OONAPU test will be triggered in this situation, even though the drive inhibit is programmed to be NOT latching, a latched OONAPU fault may be generated if the throttle remains deflected after the inhibit is activated, and this OONAPU fault would then require that the controller power is cycled.

If Flashes is set to Yes, then the drive inhibit status indication will be displayed regardless of the setting of the Latches parameter for the corresponding input. If Flashes is set to Yes and Latches is set to no then the drive inhibit indication will be displayed for as long as the corresponding input remains active while the throttle is deflected (in the inhibited direction for the case of directional Stop function).

6.5.9.2

If a pin is in its active state, the corresponding function will be executed. The input pins can be set to the following Active States:

Low — Input is active when pulled down, inactive when open or pulled up
High — Input is active when pulled up, inactive when open or pulled down
Open — Input is active when open, inactive when pulled up or pulled down
Low or High — Input is active when pulled down or pulled up, inactive when open
Low or Open — Input is active when pulled down or open, inactive when pulled up
High or Open — Input is active when pulled up or open, inactive when pulled down




Figure 60: Pulling inputs up/down

To pull up an input, connect it to B+. To pull down an input, connect it to B-.

If a multi-function input switch is connected to Pin 5 (Key Switch), put a diode in series for increased reliability. If multiple switches are connected to Pin 5 (Key Switch), it is not necessary to add a diode for each of them. One diode for all multi-function input switches combined is enough. Insert the diode as close to the switches as possible.




Figure 61: Put a diode in series if switches are connected to Pin 5 (Key Switch)





6.5.9.3 Slows to

The *Slows to* parameter sets the speed to which the controller slows down when a Slow function is active.

If set to 0%, the controller will decelerate at the programmed*Emergency Deceleration* rate and apply the park brake.

If set to 100%, the Slow function will have no effect.

Any values between 0% and 100% will cause the controller to decelerate using the programmed forward or reverse deceleration rate.

6.5.9.4 Latches

The *Latches* parameter sets whether the function will become latched once active. If a function is latched, the active condition will have to be removed and the controller turned off and then on again before the function will be turned off.

The *Latches* parameter only applies to those functions that inhibit driving: Charger Inhibit and Stop.

🚺 Note

If 'Latches' is selected, please select 'Flashes' as well to indicate to the user why the scooter will not drive.

6.5.9.5 Flashes

The *Flashes* parameter sets whether during a Drive Inhibit condition (when a Stop function is active or a Charger Inhibit condition occurs) a flash code will be displayed. The flash code that is displayed depends on the setting of the Flash Code Type parameter. See also section *7.2 Flash Code Display*.

6.5.10 Multi-function Outputs Configuration

6.5.10.1 Flash Code Type							
Parameter	Possible Values	Default	ННР	Lite	Std	Adv	
Flash Code Type	Scooter Shark Type 3 Type 4 R-Series	Scooter			\checkmark	\checkmark	

To make the most of your existing industry knowledge of products, the RHINO2 has the ability to display a variety of different flash code types.

	Scooter/R-Series*		Shark
#	Meaning	#	Meaning
1 2 3 4 5 6 7 8 9	Battery Low Low Battery Fault High Battery Fault Stall Time-out / Controller too hot Park brake Fault Drive Inhibit Speed Pot / Throttle Fault Motor Voltage Fault Other / Internal	1 2 3 4 5 6 7 8	Stop function / Charger Inhibit Battery Fault Motor Fault Stall Time-out / Controller too hot Park brake Fault - (unused) Speed Pot / Throttle Fault System / Internal Fault
,	Type 3		Туре 4
#	Meaning	#	Meaning
1 2 3 4 5 6 7 8 9 10	Battery Low Bad Motor Connection Motor Short Circuit Stall Time-out / Controller too hot - (unused) Drive Inhibit Speed Pot / Throttle Fault Controller Fault Park brake Fault High Battery Voltage	1-1 1-2 1-3 1-4 1-5 2-1 2-2 2-3 2-4 3-1 3-2 3-3 3-4 3-5 4-1 4-2 4-3 4-4	Thermal Cut-back / Stall Throttle Trip Speed Limit Pot Fault Under Voltage Fault Over Voltage Fault Main Contactor Driver Off Fault - (Unused) Main Contactor Fault Main Contactor Driver On Fault Dr. inhibit / OONAPU / Proc or Wiring Brake On Fault Pre-charge Fault Brake Off Fault High Pedal Disable Fault Current Sense Fault Motor Voltage Fault EEPROM Fault Power Section Fault

* The Scooter and R-Series produce the same flash code sequences to indicate a fault, but the flash timings are different:

• Scooter flash timings: 250 ms ON / 500 ms OFF with a 2 s break between.

• R-Series flash timings: 140 ms ON / 400 ms OFF with a 2.4 s break between.

See Section 7.2 Flash Code Display for a full description of the flash codes. The Wizard Diagnostics Report lists the currently selected Flash Code type.





6.5.10.2 Pin 3/11 Function

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Pin 3 Function	None Brake Light Reverse Light	Beeper			\checkmark	\checkmark
Pin 11 Function	Beeper Status Power Status	Power Status			\checkmark	\checkmark

These parameters set the function of Pin 3 and pin 11 on the tiller connector. Pin 3 and pin 11 are both capable of sinking 500 mA. To use the outputs, connect a 24 V beeper, lamp, or Status LED (with resistor) between B+ and pin 3 or pin 11.

None — The output is not used.

Brake Light — The output pin drives a 24 V brake light. The brake light is on when the scooter decelerates in either the forward or reverse direction. Connect the light between B+ and the pin that has 'Brake Light' selected.

Reverse Light — The output pin drives a 24 V reverse light. The reverse light is switched on when the scooter drives in reverse. Connect the light between B+ and the pin that has 'Reverse Light' selected.

Beeper — The output pin drives a 24 V beeper. Connect the beeper between B+ and the pin that has 'Beeper' selected. To activate any beeper sounds, set *Enable Beeper* to 'Yes'. Other beeper options can be selected with *Flash Code Beeper, Sleep Beeper, Motion Beeper, Deep Discharge Beeper, Reversing Beeper,* and *Beeper Timing*.

Status — The output pin drives a Status light. The Status light is on when the power is on. When a fault condition exists, the Status light shows the related flash code.

Power Status — The output pin drives a Power-on light. The Power-on light is on when the power is on. The Power-on light does not show flash codes, it remains on continuously.

If an output is set to 'Brake Light', 'Reverse Light', 'Status' or 'Power Status', the light used can be a 24 V LED array (max. 500 mA) or a relay-driven incandescent or halogen bulb. If a relay is used, a fly-back diode and a series diode must be installed. If an LED array is used, it must have its own internal current limiting system. An LED array must also have reverse polarity protection such as a series diode. An LED array may show a faint glow if the output is not active. If this is the case, resistors mounted in parallel to the LED array may reduce the glow.

For more information and schematics, see 5.9.10 Status Indicator Output, 5.9.11 Beeper Output and 5.9.13 Brake and Reversing Lights.





6.5.10.3 PIN 10 FUNCTION							
Parameter	Possible Values	Default	ННР	Lite	Std	Adv	
Pin 10 Function	None Status High Status Low Fault High Fault Low 5V Gauge 12V Gauge Other	Status High			\checkmark	√	

6.5.10.3 Pin 10 Function

Sets the function of Pin 10 on the tiller connector. Pin 10 is capable of sinking 50 mA at 24 V and sourcing 10 mA at 12 V.

None — The output is not used.

Status High — The output pin drives a 12 V Status LED (10 mA max). The Status LED is on when the power is on. When a fault condition exists, the Status LED shows the related flash code. Connect the LED between pin 10 and B-. Install a resistor that limits the current to 10 mA at 12 V. See also *5.9.10 Status Indicator Output*.

Status Low — The output pin drives a 24 V Status LED or lamp (50 mA max). The Status LED is on when the power is on. When a fault condition exists, the Status LED shows the related flash code. Connect the LED between B+ and pin 10. Install a resistor that limits the current to 50 mA at 24 V. See also *5.9.10 Status Indicator Output*.

Fault High — The output pin drives a 12 V Fault LED (10 mA max). The Fault LED is **off** when the power is on and no fault condition exists. When a fault condition exists, the Fault LED shows the related flash code. If the system is in Sleep Mode when a fault condition exists, the Fault LED does not show the related flash code. Connect the LED between pin 10 and B-. Install a resistor that limits the current to 10 mA at 12 V. See also *5.9.10 Status Indicator Output*.

Fault Low — The output pin drives a 24 V Fault LED or lamp (50 mA max). The Fault LED is **off** when the power is on and no fault condition exists. When a fault condition exists, the Fault LED shows the related flash code. If the system is in Sleep Mode when a fault condition exists, the Fault LED does not show the related flash code. Connect the LED between B+ and pin 10. Install a resistor that limits the current to 50 mA at 24 V. See also *5.9.10 Status Indicator Output*.

5V Gauge — The pin will show the state of the battery on an analogue 5 V voltmeter battery gauge. Connect the battery gauge between pin 10 and B-. See also *5.9.12 Battery Gauge Output*.

12V Gauge — The pin will show the state of the battery on an analogue 12 V voltmeter battery gauge. Connect the battery gauge between pin 10 and B-. See also *5.9.12 Battery Gauge Output*.





Other — Drives a digital multi-LED battery gauge display. Connect the LED battery gauge between B+ and B-. Connect pin 10 to the "Data In" input of the LED battery gauge.

If a Battery Charger inhibit is activated, the gauge shows a charging sequence.

If a flash code condition exists, the flash code number is indicated by the number of flashes (same as for a single status indicator), regardless of the number of bars lit. The number of bars lit continues to indicate the battery gauge level during flash code indication.

To indicate to the user when the scooter is in Sleep Mode, one or two LED bars^{‡1} will flash once every 5 seconds.

🚺 Note

‡1 — The number depends on the gauge fitted, and the RHINO2 firmware version.

6.5.10.4 Key Switch Status LED

Parameter	Possible Values	Default	HHP	Lite	Std	Adv
Key Switch Status LED	No / Yes	Yes				\checkmark

To reduce current drain, set this parameter to 'No' if a status LED is not wired in series with the key switch.



Page 122



7 Diagnostics

7.1 Introduction	4
7.2 Flash Code Display	4
7.2.1 Scooter / R-Series Flash Codes	4
7.2.2 SHARK Flash Codes	5
7.2.3 Type 3 Flash Codes	6
7.2.4 Type 4 Flash Codes	6
7.3 Diagnostics Tools	7
7.3.1 Hand Held Programmer	7
7.3.2 DYNAMIC Wizard	7
7.3.3 Fault log	7
7.4 HHP Fault Codes with sub codes	8
7.5 Advanced Diagnostics Logs	0
7.5.1 Usage Counters (available in both Wizard and HHP) 130	0
7.5.2 Run-time Readings (available in HHP – Technician	
	0
7.6 Service Scheduler	1
7.7 Status Information — Single Wire	
Communications	2
7.7.1 Status information overview	2
7.7.2 Physical interface	3
7.7.3 Protocol	4

Diagnostics



Note

The RHINO2 is not user serviceable. Specialised tools are necessary for the repair of any RHINO2 component.

7.1 Introduction

An abnormal condition may be indicated by a flash code on the Status output. A Flash Code is a sequence of flashes, separated by a pause, followed by a repetition of the sequence. Additionally, Flash Codes may be sounded by connecting a beeper to a suitably programmed output and setting the *Flash Code Beeper* parameter to 'Yes'. Depending on the condition, the scooter may or may not allow driving. In some cases, driving may be allowed but in a reduced speed mode.

7.2 Flash Code Display

To make the most of your existing industry knowledge of products, the RHINO2 has the ability to display a variety of different flash code types. These may be one of Scooter, Shark, Type 3, or Type 4. The Diagnostics Report lists the Flash Code type that the controller is currently set to display See the following sections for each set of flash code details.

Flash*		Meaning
1	Battery Low	The batteries are running low or are in an over-discharged state.Recharge the batteries.
2	Low Battery Fault	The batteries have run out of charge.Recharge the batteries.Check the battery and associated connections and wiring.
3	High Battery Fault	 Battery voltage is too high. This may occur if overcharged and/or travelling down a long slope. If travelling down a slope, reduce your speed to minimise the amount of regenerative charging.
4	Current Limit Time-out or Controller too hot	 The motor has been exceeding its maximum current rating for too long. The scooter may have stalled. Turn the controller off, leave for a few minutes and turn back on again. The motor may be faulty. Check the motor and associated connections and wiring.
5	Park Brake Fault	 Either a park brake release switch is active or the park brake is faulty. Check the park brake and associated connections and wiring. Ensure any associated switches are in their correct positions.
6	Drive Inhibit	 Either a Stop function is active or a Charger Inhibit or OONAPU condition has occurred. Release the Stop condition (seat raised etc.) Disconnect the Battery Charger Ensure the throttle is in neutral when turning the controller on. The Throttle may require re-calibration.
7	Speed Pot Fault	The throttle, speed limit pot, SRW or their associated wiring may be faulty.

7.2.1 Scooter / R-Series Flash Codes





Flash*	Description	Meaning
		• Check the throttle and speed pot and associated connections and wiring.
8	Motor Voltage Fault	The motor or its associated wiring is faulty.Check the motor and associated connections and wiring.
9	Other error	The controller may have an internal fault.Check all connections and wiring.

* The Scooter and R-Series produce the same flash code sequences to indicate a fault, but the flash timings are different:

- Scooter flash timings: 250 ms ON / 500 ms OFF with a 2 s break between.
- R-Series flash timings: 140 ms ON / 400 ms OFF with a 2.4 s break between.

7.2.2 SHARK Flash Codes

Flash	Description	Meaning
1	User Fault / Drive Inhibit	 Either a Stop function is active or a Charger Inhibit condition has occurred. Release the Stop condition (seat raised etc.) Disconnect the Battery Charger Turn the controller off and then on again.
2	Battery Fault	 Battery voltage is either too low or too high. If you have been driving normally the batteries may be depleted. Recharge the batteries. If you are travelling down a slope, the batteries may be overcharged. Reduce your speed to minimise the amount of regenerative charging Check the battery and associated connections and wiring.
3	Motor Fault	 The motor has been exceeding its maximum current rating for too long, or may be faulty. Turn the controller off, leave for a few minutes and turn back on again. Check the motor and associated connections and wiring.
4	Current Limit Time-out or Controller too hot	 The motor has been exceeding its maximum current rating for too long. The scooter may have stalled. Turn the controller off, leave for a few minutes and turn back on again. The motor may be faulty. Check the motor and associated connections and wiring.
5	Park Brake Fault	 Either a park brake release switch is active or the park brake is faulty. Check the park brake and associated connections and wiring. Ensure any associated switches are in their correct positions.
6	unused	
7	Throttle Fault	 The Throttle is out of neutral when turning the controller on. The throttle or speed limit pot, or their associated wiring may be faulty. Ensure the throttle is in neutral when turning the controller on. The Throttle may require re-calibration. Check the throttle and speed pot and associated connections and wiring.
8	System Fault	The controller may have an internal fault.Check all connections and wiring.



7.2.3 Type 3 Flash Codes

Flash	Description
1	Low Battery
2	Bad Motor Connection
3	Motor Short Circuit
4	Current Limit Time-out / Controller too hot
5	unused
6	Drive Inhibit
7	Throttle Fault
8	Controller Fault
9	Park Brake Fault
10	High Battery Voltage

7.2.4 Type 4 Flash Codes

A Type 4 flash code involves the use of twin flashes to identify the type of fault.

Flash	Description
1-1	Thermal Cut-back / Stall
1-2	Throttle Trip
1-3	Speed Limit Pot Fault
1-4	Under Voltage Fault
1-5	Over Voltage Fault
2-1	Main Contactor Driver Off Fault
2-2	Unused
2-3	Main Contactor Fault
2-4	Main Contactor Driver On Fault
3-1	Drive inhibit / OONAPU / Proc or Wiring Fault
3-2	Brake On Fault
3-3	Pre-charge Fault
3-4	Brake Off Fault
3-5	High Pedal Disable Fault
4-1	Current Sense Fault
4-2	Motor Voltage Fault
4-3	EEPROM Fault
4-4	Power Section Fault



7.3 Diagnostics Tools

While the RHINO2 may indicate the abnormal condition, a hand-held programmer or the PCbased Wizard 5 will provide more detailed information on the fault.

7.3.1 Hand Held Programmer

Plugging a hand-held programmer into the RHINO2 when an abnormal condition exists will cause the fault to be displayed on the screen. A 4-digit code will be displayed which indicates the condition. The first two digits provide the flash code number. The second two digits provide more specific diagnostics information that is suitable for repair technicians. While there are alternative flash code sequences that may be flashed on the status LED, the hand-held programmer will only display the appropriate Scooter Flash Code information. For instance if the Shark Flash Codes are used, the Status LED will display an 8-Flash code for an internal error. When the hand-held programmer is plugged in, it will display a flash code 9 on the screen.

7.3.2 DYNAMIC Wizard

Wizard is the preferred diagnostics tool in the workshop environment, providing a full fault history (last 16) and description of each flash and associated servicing code. If after analysing the data, the condition cannot be diagnosed, it is possible to save a Status Report for further analysis or distribution via email to a service centre.

🚺 Note

It is also possible to print and fax the Status Report to the service centre, but the preferred method is to email the report, as the electronic version of the report contains additional information that is not available in the printed version.

7.3.3 Fault log

The RHINO2 contains a fault log that stores the last 16 faults in sequence of occurrence. The fault log can be accessed with the HHP and with the Wizard (by making a diagnostics report).

It is possible to clear the fault log with the Wizard:

Tools -> Erase Controller History.

🚺 Note

Erasing the controller history will reset the Service Scheduler as well.



7.4 HHP Fault Codes with sub codes

Code	Fault source	Sub code	Meaning				
	User	01	Chair needs to be serviced Contact your service agent 				
01		02 03	A warning is being displayed on the Battery Gauge Out Of Neutral At Power Up (OONAPU) testing going on • Release the throttle and wait for the test to be finished				
		00	Voltage too highBatteries may be overcharged: if driving downhill, slow down				
02	Battery	01	 Voltage too high – emergency stop occurred Batteries may be overcharged: if driving downhill, slow down 				
		00	 Short circuit Check the motor cables for damage Motor brushes may be too stiff, bouncing against the case Replace motor brushes or motor 				
	Motor	01	Open circuit Check if the motor cables are loose Motor brushes may be worn Turn wheels to reconnect Replace motor brushes or motor 				
03		02	 Motor terminal connected to Battery Negative (B-) Check if the motor has been connected correctly Check the motor cables for damage 				
		03	 Motor terminal connected to Battery Positive (B+) Check if the motor has been connected correctly Check the motor cables for damage 				
		04	 Motor voltage is not what it should be during drive Possible motor short circuit check the motor cables for damage Motor brushes may be too stiff and bouncing Otherwise internal controller fault, contact Dynamic Controls 				
		07	 Intermittent short circuit Check for damaged cables Motor brushes may be too stiff, bouncing against the case Replace motor brushes or motor 				
		00	Park Brake energised or drive time test failedCheck if the cables of the park brake are loose or damaged				
	Park brake	01	Park brake not connected, short circuit or brokenCheck if the cables of the park brake are loose or damaged				
04		04	Park brake short circuit or broken Check the park brake cables for damage 				
		06	 Park brake released when throttle is not idle. re-engage the park brake using the manual override before driving 				





Code	Fault source	Sub code	Meaning				
	Throttle	00	 Throttle wiper (pin 1 on Tiller Connector) voltage out of spec Check the throttle cables for damage Recalibrate throttle Replace the throttle pot 				
		01	 Throttle Positive (pin 2 on Tiller Connector) or Throttle Negative (pin 8 on Tiller Connector) out of spec Check the throttle cables for damage Replace the throttle pot 				
		02	Speedpot fault, treating speedpot as set to minimumCheck speedpot cable for damageReplace speedpot				
05		03	Speed Reduction Wiper (SRW) fault, treating as set to minimumCheck SRW cable for damageReplace SRW				
		04	Out Of Neutral At Power Up (OONAPU) Release the throttle and try again 				
		05	Calibration fault Recalibrate throttle Check the throttle cables for damage Replace the throttle pot 				
		06	Throttle calibration in progressFinish the calibration instructions				
		07	 Neutral detect out of neutral Check the throttle cables for damage or loose connections Replace the neutral detect hardware Change the neutral window (see <i>Throttle Neutral Offset</i> and <i>Throttle Dead-band</i>) 				
06	I/O	01	Battery gauge fault, battery gauge deactivatedCheck if the battery gauge cables are damaged or loose				
	Internal fault	All	Contact Dynamic				



7.5 Advanced Diagnostics Logs

In addition to the standard diagnostics reports, additional diagnostic information is available from the controller using the Wizard or HHP. This additional information is extremely useful for identifying the root cause of any faults, and allows for a faster, more efficient service process. It will also allow for feedback to be given to the user if their use of the scooter is causing any issues.

There are two sources of the advanced diagnostics logs; the Usage Counters provide detailed information on the use of the scooter; the Run-time Readings provide real-time analysis of the system in operation.

7.5.1 Usage Counters (available in both Wizard and HHP)

Counter	Description
Powered Up Time	The total amount of time (hours) the controller has been turned on.
Powered Up Count	The number of times the controller has been turned on.
Drive Time	The total amount of time (hours) the controller has been driving (park brake disengaged).
Drive Count	The number of times the controller has been driving (number of times the park brake has disengaged).
Deep Discharge Count	The number of times the batteries have been deep discharged.

7.5.2 Run-time Readings (available in HHP – Technician mode only)

Reading	Description
Battery (V)	The voltage of the batteries.
Motor (V)	The voltage being applied to the motor.
Motor (A)	The current being applied to the motor.
Temperature (°C)	The internal temperature of the controller.
Temperature (°C)	The temperature of the FETs.
Throttle (V)	The voltage of the throttle.



7.6 Service Scheduler

The Service Scheduler is a preventative maintenance feature that allows the OEM to set up scheduled servicing plans for their scooter customers.

If enabled, a Service Period can be programmed into the controller. Once the Drive Time exceeds this value, the status LED will flash slowly 3 times every time the scooter is turned on or wakes up from sleep, to indicate the service is due. This is repeated every 15 minutes. Setting the value of *Service Period* to zero will disable the Service Scheduler and its alarm.

To enable the Service Scheduler function, set *Service Scheduler* to 'Yes' and set *Service Period* to the desired number of drive time hours before a service is due. To clear the service indication, erase the controller history with the Wizard:

Tools -> Erase Controller History.

🚺 Note

Erasing the controller history erases the fault log as well.

Consequently, erasing the controller history to erase the fault log will reset the service scheduler as well.



7.7 Status Information – Single Wire Communications

This section describes how to connect an external, third-party data logging device to the RHINO2 single wire communication pins and read the scooter's status information.

7.7.1 Status information overview

The RHINO2 controller transmits scooter status information in packets from two singlewire communication pins — see *Physical interface*. There are two packets available:

- Full Data packet
- 1 Hz Data packet

The **Full Data** packet is transmitted always; the **1 Hz Data** packet is optional and only transmitted if enabled.

🚺 Note

1 Hz refers to the sampling frequency of the data, not its transmission rate. 1 Hz Data is transmitted, nominally, every 8 seconds when enabled. See 7.7.3.2.2 1 Hz Data packet transmission for more information.

For each **Full Data** packet transmission, the following information is provided¹:

- Charger inhibit status
- Key switch status
- Active error code
- Battery gauge estimate
- Speed limit
- Driving status
- Pin status (TH4, TH6, TH12 and TH14)
- Month of manufacture
- Year of manufacture
- Serial number
- Controller current rating
- Time controller powered up

- Controller power up count
- Controller driving time
- Controller drive count
- Battery deep discharge count
- Battery overcharge count
- Internal condition code
- Active flash code
- RHINO2 software version / revision
- Battery voltage¹
- Ambient temperature¹
- Motor current¹

Note 1: Battery voltage, ambient temperature and motor current data are only available in the Full Data packets when the 1 Hz Data transmission is disabled.

For each **1 Hz Data** packet transmission, the following information is provided:

- Battery voltage
- Ambient temperature²
- Motor current

Note 2: This data is sampled from an optionally installed, external NTC thermistor.



7.7.2 Physical interface

An external, third-party data logging device can connect to one of the two single-wire communication pins: pin 14 on the tiller head connector (TH14) or pin 4 on the battery charging and programming connector (BC4) see *Figure 62* for pin location.

Note that the external data logging device can connect to either pin — the information transmitted on each pin is identical — but the pin chosen must not be used for any other circuit and must not be set as an inhibit.




Figure 62: Connectors and pin locations

🚺 Note

For RHINO2 modules with firmware version **1.24** and **1.28**, to ensure reliable communication with an external data logging device that employs a 3 V / 3.3 V UART, it is suggested that a resistor is fitted on the loom between the single-wire communication pin (TH14 or BC4) and battery negative. As a guide, 1 K Ω is suggested, but this needs to be verified through measuring the voltage levels on the connected device.

For later RHINO2 modules, with firmware version **1.35 or greater**, do not fit an external resistor. The RHINO2 module is optimised for external data logging devices that employ a 3 V / 3.3 V UART, and a resistor fitted on the loom with these later modules will prevent, if any, reliable communication.

🚺 Note

It is important that a common ground is established between the RHINO2 and the external data logging device. This is achieved by connecting the external data logging device's ground to the RHINO2's battery negative.

7.7.2.1 Connecting to pin TH14



Connect a single wire to pin 14 of the tiller head connector via a 14-way, 2row, 4.2 mm pitch Molex, Mini-Fit Jr female connector housing (manufacturer part no. 39-01-2145 — Dynamic part no. GCN0887). The wire gauge should be a minimum of 0.5mm² (20AWG) and terminated with a Molex, Mini-Fit female crimp terminal contact 18-24AWG (manufacturer part no. 39-00-0039 — Dynamic part no. GCN0771).

In Wizard, set *Pin 14 Function*, which can be found under the *Multi-function Inputs Configuration* group, to **None**.

7.7.2.2 Connecting to pin BC4



Connect a single wire to pin 4 of the battery charging and programming connector via a 4-way, 2-row, 4.2 mm pitch Molex, Mini-Fit Jr female connector housing (manufacturer part no. 39-01-3048 — Dynamic part no. GCN0886). The wire gauge should be a minimum of 0.5 mm² (20AWG) and terminated with a female Molex, Mini-Fit crimp terminal contact 18-24AWG



(manufacturer part no. 39-00-0039 – Dynamic part no. GCN0771).

In Wizard, set *Prog/Inh Pin Function*, which can be found under the *Multi-function Inputs Configuration* group, to **None**.

7.7.3 Protocol

7.7.3.1 Configuration

Communications is unidirectional, using a single wire from the RHINO2 to the external data logging device and is set at 9600 baud, with 1 stop bit, and no parity (9600/8-N-1).

7.7.3.2 Data transmission

The following outlines the transmission schedules for both the **Full Data** packet and the **1 Hz Data** packet. The **1 Hz Data** packet is transmitted only if enabled.

7.7.3.2.1 Full Data packet transmission

Full Data is scheduled to transmit periodically on each single-wire communication pin in data packets, the first of which starts approximately 10 seconds after the scooter is powered up. A packet is transmitted:

- once every 60 seconds if the scooter is driving or is connected to a charger and charging;
- once every 60 minutes (first 6 hours only) if the scooter is not driving and the key is in the *On* position;
- once every 12 hours while the scooter controller is in *Low Power Mode* see 5.11 *Controller Power Modes*.

In addition to the scheduled transmissions, a packet is transmitted when any one of the following changes state:

- key status
- inhibit status
- active fault status
- park brake status
- sleep status
- charging status

Following an unscheduled transmission (listed above), the next scheduled transmission begins after the regular fixed interval (60 seconds, 60 minutes or 12 hours) starting from the time that the unscheduled transmission began transmitting.

7.7.3.2.2 1 Hz Data packet transmission

If the 1 Hz Data packet transmission is enabled (see *Enable 1Hz Data*), it is transmitted, nominally, once every 8 seconds. Between transmissions, the values of battery voltage, ambient temperature, and motor current are sampled once a second and then stored in buffers. Note that these buffers can hold more than 8 sets of samples in case the transmission needs to be delayed, because, for example, a Full Data transmission is in progress.





1 Hz data transmissions, if enabled, will occur only while driving or while the battery is being charged and the battery gauge has not yet reached 100%.

7.7.3.2.3 Data element structure

Each packet consists of a number of 2-byte data elements (see *Table 1* for full list).

The first byte in the data element is the element's identifier (*ID* in *Figure 63*), which is unique to each data element.



2-byte element Figure 63: A 2-byte data element

The second byte is the element's data value (*Data* in *Figure 63*).

7.7.3.2.4 Packet structure - Full Data

Each element is transmitted in sequence, according to its ID. Disregarding the dummy element (see next section), the packet begins with the *start element* and ends with the *checksum* — see *Figure 64*. The start element's ID is always 0x01 and the checksum's ID, the last element, is always 0xFF.




Figure 64: Packet structure - Full Data

7.7.3.2.5 Packet structure – 1 Hz Data

The data is transmitted in chronological order in sets of three (normally 24 elements). Each set comprises a sample of battery voltage, ambient temperature and motor current — see *Figure 65*. The oldest set is transmitted first followed by 7 or more similar sets until the transmit buffers are emptied. Once started, the 1 Hz Data transmission is completed before any Full Data transmission is started — this may mean a Full Data transmission is delayed slightly if a 1 Hz Data transmission is already in progress.






Figure 65: Packet structure – 1 Hz Data

7.7.3.2.6 Packet transmission and timing - Full Data packet

The transmission of a packet begins with a dummy element (0x00, 0x00). This is sent in case the external receiving device is in a low-power sleep mode, which is particularly likely at key-on. The dummy element has no meaning other than to wake up the external device, so this can be safely ignored by the external device.



After transmitting the dummy element, there is a delay of approximately one second before the first data element is transmitted. This first element has two roles: firstly, its ID byte indicates the start of the data, and secondly, its data byte corresponds to the data protocol version. The ID byte is always 0x01; the data byte, at the time of writing is 0x01, corresponding to version 1.

Subsequent data elements are transmitted with a 40 ms delay between each element (see *Figure 66*).

The last element in the packet is the checksum, whose value can be used by the external device to validate the packet. This element, being the final element sent, also signals the end of the packet transfer to the external device. The checksum ID is always 0xFF and the checksum value is the 2's complement¹ of the 8-bit sum of all the preceding bytes in the packet, including the checksum ID (0xFF).

Note 1: For more information on the operation of the 2's complement checksum, contact Dynamic.





7.7.3.2.7 Packet transmission and timing – 1 Hz Data packet

Data elements are transmitted with a 40 ms delay between each element (see *Figure 67*). Unlike the Full Data packet, there is no *Dummy element* or *End of Data Transfer (checksum) element*.




Figure 67: Packet transmission – 1 Hz Data packet example

7.7.3.2.8 Table of data elements

Table 1: Data elements						
ID	Name	Data values	Description			
0x00	Dummy element	0	The dummy element is sent to wake up the receiving device. There is a one second delay before the next element (0x01) is transmitted.			
0x01	Start element	2	Indicates the start of the data and corresponds to the protocol version			
0x02	Inhibit status	0-1	(Charger) inhibit status: 0 — no inhibit active 1 — inhibit active 2 — inhibit active and battery charging			
0x03	Key switch status	0-2	Indicates the status of the key switch: 0 — key off 1 — key on, normal operation 2 — key on, sleep mode 3 — key on, low power mode			
0x04	Active error code	See "HHP Fault Codes with sub codes" on page 128	Upper nibble (0–F): flash code Lower nibble (0–F): subcode			
0x05	Battery gauge estimate	0-100 %	Battery gauge			
0x06	Speed limit	0-100 %	This is the value of the speed limit input (SLP) connected to pin TH9			
0x07	Driving status	0-1	Indicates driving status: 0 — not driving 1 — park brake released and driving			
0x08	Pin TH4 level	0-255	Integer part of voltage on pin TH4. Note that 1 LSB corresponds to 250 mV.			
0x09	Pin TH6 level	0-255	Integer part of voltage on pin TH6. Note that 1 LSB corresponds to 250 mV.			
0x0A	Pin TH12 level	0-255	Integer part of voltage on pin TH12. Note that 1			

dynamic

GBK51948 RHINO2 Installation Manual Issue 6



ID	Name	Data values	Description			
			LSB corresponds to 250 mV.			
0x0B	Pin TH14 level	0-255	Integer part of voltage on pin TH14. Note that 1 LSB corresponds to 250 mV.			
0x0C	Month of manufacture	1–12	Indicates the month the RHINO2 controller module was manufactured. 1 — January, 2 — February, etc.			
0x0D	Year of manufacture	0-99	Indicates the year the RHINO2 controller module was manufactured			
0x0E	Serial number — byte 1	0-255	Controller serial number — first byte of four-byte value — most significant byte			
0x0F	Serial number — byte 2	0-255	Controller serial number — second byte of four-byte value			
0x10	Serial number — byte 3	0-255	Controller serial number — third byte of four-byte value			
0x11	Serial number — byte 4	0-255	Controller serial number — fourth byte of four-byte value — least significant byte			
0x12	Controller current rating	90, 120, 160 or 180	Current rating of controller			
0x13	Time controller powered up — byte 1	0-255	Time in minutes the controller has been powered up — first byte of 3-byte value — most significant byte			
0x14	Time controller powered up — byte 2	0-255	Time in minutes the controller has been powered up — second byte of 3-byte value			
0x15	Time controller powered up — byte 3	0-255	Time in minutes the controller has been powered up — third byte of 3-byte value — least significant byte			
0x16	Controller power up count — byte 1	0-255	Number of times controller has been powered up — first byte of 3-byte value — most significant byte			
0x17	Controller power up count — byte 2	0-255	Number of times controller has been powered up — second byte of 3-byte value			
0x18	Controller power up count — byte 3	0-255	Number of times controller has been powered up — third byte of 3-byte value — least significant byte			
0x19	Controller driving time — byte 1	0-255	Time in minutes the controller has been driving — first byte of 3-byte value — most significant byte			
0x1A	Controller driving time — byte 2	0-255	Time in minutes the controller has been driving — second byte of 3-byte value			
0x1B	Controller driving time — byte 3	0-255	Time in minutes the controller has been driving — third byte of 3-byte value — least significant byte			
0x1C	Controller drive count — byte 1	0-255	Number of times controller has been driven — first byte of 3-byte value — most significant byte			
0x1D	Controller drive count — byte 2	0–255	Number of times controller has been driven — second byte of 3-byte value			
0x1E	Controller drive count — byte 3	0–255	Number of times controller has been driven — third byte of 3-byte value — least significant byte			





ID	Name	Data values	Description
	Battery deep		Number of times of battery deep discharge — first byte
0x1F	discharge count — byte 1	0-255	of 2-byte value — most significant byte
	Battery deep		Number of times of battery deep discharge — second
0x20	discharge count — byte 2	0-255	byte of 2-byte value — least significant byte
0x21	Battery overcharge count — byte 1	0-255	Number of times of battery overcharge — first byte of 2-byte value — most significant byte
0x22	Battery overcharge count — byte 2	0-255	Number of times of battery overcharge — second byte of 2-byte value — least significant byte
0x23	Internal condition Code — byte 1	0-255	Internal condition Code — first byte of 2-byte value — most significant byte
0x24	Internal condition Code — byte 2	0-255	Internal condition Code — second byte of 2-byte value — least significant byte
0x25	Active flash code	See "Flash Code Display" on page 124	Number of flashes for the active flash code (flash code will depend on the programmed flash code type)
0x26	RHINO2 software version	0-255	Version part of the software <i>version.revision</i> value. For example: 0x01 for the "1" in V 1 .26
0x27	RHINO2 software revision	0-255	Revision part of the software <i>version.revision</i> value. For example: 0x1A (26 dec) for the "26" in V1. 26
0x28	Battery voltage ¹	0-255	Battery voltage between 0 and 31.875 V. Note that 1 LSB = 125 mV.
0x29	Ambient temperature ¹	-128 to +127	Ambient temperature with nominal range between -80 to +120, which represents temperatures between -40 °C and +60 °C. Note that 1 LSB = 0.5 °C. Values - 128 and +127 indicate an open circuit or short circuit fault.
0x2A	Motor current ¹	-127 to +127	Motor current units representing a current range from - 254 A to + 254 A. Note that 1 LSB = 2 A.
0xFF	End of data transfer	0-255	8-bit checksum of all preceding bytes in this transfer.

Note 1: Battery voltage, ambient temperature and motor current data are only available in the Full Data transmission when the 1 Hz Data transmission is disabled.



Page 140





8 Appendices

8.1 Neutral Detect Active States
8.2 Parts List
8.3 Intended Use and Regulatory Statement
8.3.1 Intended Use
8.3.2 Device Classification
8.3.3 Compliance and Conformance with Standards 145
8.3.4 Programming Adapter
8.4 Service life
8.5 Maintenance
8.6 Warranty
8.7 Safety and Misuse Warnings / Notices
8.7.1 Warnings and notices to be included in the User
Manual
8.7.2 Service and Configuration Warnings / Notices
8.8 Electromagnetic Compatibility (EMC)
8.8.1 Minimising Emissions
8.9 Environmental statement 151
8.10 Labels
8.10.1 Product label
8.10.2 Motor / battery connector label (160 A and 180 A
modules only)
8.10.3 Version label

Appendices



8.1 Neutral Detect Active States

The following options are available to setup a Neutral Detect circuit.

Active State	Switch in Neutral	Switch connected to	Neutral	Driving	Short circuit in Neutral	Short circuit while driving	Open wire in neutral	Open wire while driving
Low	Closed	B- (Pin 13)	No Fault	No Fault	No Fault	No Driving, FC7	FC7	Cannot start driving with an open wire, but a wire break during driving is not detected*
High	Closed	B+ (Pin 7)		No Fault	No Fault	No Driving, FC7	FC7	Cannot start driving with an open wire, but a wire break during driving is not detected*
Open	Open	B- (Pin 13) or B+ (Pin 7)	No Fault	No Fault	FC7	Cannot start driving with a short circuit, but a short circuit during driving is not detected*	No Fault	FC7

*As soon as the throttle is returned to neutral, the wire fault will result in FC7 and Drive Inhibit.



8.2 Parts List

Dynamic RHINO2 Installation Manuals			
Part Description	DCL Part #	Qty/Unit	[]
Dynamic RHINO2 Installation Manual	GBK51948	1	

Dynamic RHINO2 Connectors				
Part Description	DCL Part #	MPN	Qty/Unit	Flammability (UL 94)
DS90 Motor/Park brake Adaptor Loom	GLM51981	N/A	-	V-2
DS120 Motor/Park brake Adaptor Loom	GLM51983	N/A	-	V-2
RHINO2 Battery/Actuator Adaptor Loom	GLM51984	N/A	-	V-2
RHINO2 Motor-4/Ring Terminal Adaptor Loom	GLM51985	N/A	-	V-2
RHINO2 Battery-6/Ring Terminal Adaptor Loom	GLM51986	N/A	-	V-2
RHINO2 Logic Adaptor Loom	GLM51987	N/A	-	V-0
Loom Kit RHINO2 Logic	GSM51982	N/A	-	V-0
Loom Kit RHINO2 4W Motor + 6W Battery	GSM51988	N/A	-	V-0
Loom Kit RHINO2 Ring Terminals	GSM51989	N/A	-	V-0
Crimp Terminal M5 Ring Yellow 10-12AWG	GCN1286	0190700123	8	V-0
Crimp Terminal Female Spade 18-22AWG Red Insulated	GCN1282	0190170014	2	V-0
Tyco 250 Series Lance Connector Housing 4 Way Plug	GCN0688 GCN51970	172134-1 N/A	1	V-2 V-0
Tyco 250 Series Lance Connector Housing 6 Way Plug	GCN0689 GCN51971	171898-1 N/A	1	V-2 V-0
Terminal Female 12-14AWG Tyco 250 Series Lance Connector	GCN0690	170258-2	10	N/A
Crimp Terminal 18-24AWG Molex Mini-fit Jnr	GCN0771	39-00-0039	16	N/A
Crimp Terminal 16AWG Molex Mini-fit Jnr	GCN0776	39-00-0212	4	N/A
Housing 2 Pin Molex Mini-fit Jnr	GCN0884	39-01-3028	1	V-0
Housing 4 Pin Molex Mini-fit Jnr	GCN0886	39-01-2045	1	V-0
Housing 14 Pin Molex Mini-fit Jnr	GCN0887	39-01-2145	1	V-0

Dynamic RHINO2 Terminal Cover		
Part Description	DCL Part #	Qty/Unit
Terminal Cover (with three screws)	GME51934	1



Dynamic RHINO2 Programming Tools

Part Description	DCL Part #	Qty/Unit	
Wizard Kit – Programming Kit Contains software, cables and adapter (no dongle)	DWIZ-KIT	1	release the magic
Dynamic Wizard Programming Adapter	DWIZ- ADAPT	1	WIZARD5
Molex Programming Adapter	DR- PRGLM02	1	
Serial to USB Adaptor	DX-USB- COM	1	
PCD Cable Assembly	DWIZ- CABLE	1	
Wizard Dongles – USB port OEM/Advanced version Enhanced dealer/Standard version Dealer/Lite version Factory version	DWD- OEM-U DWD-EDL- U DWD-DLR- U DWD-FAC- U	1 1 1	
DX Hand Held Programmer (includes DWIZ-ADAPT and DR-PRGLM02)	DX-HHP	1	



8.3 Intended Use and Regulatory Statement

8.3.1 Intended Use

The RHINO2 DS90, DS120, DS160 and DS180 modules are 90 Ampere, 120 Ampere, 160 Ampere and 180 Ampere, respectively, scooter controllers intended to provide drive control for scooters that utilise a single, 24V DC, brushed motor fitted with a park-brake. The controller will respond to user input demand in terms of direction (forward and reverse) and speed.

The DS90, DS120, DS160 and DS180 modules are designed for extended use (limited by the battery source capacity) and for both indoor and outdoor use.

The RHINO2 modules conform with global standards, and are intended for use with Class A, Class B, and Class C scooters, as defined in ISO7176 Part 5 and EN12184.

8.3.2 Device Classification

Europe

The RHINO2 Controller is a component of a Class I medical device as detailed in EU Regulation 2017/745 on Medical Devices.

USA

The RHINO2 Controller is a component of a Class II medical device (Powered Wheelchair) as detailed in 21 CFR § 890.3860.

The RHINO2 Controller is classified as 'wheelchair component' under 21 CFR 890.3920, Class 1(General Controls), with Product Code KNN.

8.3.3 Compliance and Conformance with Standards

In accordance with the device classification, the RHINO2 scooter controller is designed to enable the scooter manufacturer to comply with the relevant requirements of the European Medical Device Regulation 2017/745 (MDR) and 21 CFR § 820.30.

The RHINO2 scooter controller has been designed such that the combination of the scooter and controller, along with accessories as applicable, complies with the General Safety and Protection Requirements of the MDR by adopting relevant clauses of regulatory standards EN12184 and EN12182 and the FDA Consensus standard ANSI / RESNA WC-2:2009, Section 21 for performance.

However, final compliance of the complete scooter system with international and national standards is the responsibility of the scooter manufacturer or installer.

8.3.4 Programming Adapter

The programming adapter is intended to allow the RHINO2 scooter controllers the ability to communicate with the Wizard and the DX Hand Held Programmer. The adapter is not



intended to alter the controller in any way, but simply passes information to and from the controller. The information passed may alter the controller performance.

The intended power source is a 24 V battery supply from the controller. The intended environment is indoors or outdoors in dry conditions.

8.4 Service life

If the product has not been abused and all maintenance instructions as described in the maintenance section have been properly followed, the expected service life (i.e. minimum serviceable life expectancy) of the product is five (5) years. After this period, product reliability can no longer be guaranteed and Dynamic Controls recommends the product be replaced for safety reasons. Dynamic Controls accepts no responsibility/liability for product failure if the product is continued to be used after the expected service life period has expired.

Warning

It is the OEM's responsibility to state the expected service life, as well as the inspection and maintenance schedules for all cables.

8.5 Maintenance

The following instructions must be passed on to the operator before use of the product.

- 1. Keep all DYNAMIC electronic components free of dust, dirt and liquids. To clean the product, use a cloth dampened with warm soapy water. Do not use chemicals, solvents or abrasive cleaners, as this may cause damage to the product.
- 2. Once a month, check all vehicle components for loose, damaged or corroded components, such as connectors, terminals, or cables. Restrain all cables to protect them from damage. Replace damaged components. Check for and remove any foreign objects or material.
- 3. Every 6 months, test all switchable functions on the DYNAMIC electronics system to ensure they function correctly.
- 4. There are no user-serviceable parts in any DYNAMIC electronic component. Do not attempt to open any case or undertake any repairs, else warranty will be voided and the safety of the system may be compromised.
- 5. Where any doubt exists, consult your nearest service centre or agent.

Warning

It is the responsibility of the end user to maintain the unit in a state of good repair at all times. If any component is damaged in any way, or if internal damage may have occurred (for example by being dropped), have it checked by qualified personnel before operating.

8.6 Warranty

All equipment supplied by Dynamic Controls is warranted by the company to be free from faulty workmanship or materials. If any defect is found within the warranty period, the





company will repair, or at its discretion replace, the equipment without charge for materials or labour.

This warranty is subject to the provisions that the equipment:

- has been correctly installed.
- has been thoroughly checked upon completion of installation, and all programmable options correctly adjusted for safe operation prior to use.
- has been used solely in accordance with this manual and all other manuals of the Dynamic electronic components that are used on the scooter.
- has been properly connected to a suitable power supply in accordance with this manual.
- has not been subjected to misuse or accident, or been modified or repaired by any unauthorised personnel.
- has been used solely for the driving of electrically powered mobility scooters in accordance with the intended use and the recommendations of the scooter manufacturer.
- has not been connected to third party devices without the specific approval of Dynamic Controls.

8.7 Safety and Misuse Warnings / Notices

8.7.1 Warnings and notices to be included in the User Manual

The following warnings and notices are applicable to the installer and must be passed on to the end user before use of the product.

🛕 Warning

Do not install, maintain, or operate this equipment before you have read and understood all the instructions and all the manuals for this product and all the other products that you use or install together with this product. Follow the instructions of the manuals. If you do not follow all instructions, injury or damage can be the result.

Warning

- Immediately turn the controller off and consult your service agent if the vehicle:
 - Is damaged
 - Does not behave the same every time
 - Does not respond normally, the way you expect it to
 - Becomes hotter than normal
 - Smokes
 - Arcs
 - Does not change its speed when you adjust the speed reduction pot or the speed reduction switch (if one is available on your vehicle)
 - $\circ~$ Displays a fault on its fault indicator and the controller does not perform normally.

Warning

- Turn the controller off:
 - \circ $\,$ When you do not use it $\,$
 - Before you get in or get out of the vehicle

dynamic



- ° Before you use a mobile phone or a portable communications device near the vehicle
- If your vehicle drives by itself or against your will. When you turn the controller off the vehicle will halt.

Warning

Do not drive the vehicle if the controller indicates that the batteries are low, since the vehicle may stop operating and the user may become stranded. If the batteries become completely empty, the vehicle will stop suddenly and the batteries may be damaged.

🛕 Warning

Make sure that the battery charger that is used with the vehicle has a drive inhibit function that is correctly connected for use with the controller. The maximum voltage on the inhibit pin must not exceed 3 V if a battery voltage is to be detected when the battery charger is connected. If you are not sure, ask your dealer or vehicle manufacturer.

Warning

The controller can cause the vehicle to come to a sudden stop. If this can be dangerous to the operator, the installer must install a seat belt, and the operator must wear this seat belt.

Warning

Do not use the park brake release on a slope or when an occupant is on the scooter.

🛕 Warning

Performance adjustments must only be made by healthcare professionals, or by persons who completely understand the programming parameters, the adjustment process, the configuration of the vehicle, and the capabilities of the driver. Wrong settings can make the vehicle uncontrollable or unstable. An uncontrollable or unstable vehicle can cause an unsafe situation such as a crash, with the risk of serious injury to the driver or bystanders, or damage to the vehicle or surrounding property.

💧 Warning

Performance adjustments must only be made indoors or outdoors in dry conditions.

🛕 Warning

It is the responsibility of the scooter manufacturer to inform the scooter user about the scooter's stopping distances.

🛕 Warning

If a fault is indicated on the scooter, the battery should be isolated before transporting to service.

🚺 Note

For users within the European Union (EU), any serious incident that has occurred in relation to the device should be reported to Dynamic Controls and to the competent authority of the EU State in which you reside.

🚺 Note

Do not try to open or disassemble any case - there are no user-serviceable parts inside.

• The operator has the responsibility to keep the vehicle in a good safe operating condition. To protect all the components (for example the cables) from damage, the





operator must fasten them in optimum positions.

- Do not touch the connector pins. If you touch the pins, they can become dirty or they can be damaged by electrostatic discharge.
- In the case of an emergency while the vehicle is driving, press the On/Off button or turn the key switch to perform an emergency stop and turn the controller off.
- If there is a risk of collision with a person or object in close proximity, use the speed dial to reduce the speed of the scooter.
- If operators of the vehicle are left with limited or no mobility for any reason (for example, because the vehicle loses electric power or breaks down), it is important that they can still call for assistance from wherever they may be.
- Go downhill slowly. When the vehicle drives downhill, the motors act as a dynamo and generate energy. The controller sends the generated energy from the motor to the battery. This charges the battery. However, if the battery is fully charged, it cannot accept the generated energy any more. When this happens, there is a risk of damage to the battery or an explosion. To prevent this risk, the controller forces the vehicle to slow down until the battery can accept more energy. After this, it allows the vehicle to speed up again. The result of this will be sudden speed changes of the vehicle. To prevent these speed changes with fully charged batteries, turn on the lights (if fitted) and decrease the speed of the vehicle when going downhill.
- Operation of a vehicle on steep slopes can be dangerous. Before you drive up or down a slope, make sure that the slope does not exceed the capability of the vehicle.
- Make sure that the controller does not become colder or hotter than the minimum and maximum temperatures specified in this manual.
- Most electronic equipment is influenced by Radio Frequency Interference (RFI). Be careful when portable communications equipment is used in the area around such equipment. Dynamic Controls has made every effort to make sure that RFI does not change the behaviour of the controller, but very strong signals can still cause a problem. The vehicle manufacturer has the responsibility to make sure that the vehicle is tested according to local EMC regulations.
- The battery charger socket is to be used exclusively for the intended purpose. Warranty will be voided if any unauthorised device is connected to this port.
- When a scooter is driven uphill the controller will indicate a thermal fault if either the controller or the motor becomes very hot. In this situation the controller will reduce the available motor current to protect the controller and motor. It is possible with this reduced performance, that the controller is unable to provide sufficient power to the motor to hold the scooter on the slope and so as a safety precaution, the controller may force the scooter to a stop with the park brake applied when the user is attempting to continue driving. If the scooter operator observes this thermal fault indication (same indication as Stall timeout or Overcurrent fault) the recommended response is to immediately stop driving by releasing the throttle to neutral, then to wait for at least 30 seconds before attempting to continue driving.

The following safety information shall also be provided to all scooter operators:

- instructions on the interpretation of the battery gauge;
- any special environmental storage conditions;

dynamic



• the causes of electromagnetic interference and possible effects on the scooter.

8.7.2 Service and Configuration Warnings / Notices

The following warnings and notices are applicable to the installation technician and the dealer or the therapist who supplies the vehicle to the end user.

Warning

The dealer, therapist or other agent who supplies the vehicle to the end user has the responsibility to make sure that the vehicle is correctly configured for the needs of that user.

Warning

For each individual user, the vehicle set up and configuration should take into consideration his or her: • technical knowledge, experience and education, and

° medical and physical condition, including the level of disability and capability (where applicable).

🛕 Warning

Prior to handing over the vehicle, make sure that users are fully able to operate the product by giving them appropriate training on functionality and safety features, and having them test-drive the vehicle in a safe area in the presence of their agent.

🛕 Warning

The controller can cause the vehicle to come to a sudden stop. If this can be dangerous to the operator, the installer must install a seat belt and the operator must wear this belt.

🚺 Note

It is the responsibility of the manufacturer, dealer, therapist, or other suitably trained personnel, to determine the most appropriate installation suitable for any single user.

- It is the responsibility of the installer to make sure that accessories that are connected to the wires of the vehicle do not interfere with the operation of the controller.
- Do not use the vehicle frame as the earth return. Any electrical low-resistance connection to the frame is a safety risk and is not allowed by international safety standards.
- If the vehicle loses electric power, it is important that an attendant is able to move the vehicle easily.
- After you have completed the installation, check it thoroughly. Correctly adjust all programmable options before the vehicle is used.
- After you have configured the vehicle, check to make sure that the vehicle performs to the specifications entered in the programming procedure. If the vehicle does not perform to specifications, reprogram it. Repeat this procedure until the vehicle performs to specifications. If the wanted operation cannot be reached, contact your service agent.
- After maintenance or service of the vehicle, check the functional operation of all components that are externally connected to the controller, such as:



- lights
- external switches
- DCI/ACI/OBC resistor switch circuits (including programmed slowdown behaviour)
- For learner drivers, set the drive performance parameters, such as the maximum speed, acceleration and deceleration rates (see section *6.5.3 Drive Performance*) to suit their ability.
- It is the responsibility of the OEM and installer to make sure that the maximum driving speed of the vehicle is limited as appropriate when the vehicle is in a mechanically unstable position, for example when the seat is raised.
- It is the responsibility of the therapist/installer to minimise any risk of use error, including those arising from ergonomic features and/or the environment in which the device is intended to be used
- After configuring the system with either the DX-HHP hand-held programmer or the PC-based Wizard programmer, make sure:
 - the programming has completed correctly and verify that the program has written as requested;
 - ° vehicle safety is tested;
 - $^\circ~$ the user is capable of understanding and driving the vehicle.

8.8 Electromagnetic Compatibility (EMC)

Dynamic Controls Electronic Controllers have been tested on typical vehicles to confirm compliance with the following appropriate EMC standards:

USA: ANSI/RESNA WC-2:2009 Sec 21 Europe: EN 12184: 2014 12.1

National and international directives require confirmation of compliance on particular vehicles. Since EMC is dependent on a particular installation, each variation must be tested. The guidelines in this section are written to assist with meeting EMC requirements in general.

8.8.1 Minimising Emissions

To minimise emissions and to maximise the immunity to radiated fields and ESD, follow the *General Wiring Recommendations* in section 5.3.1 of this manual.

8.9 Environmental statement

Dynamic Controls confirms that the product variants specified in this manual, as subassemblies of electronic and electrical equipment supplied for further integration by a medical device manufacturer, conform to applicable requirements of Directive 2011/65/EU, recast of Directive 2002/95/EC - Restriction of the use of certain Hazardous Substances in electrical and electronic equipment.






This product has been supplied from an environmentally aware manufacturer. Please be environmentally responsible and recycle this product at the end of its life through your local recycling facility.

This product may contain substances that could be harmful to the environment if disposed of into a landfill.

Do not dispose of this product in fire.

8.10 Labels

The following section highlights the symbols and labels that can be found on the RHINO2 modules.



5 - Module description



8.10.2 Motor / battery connector label (160 A and 180 A modules only)





Figure 69: Motor / battery connector label

Кеу	
1 — Battery connections	3 — Torque specification
2 — Motor connections	4 — Dynamic Controls logo

8.10.3 Version label



Кеу	
1 — Module	3 — Serial number
2 — Firmware version	

The information contained on the version label is "as shipped from factory". Any maintenance of the version label following a firmware upgrade by a third party is the responsibility of that third party.



Page 154





#

1 Hz Data *111, 132* 5V Gauge *120* 12V Gauge *120*

Α

Acceleration Limit Active Error Code Active Flash Code Active States *116, 142* Advanced Diagnostics Logs Ambient Temperature *29, 111, 132*

В

Bad Motor Connection 118, 126 BatGauge Sensitivity 110 Battery 12, 21, 56, 63, 68, 90, 108, 111, 118, 130, 132, 143 Battery Charging and Programming Connections 29 Battery Connections 23 Battery Cut-Off Voltage 109 Battery Deep Discharge Count 132 Battery Fault 118, 124 Battery Gauge Dead-band 109 Battery Gauge Estimate 132 Battery Gauge High Warning 109 Battery Gauge Low Warning 109 Battery Gauge Maximum 109 Battery Gauge Minimum 109 Battery Gauge Output 46 Battery Low 118, 124 Battery Management 68, 108 Battery Negative 29, 34, 90, 128 Battery Overcharge Count 132 Battery Positive 29, 34, 128 Battery Voltage 63, 118, 124, 132 BC4 33, 111, 133 Beeper 34, 73, 119 Beeper Off Time 74 Beeper On Time 74 Beeper Output 46 Boost Current 12, 70, 100

Boost Time *12*, *70*, Brake Light *47*, *69*, Brake Off Fault *118*, Brake On Fault *118*,

С

Charge/Program Connector 30 Charger Inhibit 30, 69, 114, 118, 124 Charger Inhibit Status 132 Charger/Programmer Socket 32, 56 Charging Current 12 Class A 145 Class B 145 Class C 145 Connections 20 Controller Current Rating 132 Controller Drive Count 132 Controller Driving Time 132 Controller Fault 118, 126 Controller Power Modes 51 Controller Power Up Count 132 Controller Too Hot 118, 124 Current Limit 70, 91, 100, 124 Current Limit Time-out 124 Current Rating 12 Current Sense Fault 118, 126

D

Deceleration Limit 94 Deep Discharge Beeper 50, 74 Deep Discharge Count 130 Downhill Speed Limiting 104 Drive Count 61, 130 Drive Inhibit 49, 114, 118, 124, 142 Drive inhibit / OONAPU / 126 Drive Performance 66, 83, 151 Drive Time 61, 130 Driving Status 132 Dual Decode 8, 42 Dynamic 1, 23, 64, 128, 133, 143, 161 DYNAMIC Wizard 127

Ε

EEPROM Fault *118, 126* EMC Emissions *20*



Emergency Deceleration 44, 88 Enable 1Hz Data 111, 134 Enable Beeper 73 Enable SRW Open Circuit Testing 66, 82 ESD Immunity 20 External Ambient Temperature Sensor 29 External Ambient Temperature Sensor Input 29

F

Fault High *120* Fault Log *127* Fault Low *120* Flash Code *28, 101, 118, 124, 132* Flash Code Beeper *73* Flash Code Type *50, 117-118* Forward Acceleration *70, 83* Forward Deceleration *70, 84* Full Data *111, 132*

Н

Hand Held Programmer (HHP) 57, 97, 127 HHP Fault Codes 61, 128 Battery 12, 20, 56, 128, 143 I/O 129 Internal fault 129 Motor 12, 16, 57, 128, 132, 143 Park brake 13, 128, 143 Throttle 8, 12, 34, 57, 129 User 16, 55, 128 High Battery Fault 118, 124 High Battery Voltage 118, 126 High Pedal Disable Fault 118, 126 HW Current Limit Decel Scalar 92

I

I/O *129* Internal Condition Code Internal Fault ISO Test Resistor

Κ

Key OFF 52

Key ON 51 Key Switch 34, 116, 121 Key Switch Input 45 Key Switch Status 121, 132 Key Switch Status LED 121

L

Load Compensation 25, 70, 97 Load Compensation Damping 67, 99 Low Battery 118, 124 Low Battery Fault 118, 124 Low Power Mode 51, 112, 134 Low Power Mode Duration 112 Lowest (Minimum) Forward Speed 86

Μ

Main Contactor Driver Off Fault 118, 126 Main Contactor Driver On Fault 118, 126 Main Contactor Fault 118, 126 Max Motor V Demand Limit 104 Max Motor V Ramp Down Time 104 Max Motor V Ramp Up Time 104 Max Motor V Scalar 103 Maximum Forward Speed 70, 83, 94 Maximum Forward Speed Limit 94 Maximum Load Compensation 98 Maximum Motor Voltage 102 Maximum Reverse Speed 70, 85, 94 Maximum Reverse Speed Limit 94 Maximum Throttle Voltage 79 Micro-Switch 38 Minimum Forward Speed 86, 94 Minimum Forward Speed Limit 94 Minimum Reverse Speed 86, 94 Minimum Reverse Speed Limit 94 Minimum Throttle Voltage 79 Month of Manufacture 132 Motion Beeper 73 Motor 12, 21, 63, 67, 70, 95, 111, 118, 125, 132, 143 Motor (A) 130 Motor (V) 130 Motor Connections 25 Motor Continuous Current 70, 95 Motor Cooling Time 95



Motor Current 63, 132 Motor Fault 118, 125 Motor Heating Time 95 Motor Management 67, 95 Motor Protection 26, 95 Motor Protection Parameters 95 Motor Reverse 96 Motor Short Circuit 118, 126 Motor Testing 26, 102 Motor Voltage Fault 118, 125 Mounting Orientation 17 Multi-function Input 48 Charger Inhibit 34, 48 Neutral Detect 48 Profile 2 34, 48 Release Brake 48 Reverse Drive 34.48 Slow 34, 48 Slow/Stop 48 Slow/Stop Fwd 48 Slow/Stop Rev 48 SRW 48 SRW (variable) 48 Multi-function Input/Program (P/I) 29 Multi-function Inputs Configuration 69, 113 Multi-function Output 50 5 V Battery Gauge 50 12 V Battery Gauge 50 Beeper 34, 50, 57, 124 Brake Light 50 Fault High 50 Fault Low 50 Power Status 50, 69 Reversing Light 50 Status 50, 69, 124, 132 Status High 50, 69 Status Low 34, 50, 69 Multi-function Outputs Configuration 69, 118 Multi-function Pins 48 Ν Neutral Detect 37, 69, 115, 142

NTC Thermistor 33

0

Operating Operating Humidity Operating Voltage Optical Switch Other Error Over Voltage Fault *118, 126* Overvoltage Rollback Overvoltage Warning

Ρ

Park Brake 14, 28, 118, 128, 143 Park Brake Connections 27 Park Brake Fault 124 Park Brake Management 68, 106 Park Brake Negative 27 Park Brake Neutral Delay 106 Park Brake Output 13 Park Brake Positive 27 Park Brake Release Delay 107 Park Brake Testing 29, 106 Physical Interface 133 Pin [X] Function 113 Pin 4 Function 113 Pin 6 Function 113 Pin 12 Function 113 Pin 14 Function 113 Prog/Inh Pin Function 113 Pin 3 Function 69, 119 Pin 6 Function 40 Pin 10 Function 120 Pin 11 Function 69, 119 Pin 12 Function 40 Pin Function 113 Pin Status 132 Power Off After Sleep 75 Power Section Fault 118, 126 Power Status 50, 69, 119 Powered Down 51 Powered Up Count 130 Powered Up Time 130 Profile 34, 57, 70 Profile 2 42, 114

Normal Mode 51



Prog/Inh Pin Function Programming Menu Protection Rating Push Speed

Q

Quiescent Current (Idle) *12* Quiescent Current (Key-Off) *12* Quiescent Current (Sleep) *12*

R

Release Brake 28, 69, 89, 113 Remembered Load Compensation 67, 99 Reverse Acceleration 70, 85 Reverse Deceleration 85 Reverse Drive 35, 69, 76, 113 Reverse Supply Voltage 12 Reversing Beeper 65, 74 Reversing Light 47 RHINO2 Software Version / Revision 132 Roll-away Speed 89 Run-time Readings 130

S

Scooter / R-Series Flash Codes 124 Battery Low 118, 124 Controller Too Hot 118 Controller too hot 124 Current Limit Time-out 124 Drive Inhibit 49, 114, 124, 142 High Battery Fault 118, 124 Low Battery Fault 118, 124 Motor Voltage Fault 118, 125 Other error 125 Park Brake Fault 124 Speed Pot Fault 124 Serial Number *132, 152* Service Period 111, 131 Service Scheduler 111, 131 SHARK Flash Codes 125 Battery Fault 118, 125 Controller too hot 125 Current Limit Time-out 125 Motor Fault 118, 125 Park Brake Fault 125

System Fault 125 Throttle Fault 59, 125 User Fault / Drive Inhibit 125 Shipping Weight 14 Single Throttle Wiper 36 Single Wire Communications 132 Single-Ended 35, 65, 76, 113 Slam Brake Enable 82 Slam Brake Threshold 82 Slam Braking 88 Sleep Beeper 73 Sleep Mode 51, 72, 120 Sleep on Fault 75 Sleep Timer 72 Slow 31, 58, 69, 83, 114 Slow/Stop 44, 69, 114 Slow/Stop FWD 48, 69, 114 Slow/Stop REV 48, 69, 115 Soft Finish 87 Soft Start Period 87 Speed Limit 12, 42, 60, 81, 94, 118, 124, 132 Speed Limit Pot 12, 41, 81, 118, 124 Speed Limit Pot – Pin 9 (linear) 12 Speed Limit Pot (SLP) 34 Speed Limit Pot Fault 118, 126 Speed Pot Fault 124 Speed Reduction Wiper 12, 42, 90, 129 Speed Reduction Wiper – Pin 4 (log) 12 Speed Scale 42, 90 SRW 8, 40, 82, 90, 115, 124 SRW (variable) 42, 69, 90, 115 SRW Forward Speed Limit 90 SRW Forward Speed Scale 90 SRW Reverse Speed Limit 90 SRW Reverse Speed Scale 90 SRW Scaling Resistor (Ohm) 66, 91 Stall Timeout 13, 101 Status 69, 72, 76, 101, 113, 119, 124, 132 Status High 50, 69, 120 Status Information 132 Status Low 34, 69, 120 Storage 14 SW Current Limit Decel Scalar 91



Swap Throttle Direction 72 System Fault 125 System Options 69, 111

Т

Temperature 14, 29, 63, 130 Operating 14 Storage 14 Terminal Cover 19, 143 Testing 54, 79, 102, 106 TH14 33, 111, 133 Thermal Cut-back / Stall 118, 126 Thermal Rollback End 67, 96 Thermal Rollback Start 67, 96 Thermistor 33 Throttle 8, 12, 34, 57, 65, 72, 76, 86, 118, 124 Throttle (V) 130 Throttle Configuration 35, 65, 76 Throttle Dead-band 78 Throttle Fault 79, 115, 118, 125 Throttle Fault Non Latching 81 Throttle Full Scale Deflection 77 Throttle Input 76 Throttle Negative 34, 36, 41, 79, 86, 129 Throttle Neutral Offset 76 Throttle OONAPU Testing 80 Throttle Positive 34, 36, 41, 79, 86, 129 Throttle Resistance (Pin 2 - Pin 8) 12 Throttle Response 78 Throttle Testing 79 Throttle Trip 118, 126 Throttle Type 35, 76 Single-ended 35 Uni-polar 35 Wig-wag 35 Throttle Wiper 34, 36 Tiller Connector 32, 34, 129 Tiller Head 34 Time Controller Powered Up 132 Type 3 Flash Codes Bad Motor Connection 118, 126 Controller Fault 118, 126 Controller too hot 126 Current Limit Time-out 126

Drive Inhibit 126 High Battery Voltage 118, 126 Low Battery 118, 126 Motor Short Circuit 118, 126 Park Brake Fault 126 Throttle Fault 126 Type 4 Flash Codes Brake Off Fault 118, 126 Brake On Fault 118, 126 Current Sense Fault 118, 126 Drive inhibit / OONAPU / 126 EEPROM Fault 118, 126 High Pedal Disable Fault 118, 126 Main Contactor Driver Off Fault 118, 126 Main Contactor Driver On Fault 118, 126 Main Contactor Fault 118, 126 Motor Voltage Fault 126 Over Voltage Fault 118, 126 Power Section Fault 118, 126 Precharge Fault 126 Speed Limit Pot Fault 118, 126 Thermal Cut-back / Stall 118, 126 Throttle Trip 118, 126 Under Voltage Fault 118, 126

U

Under Voltage Fault *118, 126* Undervoltage Rollback End *108* Undervoltage Rollback Start *108* Uni-polar *35, 65, 76, 113* Usage Counters *130* User *43, 65, 72, 125, 147* User Fault / Drive Inhibit *125* User Personalisation *65, 72*

W

Wakeup Style Wig-wag *35*, *65*, *72*, *76*, Wire Size Wiring *20* Wiring Diagram



Х

XLR *44, 56* XLR Charger Socket *32, 56*

Y

Year of Manufacture 132

Dynamic Controls HQ

39 Princess Street Riccarton Christchurch 8041 New Zealand

PO Box 1866 Christchurch 8140 New Zealand

Phone: +64 3 962 2519 Fax: +64 3 962 2966

Dynamic Europe Limited

Unit 7, Finepoint Way Kidderminster Worcestershire DY11 7FB United Kingdom

GB VAT No. 487 3377 02, Registered in England No. 2385287

Phone: +44 1562 826 600 Fax: +44 1562 824 694

All enquiries: eusales@dynamiccontrols.com

North America Phone: 1-855-207-9942

......

All enquiries: sales@dynamiccontrols.com

Dynamic Controls Asia (Taiwan)

Floor 4-2, No. 59, Tien Hsiang Road Chung Shan District Taipei 10452 Taiwan R.O.C.

Phone: +886 955 335 243 Fax: +886 225 981 562

All enquiries: asiasales@dynamiccontrols.com

Dynamic Controls Asia (China) Phone: +86 512 6289 2847

All enquiries: asiasales@dynamiccontrols.com



We are Dynamic

Dynamic is a worldleading designer and manufacturer of electronic controls for power wheelchairs and scooters.

Find out about us



Find product information and downloads relating to all our current products.

Need a resource? We have you covered.



www.dynamiccontrols.com